

Veritas NetBackup™ Appliance Commands Reference Guide

Release 2.7.3

NetBackup 52xx and 5330

Document Revision 1



Veritas NetBackup™ Appliance Commands Reference Guide

Release 2.7.3 - Document Revision1

Legal Notice

Copyright © 2016 Veritas Technologies LLC. All rights reserved.

Veritas, the Veritas Logo and NetBackup are trademarks or registered trademarks of Veritas Technologies LLC or its affiliates in the U.S. and other countries. Other names may be trademarks of their respective owners.

This product may contain third party software for which Veritas is required to provide attribution to the third party ("Third Party Programs"). Some of the Third Party Programs are available under open source or free software licenses. The License Agreement accompanying the Software does not alter any rights or obligations you may have under those open source or free software licenses. Refer to the third party legal notices document accompanying this Veritas product or available at:

<https://www.veritas.com/about/legal/license-agreements>

The product described in this document is distributed under licenses restricting its use, copying, distribution, and decompilation/reverse engineering. No part of this document may be reproduced in any form by any means without prior written authorization of Veritas Technologies LLC and its licensors, if any.

THE DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID. VERITAS TECHNOLOGIES LLC SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE FURNISHING, PERFORMANCE, OR USE OF THIS DOCUMENTATION. THE INFORMATION CONTAINED IN THIS DOCUMENTATION IS SUBJECT TO CHANGE WITHOUT NOTICE.

The Licensed Software and Documentation are deemed to be commercial computer software as defined in FAR 12.212 and subject to restricted rights as defined in FAR Section 52.227-19 "Commercial Computer Software - Restricted Rights" and DFARS 227.7202, et seq. "Commercial Computer Software and Commercial Computer Software Documentation," as applicable, and any successor regulations, whether delivered by Veritas as on premises or hosted services. Any use, modification, reproduction release, performance, display or disclosure of the Licensed Software and Documentation by the U.S. Government shall be solely in accordance with the terms of this Agreement.

Veritas Technologies LLC
500 E Middlefield Road
Mountain View, CA 94043

<http://www.veritas.com>

Technical Support

Technical Support maintains support centers globally. All support services will be delivered in accordance with your support agreement and the then-current enterprise technical support policies. For information about our support offerings and how to contact Technical Support, visit our website:

<https://www.veritas.com/support>

You can manage your Veritas account information at the following URL:

<https://my.veritas.com>

If you have questions regarding an existing support agreement, please email the support agreement administration team for your region as follows:

Worldwide (except Japan)

CustomerCare@veritas.com

Japan

CustomerCare_Japan@veritas.com

Documentation

The latest documentation is available on the Veritas website:

<https://sort.veritas.com/documents>

Documentation feedback

Your feedback is important to us. Suggest improvements or report errors or omissions to the documentation. Include the document title, document version, chapter title, and section title of the text on which you are reporting. Send feedback to:

APPL.docs@veritas.com

You can also see documentation information or ask a question on the Veritas community site:

<http://www.veritas.com/community/>

Veritas Services and Operations Readiness Tools (SORT)

Veritas Services and Operations Readiness Tools (SORT) is a website that provides information and tools to automate and simplify certain time-consuming administrative tasks. Depending on the product, SORT helps you prepare for installations and upgrades, identify risks in your datacenters, and improve operational efficiency. To see what services and tools SORT provides for your product, see the data sheet:

https://sort.veritas.com/data/support/SORT_Data_Sheet.pdf

Contents

Chapter 1	Overview	10
	About NetBackup appliance commands	10
	Command limitations on appliances that are not configured	11
	Logging into the NetBackup Appliance Shell Menu	11
	About NetBackup Appliance Shell Menu usage	11
	About the NetBackup Appliance Shell Menu	12
	About the NetBackup Appliance Shell Menu command views	15
	About the commands under the Appliance view	15
	About the commands under the Manage view	16
	About the commands under the Monitor view	23
	About the commands under the Network view	24
	About the commands under the Reports view	26
	About the commands under the Settings view	26
	About the commands under the Support view	28
Appendix A	Main > Appliance view commands	32
	Main > Appliance > Master	33
	Main > Appliance > Media	34
	Main > Appliance > Remove	35
	Main > Appliance > ShowDedupPassword	36
	Main > Appliance > Status	37
Appendix B	Main > Manage > FibreChannel view commands	39
	Main > Manage > FibreChannel > Clean	40
	Main > Manage > FibreChannel > Configure	42
	Main > Manage > FibreChannel > Reset	46
	Main > Manage > FibreChannel > Scan	47
	Main > Manage > FibreChannel > Show	48
	Main > Manage > FibreChannel > Statistics	51
Appendix C	Main > Manage > Libraries view commands	53
	Main > Manage > Libraries > Configure	54
	Main > Manage > Libraries > Deny	55

Main > Manage > Libraries > Down	56
Main > Manage > Libraries > Inventory	57
Main > Manage > Libraries > List	58
Main > Manage > Libraries > Requests	59
Main > Manage > Libraries > Reset	60
Main > Manage > Libraries > Resubmit	61
Main > Manage > Libraries > Up	62

Appendix D Main > Manage > Libraries > Advanced > ACS view commands 63

Main > Manage > Libraries > Advanced > ACS	64
Main > Manage > Libraries > Advanced > ACS	65
Main > Manage > Libraries > Advanced > ACS	66
Main > Manage > Libraries > Advanced > ACS	67
Main > Manage > Libraries > Advanced > ACS	68
Main > Manage > Libraries > Advanced > ACS	69
Main > Manage > Libraries > Advanced > ACS	70
Main > Manage > Libraries > Advanced > ACS	71
Main > Manage > Libraries > Advanced > ACS	72
Main > Manage > Libraries > Advanced > ACS	73

Appendix E Main > Manage > License view commands 74

Main > Manage > License > Add	75
Main > Manage > License > List	76
Main > Manage > License > ListInfo	77
Main > Manage > License > Remove	78

Appendix F Main > Manage > MountPoints view commands 79

Main > Manage > MountPoints > List	80
Main > Manage > MountPoints > Mount	81
Main > Manage > MountPoints > Unmount	83

Appendix G Main > Manage > NetBackup CLI view commands 84

Main > Manage > NetBackupCLI > Create	85
Main > Manage > NetBackupCLI > Delete	87
Main > Manage > NetBackupCLI > List	88
Main > Manage > NetBackupCLI > PasswordExpiry	89

Appendix H	Main > Manage > OpenStorage view commands	91
	Main > Manage > OpenStorage > Install	92
	Main > Manage > OpenStorage > List	94
	Main > Manage > OpenStorage > Readme	96
	Main > Manage > OpenStorage > Share	98
	Main > Manage > OpenStorage > Uninstall	99
Appendix I	Main > Manage > Software view commands	100
	Main > Manage > Software > Cancel	101
	Main > Manage > Software > Delete	102
	Main > Manage > Software > Download	103
	Main > Manage > Software > DownloadProgress	104
	Main > Manage > Software > Install	105
	Main > Manage > Software > List	106
	Main > Manage > Software > LiveUpdateClients	108
	Main > Manage > Software > Readme	109
	Main > Manage > Software > Rollback	111
	Main > Manage > Software > Share	113
	Main > Manage > Software > UpgradeStatus	114
Appendix J	Main > Manage > Storage view commands	115
	Main > Manage > Storage > Add	116
	Main > Manage > Storage > Create	117
	Main > Manage > Storage > Delete	119
	Main > Manage > Storage > Edit	120
	Main > Manage > Storage > Monitor	123
	Main > Manage > Storage > Move	124
	Main > Manage > Storage > Remove	126
	Main > Manage > Storage > Resize	128
	Main > Manage > Storage > Scan	130
	Main > Manage > Storage > Show	132
Appendix K	Main > Manage > Tapes view commands	142
	Main > Manage > Tapes > Cleaning	143
	Main > Manage > Tapes > Delete	144
	Main > Manage > Tapes > Eject	145
	Main > Manage > Tapes > Freeze	146
	Main > Manage > Tapes > Inventory	147
	Main > Manage > Tapes > List	148

	Main > Manage > Tapes > ListNetBackupMedia	149
	Main > Manage > Tapes > Suspend	150
	Main > Manage > Tapes > Unfreeze	151
	Main > Manage > Tapes > Unsuspend	152
Appendix L	Main > Manage > Certificates	153
	Main > Manage > Certificates > Generate	154
	Main > Manage > Certificates > Delete	155
Appendix M	Main > Monitor view commands	156
	Main > Monitor > Beacon	157
	Main > Monitor > MemoryStatus	159
	Main > Monitor > NetBackup	162
	Main > Monitor > NetworkStatus	163
	Main > Monitor > SDCS	164
	Main > Monitor > Top	166
	Main > Monitor > Uptime	167
	Main > Monitor > Who	168
Appendix N	Main > Monitor > Hardware view commands	169
	Main > Monitor > Hardware ShowComponents	170
	Main > Monitor > Hardware ShowErrors	172
	Main > Monitor > Hardware ShowHealth	173
	Main > Monitor > Hardware ShowPreviousRun	180
	Main> Monitor > Hardware ShowPreviousRunErrors	182
Appendix O	Main > Network view commands	183
	Main > Network > Configure	185
	Main > Network > Date	187
	Main > Network > DNS	188
	Main > Network > Gateway	190
	Main > Network > Hostname	192
	Main > Network > Hosts	193
	Main > Network > IPv4	194
	Main > Network > IPv6	195
	Main > Network > LinkAggregation	196
	Main > Network > NetStat	200
	Main > Network > NTPServer	201
	Main > Network > Ping	202
	Main > Network > SetProperty	203
	Main > Network > Show	204

	Main > Network > TimeZone	205
	Main > Network > TraceRoute	206
	Main > Network > Unconfigure	207
	Main > Network > VLAN	208
	Main > Network > WANOptimization	211
Appendix P	Main > Network > Security (IPsec) view commands	215
	Main > Network > IPsec > Configure	216
	Main > Network > IPsec > Delete	217
	Main > Network > IPsec > Export	218
	Main > Network > IPsec > Import	219
	Main > Network > IPsec > Provision	220
	Main > Network > IPsec > Refresh	221
	Main > Network > IPsec > Show	222
	Main > Network > IPsec > Unconfigure	223
Appendix Q	Main > Reports view commands	224
	Main > Reports > Deduplication	225
	Main > Reports > Process	226
Appendix R	Main > Settings view commands	227
	Main > Settings > Deduplication	228
	Main > Settings > FibreTransport	236
	Main > Settings > LifeCycle	240
	Main > Settings > LiveUpdateServer	244
	Main > Settings > NetBackup	245
	Main > Settings > Password	249
	Main > Settings > Share	250
	Main > Settings > Sysctl	251
	Main > Settings > SystemLocale	253
Appendix S	Main > Settings > Alerts view commands	255
	Main > Settings > Alerts > CallHome	256
	Main > Settings > Alerts > Email	263
	Main > Settings > Alerts > Hardware	265
	Main > Settings > Alerts > SNMP	266
Appendix T	Main > Settings > Notifications view commands	274

	Main > Settings > Notifications > LoginBanner	275
Appendix U	Main > Settings > Security view commands	278
	Main > Settings > Security > Authorization	279
Appendix V	Main > Settings > Security > Authentication view commands	282
	Main > Settings > Security > Authentication > ActiveDirectory	283
	Main > Settings > Security > Authentication > Kerberos	285
	Main > Settings > Security > Authentication > LDAP	287
	Main > Settings > Security > Authentication > LocalUser	294
Appendix W	Main > Support view commands	295
	Main > Support > Checkpoint	297
	Main > Support > Cleanup > RemoveShelfEntries	301
	Main > Support > DataCollect	302
	Main > Support > Disk	304
	Main > Support > Errors	305
	Main > Support > FactoryReset	306
	Main > Support > InfraServices	311
	Main > Support > iostat	313
	Main > Support > IPMI	316
	Main > Support > KillRemoteCall	319
	Main > Support > Logs	320
	Main > Support > Maintenance	325
	Main > Support > Messages	327
	Main > Support > NBDNA	328
	Main > Support > nbperfchk	329
	Main > Support > NBSU	333
	Main > Support > Processes	334
	Main > Support > Reboot	335
	Main > Support > RecoverStorage	336
	Main > Support > Service	337
	Main > Support > ServiceAllowed	338
	Main > Support > Show	340
	Main > Support > Shutdown	344
	Main > Support > Storage Reset	345
	Main > Support > Storage SanityCheck	347
	Main > Support > Test	348

Overview

This chapter includes the following topics:

- [About NetBackup appliance commands](#)
- [Logging into the NetBackup Appliance Shell Menu](#)
- [About NetBackup Appliance Shell Menu usage](#)
- [About the NetBackup Appliance Shell Menu](#)
- [About the NetBackup Appliance Shell Menu command views](#)

About NetBackup appliance commands

The NetBackup Appliance Shell Menu is an interactive shell that is available on the appliances through SSH. This menu interface enables you to perform most of the administration functions that are necessary to administer the NetBackup appliances. You can use the NetBackup Appliance Shell Menu in place of the NetBackup Appliance Web Console for many operations. In addition, anyone who is limited to only SSH because of firewall restraints should use this shell menu.

This document contains detailed information about the NetBackup Appliance commands. Each command contains a brief description of the primary function of the command, a synopsis, and descriptions of the options that are listed in the synopsis. Some commands also contain notes and usage examples.

Note: It is possible that changes may occur after the documents have been initially released. The electronic versions of these documents on the Support website contain the most up-to-date information. You should refer to these documents for the latest information about the appliance. The documents are provided so that you can download and print them at any time.

[NetBackup Appliance Documentation page](#)

Command limitations on appliances that are not configured

Before an appliance can be managed, it must first be configured. The commands that are used for initial configuration are the only valid commands that can be executed on a new appliance, or a factory reset appliance. Commands other than those used for the initial configuration can exhibit unexpected or undesired behavior. To prevent this situation, it is a best practice to avoid using any management commands until after the appliance initial configuration has been completed.

For information on valid commands for appliances that are not configured, refer to the following documents:

NetBackup Appliance Initial Configuration Guide

NetBackup Appliance Commands Reference Guide

Logging into the NetBackup Appliance Shell Menu

The following procedure explains how to log into the NetBackup Appliance Shell Menu.

To log into the NetBackup Appliance Shell Menu

- 1 Connect to the NetBackup Appliance Shell Menu.
- 2 Enter the user name and password for the NetBackup appliance. By default, the user name `admin` has the password, `P@ssw0rd`.

Caution: For security reasons, you should change this password after you have installed the NetBackup appliance.

- 3 After a successful logon, the cursor is alongside the **Main_Menu** prompt.
- 4 Press the `?` key to display the available commands and shell views that are available for you to use.

See [“About the NetBackup Appliance Shell Menu command views”](#) on page 15.

About NetBackup Appliance Shell Menu usage

This section details the use, options, and organization of the NetBackup Appliance Shell Menu.

The initial view outlines the various categories of tasks you can perform from the command-line interface.

All the commands are auto-completed. You can press **Tab** or **Enter** to complete a command.

The following is a list of helpful tips on how to use the NetBackup Appliance Shell Menu:

- When you press the `?` key more information about the commands or sub-views that are available under that view. If you press `?` after you enter a command, the format and usage of the parameters for that command appear.
- When you press the space bar key the next parameter that needs to be entered is displayed.
- When you press the Enter key the next "mandatory" parameter that needs to be entered is displayed. A "mandatory" parameter is one that does not have default values.

Note: Command variables that are *italicised* or in angular barackets (`<>`) are mandatory variables; whereas command parameters that are in square brackets (`[]`) are optional. For example, in the `Main > Appliance > Add ApplianceName [AdminPassword]` command, where *ApplianceName* is a mandatory variable and `[AdminPassword]` is an optional parameter.

- Due to the introduction of the Red Hat Enterprise Linux (RHEL) Operating System in release 2.7.1, Secure Shell(SSH) sessions now have a limited idle time. Although the change to the RHEL operating system adds security by honoring the current session time limit, you may experience the following issues:
 - The user is logged out automatically if the SSH session remains idle up to the current session time limit.
 - Commands fail to complete if they require more time than the current session time limit. One example where you may experience this issue is when you add a large number of LDAP or AD users and user groups.

To help avoid these issues, keep the session alive for a longer duration by increasing the session time limit in the SSH client. For detailed configuration instructions, refer to your SSH client documentation.

About the NetBackup Appliance Shell Menu

When you enter the NetBackup Appliance Shell Menu, you enter on the `Main_Menu` view. This view is the starting point from which you can configure, manage, monitor, and support your appliance using the command line. The following table describes the views and commands that are available for you to use.

Table 1-1 NetBackup appliance commands and views from the `Main_Menu` view

Command	Explanation
<code>Appliance</code>	Use this command to enter the <code>Appliance</code> view to manage your master and media appliances. See “About the commands under the Appliance view” on page 15.
<code>Exit</code>	Use this command to exit the current shell and log out.
<code>Manage</code>	Use this command to enter the <code>Manage</code> view to manage your appliance. See “About the commands under the Manage view” on page 16.
<code>Monitor</code>	Use this command to enter the <code>Monitor</code> view to monitor NetBackup appliance activities. See “About the commands under the Monitor view” on page 23.
<code>Network</code>	Use this command to enter the <code>Network</code> view to be able to administer your network. See “About the commands under the Network view” on page 24.
<code>Reports</code>	Use this command to enter the <code>Reports</code> view to examine the running and historical state of the host. See “About the commands under the Reports view” on page 26.
<code>Settings</code>	Use this command to enter the <code>Settings</code> view to change the NetBackup appliance settings See “About the commands under the Settings view” on page 26.

Table 1-1 NetBackup appliance commands and views from the `Main_Menu` view (continued)

Command	Explanation
Shell	<p>This command appears on all of the other command views. Use the following commands to display reference manual help, command line history information, and to return to the main menu.</p> <ul style="list-style-type: none">■ <code>Shell Help</code> Displays the online reference manuals of the command line interface.■ <code>Shell History</code> Displays the command-line history of the current session. You can set a limit with this command that defines the size of the history list. A limit of zero means the list has no boundaries. Example of history output: <pre>Main_Menu> history 1 2 History 0 3 Support 4 Help 5 Return 6 History 4 7 Exit</pre>■ <code>Shell Main</code> Returns you to the main menu.
Support	<p>Use this command to enter the <code>Support</code> view to enable and administer support capabilities on your NetBackup appliance.</p> <p>See “About the commands under the Support view” on page 28.</p>
Return	<p>This command is not present on the <code>Main_Menu</code> view, however, it appears on all other views. Use this command to return you to the previous menu.</p>

See [“About NetBackup appliance commands”](#) on page 10.

See [“Logging into the NetBackup Appliance Shell Menu ”](#) on page 11.

About the NetBackup Appliance Shell Menu command views

The following sections detail the commands and views that are available for your appliance.

About the commands under the Appliance view

From within the Appliance view you can perform the following functions:

- Status of the appliance.
- Decommission an existing media appliance.
- View the NetBackup deduplication password.

The following table summarizes the commands that are available to you in the Appliance view depending on the role that you chose your appliance to take during the initial configuration.

Table 1-2

Command	Explanation
Master	Use this command to configure your appliance as a NetBackup master appliance. See Appliance > Master on page 33.
Media	Use this command to configure the appliance as NetBackup media server. See Appliance > Media on page 34.
Remove	Use this command to decommission an existing media appliance. See Appliance > Remove on page 35.
ShowDedupPassword	Use to display the NetBackup deduplication password of the domain. See Appliance > ShowDedupPassword on page 36.
Status	Use this command to display the current appliance status information. See Appliance > Status on page 37.

About the commands under the Manage view

From the appliance management view, **Manage**, you can perform the following functions:

- Administer the Fibre Transport HBA cards.
- Configure and inventory robotic tape libraries.
- Add, remove, and list license keys.
- Manage software updates.
- List and resize Storage Disk Pool Volumes of NetBackup.
- Manage the tape media for the appliance.
- Make the appliance logs available through a network share or network unshare. You can also set the debug logging level of the appliance logs.
- Run NetBackup commands.
- Manage OpenStorage plugins.
- Manage remote mount points.

The following table summarizes the commands that are available for you to use in the Main > Manage view.

Table 1-3 Main > Manage view commands

Commands	Explanation
FibreChannel	<p>Use this command to administer the Fibre Transport HBA cards. You can perform the following administrative functions:</p> <ul style="list-style-type: none">■ <code>Clean</code> - Clean stale SCSI information about unresponsive Fibre Channel devices from the system. See Manage > FibreChannel > Clean on page 40.■ <code>Configure</code> - Configure supported FC HBA cards. See Manage > FibreChannel > Configure on page 42.■ <code>Reset</code> - Reset Fibre Channel initiator ports on this appliance. See Manage > FibreChannel > Reset on page 46.■ <code>Scan</code> - Scan the Fibre Channel HBA initiator ports on this appliance. See Manage > FibreChannel > Scan on page 47.■ <code>Show</code> - Show the Fibre Channel cards in this appliance and configuration. See Manage > FibreChannel > Show on page 48.■ <code>Statistics</code> - Display utilization statistics for the Fibre Channel HBA initiator ports on this appliance. See Manage > FibreChannel > Statistics on page 51.

Table 1-3 Main > Manage view commands (continued)

Commands	Explanation
Libraries	<p>The <code>Libraries</code> command takes you into the NetBackup Library view. From the Libraries view you can configure and inventory robotic tape libraries in addition to the following functions:</p> <ul style="list-style-type: none"> ■ <code>Advanced > ACS</code> - Configure or edit the ACSLS network configuration entries in the <code>vm.conf</code> file. ■ <code>Configure</code> - Configure attached libraries for a media server. See Manage > Libraries > Configure on page 54. ■ <code>Deny</code> - Deny a pending tape request. See Manage > Libraries > Deny on page 55. ■ <code>Down</code> - Take drive offline. See Manage > Libraries > Down on page 56. ■ <code>Inventory</code> - Inventory libraries for volumes. See Manage > Libraries > Inventory on page 57. ■ <code>List</code> - List the attached libraries and tape drives for a media server. See Manage > Libraries > List on page 58. ■ <code>Requests</code> - List any pending tape requests. See Manage > Libraries > Requests on page 59. ■ <code>Reset</code> - Reset a drive. See Manage > Libraries > Reset on page 60. ■ <code>Resubmit</code> - Resubmit a pending tape request. See Manage > Libraries > Resubmit on page 61. ■ <code>Up</code> - Bring a drive online. See Manage > Libraries > Up on page 62.
License	<p>Use this command to enter into the License administration view, where you can add, remove, and list license keys.</p> <ul style="list-style-type: none"> ■ <code>Add</code> - Add a license key. See Manage > License > Add on page 75. ■ <code>List</code> - List the currently installed licenses. See Manage > License > List on page 76. ■ <code>ListInfo</code> - List the detailed information of the installed licenses. See Manage > License > ListInfo on page 77. ■ <code>Remove</code> - Remove a license key. See Manage > License > Remove on page 78.

Table 1-3 Main > Manage view commands (continued)

Commands	Explanation
MountPoints	<p>Use this command to</p> <ul style="list-style-type: none"> List - List existing mount points on the appliance. See Manage > MountPoints > List on page 80. Mount - Mount a remote NFS drive. See Manage > MountPoints > Mount on page 81. Unmount - Unmount a previously mounted NFS drive. See Manage > MountPoints > Unmount on page 83.
NetBackupCLI	<p>Use this command to enter into the NetBackupCLI view.</p> <ul style="list-style-type: none"> Create - Create a NetBackup user account. See Manage > NetBackupCLI > Create on page 85. Delete - Delete a NetBackup user account. See Manage > NetBackupCLI > Delete on page 87. List - View a list of NetBackup users. See Manage > NetBackupCLI > List on page 88. PasswordExpiry - Use to manage the NetBackup command-line password. See Manage > NetBackupCLI > PasswordExpiry on page 89.
OpenStorage	<ul style="list-style-type: none"> Install - Install an OpenStorage plug-in. See Manage > OpenStorage > Install on page 92. List - View list of available or installed OpenStorage plug-ins. See Manage > OpenStorage > List on page 94. Share - Share or unshare directory for uploading a plug-in See Manage > OpenStorage > Share on page 98. Uninstall - Uninstall the OpenStorage plug-in. See Manage > OpenStorage > Uninstall on page 99.

Table 1-3 Main > Manage view commands (continued)

Commands	Explanation
Software	<p>Use the <code>Software</code> to enter into the Software view. From this view you can do the following:</p> <ul style="list-style-type: none"> ■ <code>Cancel</code> - Cancel the download of a software patch. See Manage > Software > Cancel on page 101. ■ <code>Delete</code> - Delete a software update. See Manage > Software > Delete on page 102. ■ <code>Download</code> - Download a software update. See Manage > Software > Download on page 103. ■ <code>DownloadProgress</code> - View the progress of an online patch download. See Manage > Software > DownloadProgress on page 104. ■ <code>Install</code> - Install a release update. See Manage > Software > Install on page 105. ■ <code>List</code> - List the available software information. See Manage > Software > List on page 106. ■ <code>LiveUpdateClients</code> - Use LiveUpdate to update client software. See Manage > Software > LiveUpdateClients on page 108. ■ <code>Readme</code> - View the Readme to obtain the event sequence for installing a release update. See Manage > Software > Readme on page 109. ■ <code>Rollback</code> - Roll back the last installed release update. See Manage > Software > Rollback on page 111. ■ <code>Share</code> - Share or unshare a directory for uploading a software update. See Manage > Software > Share on page 113. ■ <code>UpgradeStatus</code> - View the version of your appliance. See Manage > Software > UpgradeStatus on page 114.

Table 1-3 Main > Manage view commands (*continued*)

Commands	Explanation
Storage	<p>Use this command to enter into the Storage view. From this view you can do the following:</p> <ul style="list-style-type: none">■ Add - Add new storage expansion unit. See Manage > Storage > Add on page 116.■ Create - Create a share. See Manage > Storage > Create on page 117.■ Delete - Delete a share. See Manage > Storage > Delete on page 119.■ Edit - Edit a share. See Manage > Storage > Edit on page 120.■ Monitor - Monitor storage tasks. See Manage > Storage > Monitor on page 123.■ Move - Move storage partition from one device to another. See Manage > Storage > Move on page 124.■ Remove - Remove a storage expansion unit. See Manage > Storage > Remove on page 126.■ Resize - Resize NetBackup storage partitions. See Manage > Storage > Resize on page 128.■ Scan - Refresh the storage disks and devices information. See Manage > Storage > Scan on page 130.■ Show - View NetBackup storage information. See Manage > Storage > Show on page 132.

Table 1-3 Main > Manage view commands (continued)

Commands	Explanation
Tapes	<p>Use this command to enter into the Tapes view. The Tapes view contains the following commands that enable you administer the media that is configured to your appliance:</p> <ul style="list-style-type: none"> ■ Cleaning - Designate which tape is the cleaning tape See Manage > Tapes > Cleaning on page 143. ■ Delete - Delete media from a NetBackup database See Manage > Tapes > Delete on page 144. ■ Eject - Eject media from a tape library See Manage > Tapes > Eject on page 145. ■ Freeze - Freeze media in a NetBackup database See Manage > Tapes > Freeze on page 146. ■ Inventory - Inventory all of the libraries for the volumes that have been added or removed See Manage > Tapes > Inventory on page 147. ■ List - Show a list of the available media See Manage > Tapes > List on page 148. ■ ListNetBackupMedia - Show a list of the media that NetBackup uses See Manage > Tapes > ListNetBackupMedia on page 149. ■ Suspend - Suspend media in a NetBackup database See Manage > Tapes > Suspend on page 150. ■ Unfreeze - Unfreeze the media that has been frozen in a NetBackup database See Manage > Tapes > Unfreeze on page 151. ■ Unsuspend - Unsuspend the media that has been suspended in a NetBackup database See Manage > Tapes > Unsuspend on page 152.
Certificates	<p>Use this command to enter into the Certificates view. From this view you can do the following:</p> <ul style="list-style-type: none"> ■ Generate - Use the Generate command to generate and download a certificate for a vCenter or SCVMM client. See Manage > Certificates > Generate on page 154. ■ Delete - Use the Delete command to delete an existing certificate. See Manage > Certificates > Delete on page 155.

See “About the NetBackup Appliance Shell Menu” on page 12.

About the commands under the Monitor view

From the Monitor view, you can perform the following functions:

- Monitor the appliance hardware.
- Display backup jobs and network statistics.
- Display top process information and uptime statistics for the host.
- Display current logon sessions.

The following table summarizes the commands that are available in the Monitor view.

Table 1-4 Main > Monitor view commands

Command	Explanation
Beacon	Flash lights on storage expansion unit disk drives. See Monitor > Beacon on page 157.
Hardware	Monitors various components of the appliance hardware. The 5230 appliances have additional options for the Monitor > Hardware commands.
MemoryStatus	Displays the memory usage statistics of the appliance in KB. See Monitor > MemoryStatus on page 159.
NetBackup	Displays and controls backup jobs. This command is available only for a master appliance. See Monitor > NetBackup on page 162.
NetworkStatus	Displays the network statistics for the appliance. See Monitor > NetworkStatus on page 163.
SDCS	Monitors the connection to Symantec Data Center Security (SDCS). See Monitor > SDCS on page 164.
Top	Display the top process information. See Monitor > Top on page 166.
Uptime	Display the uptime statistics for the current host. See Monitor > Uptime on page 167.
Who	Display current logon sessions on the current host. See Monitor > Who on page 168.

See “[About the NetBackup Appliance Shell Menu](#)” on page 12.

About the commands under the Network view

From the Network administration view, you can perform the following operations:

- Administer the network settings and link aggregation of the appliance.
- Set the time zone and the system time.
- Display the uptime statistics for the appliance.

The following table summarizes the commands that are available for you to use in the Network view.

Table 1-5 Main > Network view commands

Command	Explanation
Configure	Configure the IPv4 or IPv6 address of a network interface with the default gateway. See Network > Configure on page 185.
Date	Use to set or show the computer system time. See Network > Date on page 187.
DNS	Configure the DNS information. See Network > DNS on page 188.
Gateway	Add a new default gateway or delete an existing one for an interface. See Network > Gateway on page 190.
Hostname	Use this command to set or get the host name of an appliance. See Network > Hostname on page 192.
Hosts	Add or delete a host entry from the hosts' file or view the hosts configuration information. See Network > Hosts on page 193.
IPv4	Change the IPv4 address of a network interface. See Network > IPv4 on page 194.
IPv6	Change the IPv6 address of a network interface. See Network > IPv6 on page 195.

Table 1-5Main > Network view commands (continued)

Command	Explanation
LinkAggregation	<p>LinkAggregation - The LinkAggregation command provides you with the following commands options.</p> <ul style="list-style-type: none"> ■ Create - Create a bond with or without assigning an IP to it. ■ Delete - Delete a bond. ■ Disable - Disable link aggregation. ■ Enable - Enable link aggregation and select a bonding mode. ■ Show - Show the status of link aggregation. ■ Status - Check the status of the link aggregation. <p>See Network > LinkAggregation on page 196.</p>
NetStat	<p>Examine network statistical information.</p> <p>See Network > NetStat on page 200.</p>
NTPServer	<p>Use this command to manage the NTP servers. You can add, delete, and show current NTP servers.</p> <p>See Network > NTPServer on page 201.</p>
Ping	<p>An attempt to reach a host or IP address with ICMP ECHO_REQUESTs</p> <p>See Network > Ping on page 202.</p>
Security	<p>Use this command to manage IPsec policies.</p>
SetProperty	<p>Use to set the Ethernet interface property.</p> <p>See Network > SetProperty on page 203.</p>
Show	<p>You can use this command to show the network properties.</p> <p>See Network > Show on page 204.</p>
Timezone	<p>Use to set or reset the time zone.</p> <p>See Network > TimeZone on page 205.</p>
TraceRoute	<p>Displays the network packet route.</p> <p>See Network > TraceRoute on page 206.</p>
Unconfigure	<p>Removes the IP address and shuts down the interface.</p> <p>See Network > Unconfigure on page 207.</p>

Table 1-5 Main > Network view commands *(continued)*

Command	Explanation
VLAN	<p>Manages VLAN operations</p> <p>The VLAN command provides you with the following options.</p> <ul style="list-style-type: none"> ■ Delete - Deletes a VLAN interface. ■ Show - Displays properties and status of VLAN interfaces. ■ Tag - Tags a VLAN over a physical or bonded interface. <p>See Network > VLAN on page 208.</p>
WANOptimization	<p>Manages WANOptimization.</p> <p>See Network > WANOptimization on page 211.</p>

See “[About the NetBackup Appliance Shell Menu command views](#)” on page 15.

About the commands under the Reports view

From the Reports view, you can perform the following functions:

- View deduplication statistics.
- View the status of current process.

The following table summarizes the commands that are available in the Reports view.

Table 1-6 Main > Reports view commands

Command	Explanation
Deduplication	<p>Display deduplication statistics for the appliance.</p> <p>See Reports > Deduplication on page 225.</p>
Process	<p>View the status of the current processes on the appliance.</p> <p>See Reports > Process on page 226.</p>

See “[About the NetBackup Appliance Shell Menu](#)” on page 12.

About the commands under the Settings view

From the Main > Settings view you can perform the following functions:

- Enable or disable Call Home.
- Adjust deduplication parameters.

- Add, delete, hardware, and manage email accounts.
- Administer the Fibre Transport features.
- Change backup image life cycle parameters settings.
- Configure a LiveUpdate server.
- Change your user password.
- Manage user authorization and authentication.
- Administer the SNMP-related settings.
- Adjust NetBackup settings.
- Configure a media share.
- Modify sysctl parameters.
- Change the system locale.

The following table summarizes the commands that are available for you to use in the Main > Settings view.

Table 1-7 Main > Settings view commands

Command	Explanation
Alerts	<p>The <code>Alerts</code> commands let you manage your alerts for Call Home, SNMP, and error acknowledgment settings. The following commands are available under the <code>Alerts</code> submenu:</p> <ul style="list-style-type: none"> ■ <code>CallHome</code> ■ <code>Email</code> ■ <code>Hardware</code> ■ <code>SNMP</code>
Deduplication	<p>Use this command to adjust deduplication parameters.</p> <p>See Settings > Deduplication on page 228.</p>
FibreTransport	<p>Administer Fibre Transport settings. This command is available only for a master appliance.</p> <p>See Settings > FibreTransport on page 236.</p>
LifeCycle	<p>Change backup image life cycle parameters settings. This command is available only for a master appliance.</p> <p>See Settings > LifeCycle on page 240.</p>
LiveUpdateServer	<p>Configure a LiveUpdate server.</p> <p>See Settings > LiveUpdateServer on page 244.</p>

Table 1-7 Main > Settings view commands (continued)

Command	Explanation
NetBackup	<p>Use this command to do the following:</p> <ul style="list-style-type: none"> ■ Add/delete/show additional servers to the server list. ■ Tune NetBackup data buffers. ■ Show the NetBackup additional server list. <p>See Settings > NetBackup on page 245.</p>
Notifications	<p>Set and manage a text banner that appears before a user logs on to the appliance.</p> <p>See Settings > Notifications > LoginBanner on page 275.</p>
Password	<p>Use this command to change the administrator's user password on the current host.</p> <p>See Settings > Password on page 249.</p>
Security	<p>Use this command to enter into the Security view. From this view you can do the following:</p> <ul style="list-style-type: none"> ■ <i>Authentication</i> - authorize users to access the appliance by assigning them various roles (permissions). ■ <i>Authorization</i> - configure and manage user registration and authentication on the appliance. <p>See Settings > Security > Authorization on page 279.</p>
Share	<p>Use this command to configure a media share.</p> <p>See Settings > Share on page 250.</p>
Sysctl	<p>Use this command to modify your sysctl parameters.</p> <p>See Settings > Sysctl on page 251.</p>
SystemLocale	<p>Use this command to change the system locale of the NetBackup Appliance to correctly display, backup, and restore the files and the folders that are named with non-7-bit ASCII characters. For example, Chinese, Japanese, Korean, German Umlaut, or French accents.</p> <p>See Settings > SystemLocale on page 253.</p>

See “[About the NetBackup Appliance Shell Menu](#)” on page 12.

About the commands under the Support view

From the Main > Support view you can perform the following functions:

- Collects appliance logs and data for support interactions through the `DataCollect` command.
- Manage system checkpoints and IPMI operations.
- Gather disk information.
- Display NetBackup errors.
- Resets the appliance to factory default settings.
- Show the appliance logs.
- Display the messages file.
- Restart your appliance.
- Turn off your appliance.
- Share, unshare, and set the level of debug logs.
- Display debugging information from the Vxlog files.
- Restart a service on a host.
- Upload a set of log files that are based on a timed duration of four hours.
- Create and send a .tar file of the logs based on the job ID.
- Create and send a .tar file of the logs based on the time the log files were created.

The following table summarizes all of the commands that are available for you to use in the NetBackup Support view.

Table 1-8 Main > Support view commands

Command	Explanation
<code>CheckPoint</code>	Manages system checkpoints. See Support > Checkpoint on page 297.
<code>DataCollect</code>	Gathers the device logs. See Support > DataCollect on page 302.
<code>Disk</code>	Gathers and displays information about the local disk layout and usage. See Support > Disk on page 304.
<code>Errors</code>	Displays the problem entries from the previous day in the NetBackup logs. See Support > Errors on page 305.

Table 1-8 Main > Support view commands (*continued*)

Command	Explanation
FactoryReset	Resets the appliance to factory default settings. See Support > FactoryReset on page 306.
iostat	Monitors the system input and output device loading See Support > iostat on page 313.
IPMI	Manages the IPMI operations. See Support > IPMI on page 316.
KillRemoteCall	Terminates remote calls on peer compute nodes. See Support > KillRemoteCall on page 319.
Logs	From this command you can perform the following tasks: <ul style="list-style-type: none"> ■ Browse the different NetBackup appliance logs. ■ Set the level of debug logs ■ Export or remove CIFS and NFS shares for the logs. ■ Upload the NetBackup log files for your appliance to Support. The files that you send can be based on the job ID, the time that the log files were taken, or the default-based duration. ■ Display debugging information from the VXlog files. See Support > Logs on page 320.
Maintenance	Enables you to open an interactive shell menu that you can use to troubleshoot or manage underlying operating system tasks. See Support > Maintenance on page 325.
Messages	Displays the message file. See Support > Messages on page 327.
NBDNA	Create and remove network traces with the NetBackup Domain Network Analyzer (NBDNA) utility. See Support > NBDNA on page 328.
Nbperfchk	Measures the read and write speeds of a disk array. See Support > nbperfchk on page 329.
NBSU	Manage NetBackup supported data files. See Support > NBSU on page 333.

Table 1-8 Main > Support view commands (continued)

Command	Explanation
Processes	Displays the status of the current processes. See Support > Processes on page 334.
Reboot	Use this command to restart the system. See Support > Reboot on page 335.
RecoverStorage	View or purge any storage recovered during a reimage. See Support > RecoverStorage on page 336.
Service	Stops or restarts a service on an appliance Linux host. See Support > Service on page 337.
ServiceAllowed	Set specific components of a Primary or an Expansion Storage Shelf to the Service Allowed mode so that service can be performed on those units. See Support > ServiceAllowed on page 338.
Shutdown	Use this command to power the system off. See Support > Shutdown on page 344.
Storage	Use this command to perform the following tasks: <ul style="list-style-type: none"> Storage Reset - Delete the backup data and partitions from the appliance, and configure the disk status for all the disks as New Available. See Support > Storage Reset on page 345. Storage SanityCheck- Enable or disable storage sanity checks. See Support > Storage SanityCheck on page 347.
Test	Test the current status of the various appliance components. See Support > Test on page 348.

See “[About the NetBackup Appliance Shell Menu](#)” on page 12.

Main > Appliance view commands

This appendix includes the following topics:

- [Appliance > Master](#)
- [Appliance > Media](#)
- [Appliance > Remove](#)
- [Appliance > ShowDedupPassword](#)
- [Appliance > Status](#)

Appliance > Master

Appliance > Master – Configure the appliance as a NetBackup master appliance

SYNOPSIS

Master

DESCRIPTION

This command configures your appliance as a NetBackup master appliance. You can also configure your appliance as a master appliance during the initial configuration of the appliance from the NetBackup Appliance Web Console.

Note: This command is available only when the appliance is in a factory-install mode. The command is not available after the appliance is configured.

OPTIONS

Master

Use this command to configure your appliance as a NetBackup master appliance.

See [Appliance > Media](#) on page 34.

See “[About the commands under the Appliance view](#) ” on page 15.

See “[About NetBackup appliance commands](#)” on page 10.

Appliance > Media

Appliance > Media – Configure an appliance as a media server.

SYNOPSIS

Media *MasterServer*

DESCRIPTION

This command is used to configure the appliance as a media server to an existing NetBackup master server. If the master server is in a clustered environment, Veritas recommends that you enter the cluster name first, followed by the names of the nodes within the master server cluster. You should use the comma character as a delimiter between the node names.

Note: This command is available only during the initial configuration of the appliance. After the appliance is configured, the `Appliance > Media` command is not available.

OPTIONS

Media *MasterServer*

Use to configure the appliance as a media server to an existing NetBackup master server.

MasterServer is the master server host name. You can provide the following information in this field:

- If the master server is a multi-homed server, make sure that the appliance and the host name are on the same network.
- If the master server is a clustered environment, enter the cluster name first followed by the names of the nodes within the master server cluster. You should use the comma character as a delimiter between the node names.

See [“About the commands under the Appliance view ”](#) on page 15.

See [“About NetBackup appliance commands”](#) on page 10.

See [“Logging into the NetBackup Appliance Shell Menu ”](#) on page 11.

See [“About NetBackup Appliance Shell Menu usage”](#) on page 11.

Appliance > Remove

Appliance > Remove – Decommission an existing media server.

SYNOPSIS

```
Remove MediaServer TargetMediaServer
```

DESCRIPTION

You can use the `Remove` command to decommission a media appliance from your configuration. When you go through the process of decommissioning an appliance you can move your tape media to another appliance. This appliance is your *target appliance*. The other appliance that you must name is the appliance that you want to decommission.

OPTIONS

```
Remove MediaServer TargetMediaServer [Force]
```

Use to decommission a media appliance. The *MediaServer* variable is the name of the appliance that you want to decommission. The *TargetMediaServer* variable is the name of the new appliance where the tapes are moved during the decommissioning of the original media server. If you do not want to move tape media, then specify **NONE** for this variable.

See [“About the NetBackup Appliance Shell Menu”](#) on page 12.

Appliance > ShowDedupPassword

Appliance > ShowDedupPassword – Display the NetBackup deduplication password of the domain.

SYNOPSIS

ShowDedupPassword

DESCRIPTION

You can use this command to display the NetBackup deduplication password of the domain. Simply type `ShowDedupPassword` at the command prompt to see the password.

Note: If you change the password for MSDP, the NetBackup Appliance Shell Menu does not display the new password. The `ShowDedupPassword` option displays the original password that was created during the installation process.

OPTIONS

ShowDedupPassword

Use to display the NetBackup deduplication password of the domain.

See [“About the NetBackup Appliance Shell Menu”](#) on page 12.

Appliance > Status

Appliance > Status – Use to show status information about the appliance.

SYNOPSIS

Status

DESCRIPTION

Use this command to show status information about the appliance, such as the appliance role and master server information.

OPTIONS

Status

Use to show the status information about the appliance.

EXAMPLES

The following is an example of information that is displayed when you run the `Main > Appliance > Status` command

```
abc123.Appliance> Status
```

```
Wed Jul 10 04:43:00 UTC 2013
```

```
=====
```

```
Appliance Model is NetBackup Appliance 5230.
```

```
Appliance Version is 2.6.
```

```
Appliance is configured as master appliance.
```

```
All storage partitions are below watermark.
```

```
-----
```

```
Network Settings
```

```
-----
```

```
BONDING [Disabled]
```

```
-----
```

```
PHYSICAL DEVICE STATUS
```

```
-----  
eth0   : 1Gb/s    TP  UNPLUGGED|UP      192.168.229.233  -- None --  
eth1   : 1Gb/s    TP  UNPLUGGED|UP      -- None --      -- None --  
eth2   : 1Gb/s    TP   PLUGGED|UP      10.182.20.242   -- None --  
eth3   : 1Gb/s    TP  UNPLUGGED|UP      -- None --      -- None --  
eth4   : 10Gb/s   FC  UNPLUGGED|UP      -- None --      -- None --  
eth5   : 10Gb/s   FC  UNPLUGGED|UP      -- None --      -- None --  
eth6   : 10Gb/s   FC  UNPLUGGED|UP      -- None --      -- None --  
eth7   : 10Gb/s   FC  UNPLUGGED|UP      -- None --      -- None --
```

ROUTING STATUS

```
-----  
default      10.182.1.1      eth2
```

**VNIC=Virtual Interface TP=Twisted Pair FC=Fibre channel 1G/10G=1/10 Gigabit Ethernet
INFO:Only a single cabled network card detected. Cabling other ports is recommended to
make use of Link aggregation.

```
-----
```

Main > Manage > FibreChannel view commands

This appendix includes the following topics:

- [Manage > FibreChannel > Clean](#)
- [Manage > FibreChannel > Configure](#)
- [Manage > FibreChannel > Reset](#)
- [Manage > FibreChannel > Scan](#)
- [Manage > FibreChannel > Show](#)
- [Manage > FibreChannel > Statistics](#)

Manage > FibreChannel > Clean

Manage > FibreChannel > Clean – Use this command to clean stale SCSI information about unresponsive Fibre Channel devices from the system.

SYNOPSIS

Clean

DESCRIPTION

SCSI devices may become unresponsive because these devices might have been removed from the system. However, the operating system keeps a stale reference to these SCSI devices. This command is used to remove the operating system references to these devices that are not relevant anymore.

Note: The `Clean` operation may fail the currently running duplication jobs over FC. The duplication jobs failover to other FT paths if they exist. If no other FT paths are available, they failover to the Ethernet network. If no FT connection or IP connection exists, the jobs fail.

OPTIONS

Clean

Use to remove stale SCSI information.

EXAMPLES

The following is an example of information when you run the `Main > Manage> FibreChannel > Clean` command.

```
nbu-appliance.FC> Clean
- [Info] FTMS mode: Fibre Transport server installed and running.
- [Info] Fibre Transport Deduplication state: enabled
**** FC HBA Cards ****
07:00.0 Fibre Channel: QLogic Corp. ISP2532-based 8Gb Fibre Channel to PCI Express HBA (rev 02)
07:00.1 Fibre Channel: QLogic Corp. ISP2532-based 8Gb Fibre Channel to PCI Express HBA (rev 02)
08:00.0 Fibre Channel: QLogic Corp. ISP2532-based 8Gb Fibre Channel to PCI Express HBA (rev 02)
08:00.1 Fibre Channel: QLogic Corp. ISP2532-based 8Gb Fibre Channel to PCI Express HBA (rev 02)
81:00.0 Fibre Channel: QLogic Corp. ISP2532-based 8Gb Fibre Channel to PCI Express HBA (rev 02)
81:00.1 Fibre Channel: QLogic Corp. ISP2532-based 8Gb Fibre Channel to PCI Express HBA (rev 02)
82:00.0 Fibre Channel: QLogic Corp. ISP2532-based 8Gb Fibre Channel to PCI Express HBA (rev 02)
```


82:00.1 Fibre Channel: QLogic Corp. ISP2532-based 8Gb Fibre Channel to PCI Express HBA (rev 02)

**** Drivers ****

qla2xxx is loaded
windrvr6 is loaded
qla2x00tgt is loaded
scst is loaded
scst_user is loaded

**** Ports ****

Bus ID	Slot	Port	PortWWN	Status	PhysicalState	ConfigurationType	Speed	RemotePort
07:00.0	Slot5 1	21:00:00:24:FF:46:8A:12	Disconnected	Target	Target (FTMS)	0 gbit/s	-----	
07:00.1	Slot5 2	21:00:00:24:FF:46:8A:13	Fabric	Target	Target (FTMS)	8 gbit/s	-----	
08:00.0	Slot6 1	21:00:00:24:FF:8E:E4:0F	Disconnected	Target	Target (FTMS)	0 gbit/s	-----	
08:00.1	Slot6 2	21:00:00:24:FF:8E:E4:0E	Disconnected	Target	Target (FTMS)	0 gbit/s	-----	
81:00.0	Slot4 1	21:00:00:24:FF:8E:E4:14	Online	Initiator	Initiator	8 gbit/s		
81:00.1	Slot4 2	21:00:00:24:FF:8E:E4:15	Online	Target	Target (MSDP)	8 gbit/s		
82:00.0	Slot2 1	21:00:00:24:FF:8E:E5:B2	Linkdown	Initiator	Initiator	8 gbit/s		
82:00.1	Slot2 2	21:00:00:24:FF:8E:E5:B3	Online	Target	Target (MSDP)	8 gbit/s		

**** Devices ****

Device	Vendor	ID	Type	Remote Port
--------	--------	----	------	-------------

**** Remote Appliances over FC ****

Please scan for remote appliances over FC first

Manage > FibreChannel > Configure

Manage > FibreChannel > Configure – Use this command to configure the QLogic Fibre Channel HBA ports.

SYNOPSIS

Configure *NumberPorts*

Configure Deduplication Initiator *HBAportid*

Configure Deduplication Target *HBAportid*

DESCRIPTION

You can use the `configure` command to do the following:

- Configure the appliance to use 2 or 4 target port configuration for use by SAN Client Fibre Transport.
- Configure the FC HBA ports on this appliance as target ports for Fibre Transport Deduplication. Fibre Transport Deduplication is a feature that enables you to use an appliance as a target host for Optimized Duplication and Auto Image Replication.

Note: You must restart the appliances in the FC zone where a port mode change has occurred. A port mode change occurs when you change and save the port mode configuration, or enable/disable the feature. We recommend that you reboot after you finish all the port mode changes.

OPTIONS

Configure *NumberPorts*

Configure the number of FC HBA target ports for use with the SAN Client feature. The available *NumberPorts* is 2 and 4.

For new appliances or for appliances that have been factory reset, the configuration default is 2.

The available options are as follows:

- `Configure 2`
Sets Port 1 to the target mode on the following FC HBA cards:
 - NetBackup 5220 - cards in slots 2 and 4

- NetBackup 5230 and 5330 - cards in slots 5 and 6
- NetBackup 5240 - cards in slots 5 and 6
- `Configure 4`
Sets Ports 1 and 2 to the target mode on the following FC HBA cards:
 - NetBackup 5220 - cards in slots 2 and 4
 - NetBackup 5230 and 5330 - cards in slots 5 and 6
 - NetBackup 5240 - cards in slots 5 and 6

Changing this option restarts the appliance, but it does not change the state of the SAN Client feature.

By default, the SAN Client feature is disabled on new appliances or on appliances that have been factory reset. If the SAN Client feature is disabled, changes to this setting only mark the ports as ready for target mode use. To enable the SAN Client feature, go to the `Settings` view and run the `FibreTransport SANClient Enable` command.

`Configure Deduplication Initiator HBAportid`

Configure a port as an FC initiator port.

The *HBAportid* is the slot number(1-6) and port number(1-2) of the HBA port. The format is *Slot:Port*.

Note: You can check the current state of the available ports by using the `Main> Manage> FibreChannel> Show Ports` command before you configure a port.

The following HBA ports may be available:

- NetBackup 5220 - ports in slot 3
- NetBackup 5230 - ports in slot 2, 3, 4
- NetBackup 5330 - ports in slot 2, 3, 6
- NetBackup 5240 - ports in slot 2, 4, 6

FC feature support depends on the particular HBA card configuration of each appliance. For complete information about available ports on your HBA configuration, see the *NetBackup Appliance Fibre Channel Guide*.

Note: This command restarts the Deduplication service if the port mode is changed. The service restart causes the ongoing jobs fail, and then failover to LAN. It is recommended that you cancel or suspend all jobs before you change the port mode.

Configure Deduplication Target *HBAportid*

Configures a port as an FC target port for Optimized Duplication and Auto Image Replication(AIR).

The *HBAportid* is the slot number(1-6) and port number(1-2) of the HBA port. The format is *Slot:Port*.

Note: You can check the current state of the available ports by using the `Main> Manage> FibreChannel> Show Ports` command before you configure a port.

The following HBA ports may be available:

- NetBackup 5220 - ports in slot 3
- NetBackup 5230 - ports in slot 2, 3, 4
- NetBackup 5330 - ports in slot 2, 3, 6
- NetBackup 5240 - ports in slot 2, 4, 6

FC feature support depends on the particular HBA card configuration of each appliance. For complete information about available ports on your HBA configuration, see the *NetBackup Appliance Fibre Channel Guide*.

Note: This command restarts the Deduplication service if the port mode is changed. The service restart causes the ongoing jobs fail, and then failover to LAN. It is recommended that you cancel or suspend all jobs before you change the port mode.

EXAMPLES

The following is an example of information when you run the `Configure Deduplication Initiator` command.

```
appliance.FC> Configure Deduplication Initiator 2:2
[Info] Checking the port state...
[Info] This port is currently configured as an FC target port for optimized duplication
and replication.
Are you sure that you want to change it to an FC initiator port? [yes, no](no) yes
[Info] Configuring the port state...
[Info] Restarting the optimized duplication service to complete the change. This may take
1 - 2 minutes...
[Info] Port configured successfully as an FC initiator port for optimized duplication.
```

The following is an example of information when you run the `Configure Deduplication Target` command.

```
appliance.FC> Configure Deduplication Target 2:2
[Info] Checking the port state...
[Info] This port is currently configured as an FC initiator port.
      Are you sure that you want to change it to an FC Target port for optimized duplication
      and replication? [yes, no] (no) yes
[Info] Configuring the port state...
[Info] Restarting the optimized duplication service to complete the change. This may take
      1 - 2 minutes...
[Info] Port configured successfully as an FC Target port for optimized duplication
      and replication.
```

See [“About the NetBackup Appliance Shell Menu”](#) on page 12.

Manage > FibreChannel > Reset

Manage > FibreChannel > Reset – Use to reset the links between the appliance FC HBA ports that are in initiator mode and any ports connected to its initiator mode ports.

SYNOPSIS

Reset

DESCRIPTION

Use this command to reset the links between the appliance FC HBA ports that are in initiator mode and any ports that are connected to its initiator mode ports.

This command is most useful when the FC links are not up as expected. Link status can change because of SAN zoning changes. If a reset does not reset the links, use the `Main> Support> Reboot` command to restart the appliance.

OPTIONS

Reset

Reset the Fibre Channel card ports that are in the initiator mode. This option re-initializes the ports by issuing a Link Initialization Protocol reset.

EXAMPLES

The following is an example of information when you run the `Main > Manage> FibreChannel > Reset` command.

```
nbu-appliance.FC> reset
- [Info] Resetting HBA ports involves restarting the Deduplication service. It is recommended
that you cancel all running jobs before the reset. It may take 2-3 minutes before the ports are
available again.
Do you want to proceed? [yes, no] (no) yes
- [Info] FTMS mode: Fibre Transport server installed and running.
- [Info] Fibre Transport Deduplication state: enabled
- [Info] Initiating reset of port at 81:00.0
- [Info] Initiating reset of port at 81:00.1
- [Info] Initiating reset of port at 82:00.0
- [Info] Initiating reset of port at 82:00.1
```

See [Settings > FibreTransport](#) on page 236.

Manage > FibreChannel > Scan

Manage > FibreChannel > Scan – Use to scan the devices that are visible from the FC card initiator ports on the appliance.

SYNOPSIS

Scan

DESCRIPTION

Use this command to scan the devices that are visible from the FC card initiator ports on the appliance.

By default, the operating system should detect the devices that are connected to the appliance HBA initiator mode ports automatically. If the OS does not detect devices, use this command to try to detect them. If that fails, test the FC links by using the `Reset` command.

This command is most useful during zoning changes.

OPTIONS

Scan

Scan for target mode drivers that are visible from the FC card initiator ports on the appliance.

EXAMPLES

```
nbu-appliance.FC> SCAN
- [Info] FTMS mode: Fibre Transport server installed and running.
- [Info] Fibre Transport Deduplication state: enabled
- [Info] Initiating scan of port at 81:00.0
- [Info] Initiating scan of port at 82:00.0
- [Info] Scanning for remote appliances over FC
```

See [Settings > FibreTransport](#) on page 236.

Manage > FibreChannel > Show

`Manage > FibreChannel > Show` – Use to view the FC HBA card port and device configuration.

SYNOPSIS

`Show [Ports]`

DESCRIPTION

Use this command to view the FC HBA card port and device configuration for this appliance.

OPTIONS

`Show Ports`

Use this command to view only the port information of the FC HBA cards for this appliance.

Port Information includes the following:

- Bus ID
- Slot location (1-6)
- Port location (1-2)
- Port World Wide Name (WWN)
- Status
 - Online
 - Offline
 - Fabric
 - Disconnected
 - Linkdown
 - Loop
 - Ptp
- Physical State (Initiator or Target)
- Configuration Type
 - Initiator - marked as a standard initiator port.

- Target (FTMS) - marked as a target port for SAN Client FTMS.
- Target (MSDP) - marked as a target port for duplicating data from another NetBackup 52xx or 5330 appliance.
- Speed
- Remote Ports

The `Physical State` column shows the actual state of the HBA ports.

The `Configuration Type` column shows the port mode that a user has specified. The default port type configuration is shown if the user has not changed it.

When you enable an FC feature, the port(s) that has been marked as a target port(s) for that feature then enters the target mode. That is to say, before the enabling operation, the port stays in the standard initiator mode, and it shows a actual physical state of `Initiator`.

By comparing the `Configuration Type` and `Physical State` columns, a user can know if a related FC feature is enabled.

Show

Use this command to view the following FC HBA card port and device configuration for this appliance:

- Configuration state of the Fibre Transport media server (FTMS)
- Configuration state of the HBA cards and the card names
- Whether the drivers are loaded
- Port information
- Device information
- Remote appliances over FC

Note: If you cannot see any target appliance that you have configured for this appliance, scan for remote appliances over FC by using the `Main> Manage> FibreChannel> Scan` and then run the `Show` command again.

EXAMPLES

The following is an example of information when you run the `Main > Manage> FibreChannel > Show` command.

```
appliance.FC> Show
- [Info] FTMS mode: none
```

```
- [Info] Fibre Transport Deduplication state: disabled
**** FC HBA Cards ****
08:00.0 Fibre Channel: QLogic Corp. ISP2532-based 8Gb Fibre Channel to PCI Express HBA (rev 02)
08:00.1 Fibre Channel: QLogic Corp. ISP2532-based 8Gb Fibre Channel to PCI Express HBA (rev 02)

**** Drivers ****
qla2xxx      is loaded
windrvr6     is not loaded
qla2x00tgt   is loaded
scst         is loaded
scst_user    is loaded

**** Ports ****
BusID Slot Port Port WWN          Status PhysicalState ConfigurationType Speed Remote Ports
08:00.0 Slot6 1 21:00:00:24:FF:88:1E:52 Online Initiator Initiator      8 gbit/s 0x21000024ff8cd275
                                           0x21000024ff8cd275
08:00.1 Slot6 2 21:00:00:24:FF:88:1E:53 Online Initiator Target(MSDP) 8 gbit/s 0x21000024ff8cd275
                                           0x21000024ff8cd275

**** Devices ****
Device Vendor ID Type Remote Port
/dev/sg11 SYMANTEC TEST-NET-2 FCPIPE (Dedup Target) 0x21000024ff8cd265
/dev/sg12 SYMANTEC TEST-NET-2 FCPIPE (Dedup Target) 0x21000024ff8cd275

**** Remote Appliances over FC ****
The result is based on the scan at December 28 2015 Monday 06:01:35 PST
/dev/sg11 203.0.113.0
          98.51.100.0 (TEST-NET-2.veritas.com)
/dev/sg12 203.0.113.0
          98.51.100.0 (TEST-NET-2.veritas.com)
```

See [“About the NetBackup Appliance Shell Menu”](#) on page 12.

See [Settings > FibreTransport](#) on page 236.

Manage > FibreChannel > Statistics

Manage > FibreChannel > Statistics – Use to display usage statistics for the FC card ports that are in the standard initiator mode.

SYNOPSIS

Statistics [Interval] [Count]

DESCRIPTION

Use this command to display usage statistics for the FC card ports that are in the standard initiator mode.

OPTIONS

Statistics [Interval] [Count]

Display usage statistics for the FC card ports that are in the standard initiator mode. The [Interval] and [Count] parameters are optional. The [Interval] parameter can be used to specify the time interval in seconds between updates. The default value of this parameter is one second. The [Count] parameter can be used to specify the number of times to display statistics. The default value of this parameter is 3.

EXAMPLES

The following is an example of information when you run the Main > Manage> FibreChannel > Statistics command.

```
nbu-appliance.FC> Statistics
```

Slot	Port	I/O R	I/O W	I/O R(KB	I/O W(KB	Target I/O R	Target I/O W
		(count/s)	(count/s)	/s)	/s)	(KB/s)	(KB/s)
2	1	0	0	0	0	-	-
2	2	0	0	0	0	0	0
4	1	0	0	0	0	-	-
4	2	0	0	0	0	0	0

Slot	Port	I/O R (count/s)	I/O W (count/s)	I/O R(KB /s)	I/O W(KB /s)	Target I/O R (KB/s)	Target I/O W (KB/s)
2	1	0	0	0	0	-	-
2	2	0	0	0	0	0	0
4	1	0	0	0	0	-	-
4	2	0	0	0	0	0	0

Slot	Port	I/O R (count/s)	I/O W (count/s)	I/O R(KB /s)	I/O W(KB /s)	Target I/O R (KB/s)	Target I/O W (KB/s)
2	1	0	0	0	0	-	-
2	2	0	0	0	0	0	0
4	1	0	0	0	0	-	-
4	2	0	0	0	0	0	0

See [“About the NetBackup Appliance Shell Menu”](#) on page 12.

See [Settings > FibreTransport](#) on page 236.

Main > Manage > Libraries view commands

This appendix includes the following topics:

- [Manage > Libraries > Configure](#)
- [Manage > Libraries > Deny](#)
- [Manage > Libraries > Down](#)
- [Manage > Libraries > Inventory](#)
- [Manage > Libraries > List](#)
- [Manage > Libraries > Requests](#)
- [Manage > Libraries > Reset](#)
- [Manage > Libraries > Resubmit](#)
- [Manage > Libraries > Up](#)

Manage > Libraries > Configure

Manage > Libraries > Configure – Use to configure attached robotic tape libraries for a media server.

SYNOPSIS

`Configure MediaServer`

DESCRIPTION

This command enables you to configure the attached libraries for a media server.

OPTIONS

`Configure MediaServer`

Use this command to configure the attached libraries for a media server.

MediaServer is the name of the media server.

Manage > Libraries > Deny

Manage > Libraries > Deny – Deny a pending tape request.

SYNOPSIS

Deny *RequestID*

DESCRIPTION

Use this command to deny a pending tape request.

OPTIONS

Deny *RequestID*

Use this command to deny a pending tape request.

RequestID is the ID for the pending tape request. You must run the `Libraries > Requests` command to retrieve the request ID.

See [“About NetBackup Appliance Shell Menu usage”](#) on page 11.

Manage > Libraries > Down

Manage > Libraries > Down – Use to stop a drive.

SYNOPSIS

Down *DriveName*

DESCRIPTION

Use this command to stop a drive that you identify by a drive name.

OPTIONS

Down *DriveName*

Use this command to stop a drive.

DriveName defines the name of the drive that you want to stop.

Manage > Libraries > Inventory

Manage > Libraries > Inventory – Inventory libraries for volumes.

SYNOPSIS

```
Inventory MediaServer
```

DESCRIPTION

This command enables you to inventory libraries for volumes for a designated media server.

OPTIONS

```
Inventory MediaServer
```

Use this command to inventory libraries for volumes for a media server.

MediaServer is the name of the media server.

Manage > Libraries > List

Manage > Libraries > List – List attached libraries and tape drives for the media server.

SYNOPSIS

List

DESCRIPTION

This command enables you to list the attached libraries and the tape drives for the media server in the form of a Drive Status output. This output provides pertinent information such as the drive name, label, drive type, the host, drive path, and the current status.

OPTIONS

List

Configure the attached libraries for the media server.

EXAMPLES

The following drive status and robots information is produced when you run the List command.

DRIVE STATUS

```
Drive Name Label Ready RecMID ExtMID Wr.Enbl. Type Host DrivePath Status
=====
```

```
Libraries> List
```

ROBOTS

```
Robot:          ROBOT0
Robot Type:     TLD(8)
Media Server:   ascm2
Serial Number:  RBD31A0008
Inquiry:        ATL      M2500          3.07
```

Manage > Libraries > Requests

`Manage > Libraries > Requests` – List the pending tape requests.

SYNOPSIS

`Requests`

DESCRIPTION

This command enables you to list all pending tape requests.

OPTIONS

`Request`

Lists the pending tape requests.

EXAMPLES

To view the pending tape requests, type the following in the NetBackup Libraries view:

`Requests`

The result shows the pending requests. If there are no pending requests, the following appears.

PENDING REQUESTS

<NONE>

Manage > Libraries > Reset

`Manage > Libraries > Reset` – Use to reset a drive.

SYNOPSIS

`Reset DriveName`

DESCRIPTION

This command enables you to reset a specific drive.

OPTIONS

`Reset DriveName`

Use this command to reset a drive.

DriveName is the name of the drive. Run the `Manage > Libraries > List` to retrieve the *DriveName*.

Manage > Libraries > Resubmit

Manage > Libraries > Resubmit – Use to resubmit a pending tape request.

SYNOPSIS

`Resubmit RequestID`

DESCRIPTION

This command enables you to resubmit a pending tape request.

OPTIONS

`Resubmit RequestID`

Use to resubmit a pending tape request.

RequestID contains the RequestID for the pending request.

See [“Logging into the NetBackup Appliance Shell Menu ”](#) on page 11.

Manage > Libraries > Up

Manage > Libraries > Up – Use to start a drive.

SYNOPSIS

Up *DriveName*

DESCRIPTION

This command enables you to start a drive and to bring it back online for use.

OPTIONS

Up *DriveName*

Use this command to start a drive.

DriveName contains the name of the drive.

Main > Manage > Libraries > Advanced > ACS view commands

This appendix includes the following topics:

- [Manage > Libraries > Advanced > ACS > ACS_CSI_HOSTPORT](#)
- [Manage > Libraries > Advanced > ACS > ACS_SEL_SOCKET](#)
- [Manage > Libraries > Advanced > ACS > ACS_SSI_HOSTNAME](#)
- [Manage > Libraries > Advanced > ACS > ACS_SSI_INET_PORT](#)
- [Manage > Libraries > Advanced > ACS > ACS_SSI_SOCKET](#)
- [Manage > Libraries > Advanced > ACS > ACS_TCP_RPCSERVICE](#)
- [Manage > Libraries > Advanced > ACS > ACS_UDP_RPCSERVICE](#)
- [Manage > Libraries > Advanced > ACS > API_BARCODE_RULES](#)
- [Manage > Libraries > Advanced > ACS > TestACS](#)
- [Manage > Libraries > Advanced > ACS > ViewVMconf](#)

Manage > Libraries > Advanced > ACS > ACS_CSI_HOSTPORT

Manage > Libraries > Advanced > ACS > ACS_CSI_HOSTPORT – Use to add or remove the ACS CSI host name and the socket name in the `vm.conf` file.

SYNOPSIS

`ACS_CSI_HOSTPORT Operation SSIHOSTNAME PORTNAME`

DESCRIPTION

Use this command to add or remove the ACS library software host name and the socket name in the `vm.conf` file.

OPTIONS

`ACS_CSI_HOSTPORT Operation SSIHOSTNAME PORTNAME`

Use this command to add or remove the ACS CSI host name and socket name in the `vm.conf` file. The `vm.conf` entry specifies the port where the `acsssi` process sends its ACSLS requests on the ACSLS server. The ACSLS CSI must use this port to accept inbound ACSLS requests from `acsssi` processes.

Operation is Add or Remove.

SSIHOSTNAME contains the name of the SSI host name of the ACS library host. Do not use the IP address of the ACS library host for this parameter.

PORTNAME contains a value of 1024 - 65535, or 0. The value must match the one on the ACSLS server for the port that the CSI uses for inbound packets. If 0 (zero), NetBackup uses the previous behavior of CSI and `acsssi` (no specific ports).

Manage > Libraries > Advanced > ACS > ACS_SEL_SOCKET

Manage > Libraries > Advanced > ACS > ACS_SEL_SOCKET – Use to add or remove the ACS SEL socket name in the `vm.conf` file on the specified host.

SYNOPSIS

`ACS_SEL_SOCKET Operation SOCKETNAME`

DESCRIPTION

Use this command to add or remove the ACS SEL socket name in the `vm.conf` file on the specified host.

OPTIONS

`ACS_SEL_SOCKET Operation SOCKETNAME,`

Use this command to add or remove the ACS SEL socket name in the `vm.conf` file on the specified host.

Operation is Add or Remove.

SOCKETNAME defaults to 13740. If the `ACS_SEL_SOCKET` entry is specified in the `vm.conf` file, the default can be changed.

Manage > Libraries > Advanced > ACS > ACS_SSI_HOSTNAME

Manage > Libraries > Advanced > ACS > ACS_SSI_HOSTNAME – Use to add or remove the ACS SSI host name in the `vm.conf` file on the local host.

SYNOPSIS

`ACS_SSI_HOSTNAME Operation SSIHOSTNAME`

DESCRIPTION

Use this command to add or remove the ACS SSI host name in the `vm.conf` file on the local host.

OPTIONS

`ACS_SSI_HOSTNAME SSIHOSTNAME`

Use this command to add or remove the ACS SSI host name in the `vm.conf` file on the local host.

Operation is Add or Remove.

SSIHOSTNAME contains the host name to which RPC return packets from ACS library software are routed for ACS network communications. By default, the local host name is used. Do not use the IP address of the host for this parameter.

Manage > Libraries > Advanced > ACS > ACS_SSI_INET_PORT

Manage > Libraries > Advanced > ACS > ACS_SSI_INET_PORT – Use to add or remove the ACS SSI INET PORT host name and the socket name in the `vm.conf` file.

SYNOPSIS

```
ACS_SSI_INET_PORT Operation SSIHOSTNAME PORTNAME
```

DESCRIPTION

Use this command to add or remove the host name of the ACS library host in the `vm.conf` file.

OPTIONS

```
ACS_SSI_INET_PORT Operation SSIHOSTNAME PORTNAME
```

Use this command to add or remove the host name of the ACS library host in the `vm.conf` file.

Operation is Add or Remove.

SSIHOSTNAME contains the host name of the ACS library host. Do not use the IP address of the ACS library host for this parameter.

PORTNAME contains the port that `acsssi` uses for incoming ACSLS responses. Valid values are 1024 - 65535 and 0. This value must be unique for each `acsssi` process. A value from 1024 - 65535 indicates the number to be used as the TCP port on which `acsssi` accepts ACSLS responses.

Manage > Libraries > Advanced > ACS > ACS_SSI_SOCKET

Manage > Libraries > Advanced > ACS > ACS_SSI_SOCKET – Use to add or remove the host name of the ACS library host in the `vm.conf` file.

SYNOPSIS

`ACS_SSI_SOCKET Operation SSIHOSTNAME SOCKETNAME`

DESCRIPTION

Use this command to add or remove the host name of the ACS library host in the `vm.conf` file.

OPTIONS

`ACS_SSI_SOCKET Operation SSIHOSTNAME SOCKETNAME`

Use this command to add or remove the host name of the ACS library host in the `vm.conf` file.

Operation is Add or Remove.

SSIHOSTNAME contains the host name of the ACS library host. Do not use the IP address of the ACS library host for this parameter.

SOCKETNAME defaults to 13741. If the `ACS_SSI_SOCKET` entry is specified in the `vm.conf` file, specify socket names on an ACS library software host basis.

See [“About the commands under the Manage view”](#) on page 16.

Manage > Libraries > Advanced > ACS > ACS_TCP_RPCSERVICE

Manage > Libraries > Advanced > ACS > ACS_TCP_RPCSERVICE – Use to add or remove the ACS_TCP_RPCSERVICE entry in the `vm.conf` file on the specified host.

SYNOPSIS

`ACS_TCP_RPCSERVICE Operation`

DESCRIPTION

Use this command to add or remove the `ACS_TCP_RPCSERVICE` entry in the `vm.conf` file.

OPTIONS

`ACS_TCP_RPCSERVICE Operation`

Use this command to specify the method over which `acsssi` communicates with ACSLS servers: TCP or UDP.

Operation is Add or Remove.

Only one entry should be entered into the `vm.conf` file. NetBackup uses UDP if both entries are found or if neither entry is found. For `acsssi` firewall support, `ACS_TCP_RPCSERVICE` must be entered in the `vm.conf` file.

Manage > Libraries > Advanced > ACS > ACS_UDP_RPCSERVICE

Manage > Libraries > Advanced > ACS > ACS_UDP_RPCSERVICE – Use to add or remove the ACS_UDP_RPCSERVICE entry in the `vm.conf` file on the specified host.

SYNOPSIS

`ACS_UDP_RPCSERVICE Operation`

DESCRIPTION

Use this command to add or remove the `ACS_UDP_RPCSERVICE` entry in the `vm.conf` file.

OPTIONS

`ACS_UDP_RPCSERVICE Operation`

Use this command to specify the method over which `acsssi` communicates with ACSLS servers: TCP or UDP.

Operation is Add or Remove.

Only one entry should be entered into the `vm.conf` file. NetBackup uses UDP if both entries are found or if neither entry is found. For `acsssi` firewall support, `ACS_TCP_RPCSERVICE` must be entered in the `vm.conf` file.

See [“About the NetBackup Appliance Shell Menu”](#) on page 12.

Manage > Libraries > Advanced > ACS > API_BARCODE_RULES

Manage > Libraries > Advanced > ACS > API_BARCODE_RULES – Use to enable or disable NetBackup barcode rule support for API robots.

SYNOPSIS

API_BARCODE_RULES *Operation*

DESCRIPTION

Use this command to enable or disable NetBackup barcode rule support for API robots.

NetBackup barcode rules allow default media mappings to be overridden. Barcode rules are especially useful when multiple generations of the same tape drive use the same type of media.

OPTIONS

API_BARCODE_RULES *Operation*

Use this command to enable or disable NetBackup barcode rule support for API robots.

Operation is Add or Remove.

Use Add to enable NetBackup barcode rule support for API robots. Use Remove to disable NetBackup barcode rule support for API robots.

Manage > Libraries > Advanced > ACS > TestACS

Manage > Libraries > Advanced > ACS > TestACS – Use to test ACSLS communications.

SYNOPSIS

```
TestACS ACSLSHOSTNAME
```

DESCRIPTION

Use this command to test the ACSLS communications based on the ACS settings in the `vm.conf` file.

OPTIONS

```
TestACS ACSLSHOSTNAME
```

Tests the ACSLS communications.

ACSLSHOSTNAME is the ACSLS host name.

Manage > Libraries > Advanced > ACS > ViewVMconf

Manage > Libraries > Advanced > ACS > ViewVMconf – Use to view the `vm.conf` file entries.

SYNOPSIS

ViewVMconf

DESCRIPTION

Use this command to view the entries in the `vm.conf` file.

OPTIONS

ViewVMconf

Use to view the `vm.conf` file entries.

Main > Manage > License view commands

This appendix includes the following topics:

- [Manage > License > Add](#)
- [Manage > License > List](#)
- [Manage > License > ListInfo](#)
- [Manage > License > Remove](#)

Manage > License > Add

Manage > License > Add — Use to add a license key.

SYNOPSIS

Add

DESCRIPTION

You can use this command to add a license key.

OPTIONS

Add

Use to add a license key.

See [“About NetBackup Appliance Shell Menu usage”](#) on page 11.

Manage > License > List

`Manage > License > List` – Use to list the installed licenses.

SYNOPSIS

`List`

DESCRIPTION

You use this command to list the installed licenses.

OPTIONS

`List`

Use to list the installed licenses.

Manage > License > ListInfo

`Manage > License > ListInfo` – Use to list detailed information about the installed licenses.

SYNOPSIS

`ListInfo`

DESCRIPTION

Use this command to list detailed information about the installed licenses.

OPTIONS

`ListInfo`

Use to list detailed information about the installed licenses.

Manage > License > Remove

Manage > License > Remove – Use to remove a license key.

SYNOPSIS

Remove

DESCRIPTION

You use this command to remove a license key.

OPTIONS

Remove

Use to remove a license key.

Main > Manage > MountPoints view commands

This appendix includes the following topics:

- [Manage > MountPoints > List](#)
- [Manage > MountPoints > Mount](#)
- [Manage > MountPoints > Unmount](#)

Manage > MountPoints > List

`Manage > MountPoints > List` – Use to list all the existing mount points on the current appliance.

SYNOPSIS

```
List [Type]
```

DESCRIPTION

You can use the `List` command to list all the existing mount points on your appliance.

OPTIONS

```
List [Type]
```

The `List` command does not require an option. Here `Type` is an optional parameter that displays the mount points of specified type.

EXAMPLES

The following example demonstrates the displayed output when you run the `MountList` command.

```
MountList /mymounts/moun1
```


Manage > MountPoints > Mount

Manage > MountPoints > Mount – Use to mount a remote NFS drive as a backup source.

SYNOPSIS

```
Mount RemotePath MountPoint [FileSystemType] [Options]
```

DESCRIPTION

Mount command is used to mount an NFS drive as a backup source.

OPTIONS

```
Mount RemotePath MountPoint [FileSystemType] [Options]
```

Use to mount a remote NFS device as a backup source. Use the parameters *RemotePath*, *MountPoint*, *[FileSystemType]*, and *[Options]* to specify the details of NFS drive. This command includes the following parameters:

<i>RemotePath</i>	Provide the address of device or directory to be mounted. You should use the format <code>HOST:DIRECTORY</code> to write the device name.
<i>MountPoint</i>	Provide name of the target directory where the device should be mounted. The directory name must start with <code>/</code> and must have the correct directory name.
<i>[FileSystemType]</i>	Identify the type of device to be mounted.
<i>[Options]</i>	Specify comma-separated list of parameters to be passed to the appliance along with the <code>Mount</code> command. You can only use options specific for mounting the NFS drive.

EXAMPLES

The following example demonstrates the displayed output when you run the `Mount` command.

```
Mount RemotePath MountPoint [FileSystemType] [Options]
Mount a remote device
```

```
RemotePath      : Address of device/directory to be mounted
MountPoint      : Name of the target directory where the device
                  should be mounted
```

FileSystemType: Identify the type of device to be mounted for
e.g. nfs

Options : Enter optional parameters to be passed to the
mount command

Manage > MountPoints > Unmount

Manage > MountPoints > Unmount – Use to unmount a previously mounted NFS drive.

SYNOPSIS

```
Unmount MountPoint [Force]
```

DESCRIPTION

Use the `Unmount` command to unmount a previously mounted NFS drive. If the directory name is specified correctly the following process takes place:

- The NFS is unmounted successfully.
- The directory is removed from the file system.
- In case the directory is on a nested path, only that directory is removed.

OPTIONS

You can use this command to unmount a previously mounted NFS drive. The following options are used to identify the NFS drive to be unmounted:

MountPoint Provide the name of the directory that is to be un-mounted. The directory name must start with / and must have the correct directory name.

[*Force*] Specify this parameter to unmount the NFS forcibly.

Main > Manage > NetBackup CLI view commands

This appendix includes the following topics:

- [Manage > NetBackupCLI > Create](#)
- [Manage > NetBackupCLI > Delete](#)
- [Manage > NetBackupCLI > List](#)
- [Manage > NetBackupCLI > PasswordExpiry](#)

Manage > NetBackupCLI > Create

Manage > NetBackupCLI > Create – Use to create a NetBackup user account.

SYNOPSIS

`Create UserName`

DESCRIPTION

The `Create` command is used to create NetBackup user account.

Veritas recommends that you use a mix of upper and lower case letters, digits, and other characters. The rules for creating the password are defined for you during this operation.

OPTIONS

`Create UserName`

Use to create a NetBackup user account. Use the `user_name` parameter to define the user that you want to create.

EXAMPLES

The following example demonstrates the displayed output when you run the `Create` command.

To create a new user account

1 Enter `Create <test_user>`

Changing password for test_user.

You can now choose the new password or passphrase.

A valid password should be a mix of upper and lower case letters, digits, and other characters. You can use an 8 character long password with characters from at least 3 of these 4 classes, or a 7 character long password containing characters from all the classes. An upper case letter that begins the password and a digit that ends it do not count towards the number of character classes used.

A passphrase should be of at least 3 words, 12 to 40 characters long and contain enough different characters.

Enter new password:

2 Enter a password.

Re-type new password:

3 Enter the same password a second time to validate the first entry.

Password changed.

- [info] User test_user created successfully

Manage > NetBackupCLI > Delete

Manage > NetBackupCLI > Delete – Use to delete a NetBackup user account.

SYNOPSIS

Delete *UserName*

DESCRIPTION

The `Delete` command is used to delete a NetBackup user account.

OPTIONS

Delete *UserName*

Use to delete a NetBackup user account. Use the *user_name* parameter to define the user that you want to delete.

EXAMPLES

The following example demonstrates the displayed output when you run the `Delete` command.

To delete a user account

◆ Enter `Delete test_user`

- [info] User test_user deleted successfully

Manage > NetBackupCLI > List

Manage > NetBackupCLI > List – Use to view a list of NetBackup users.

SYNOPSIS

List

DESCRIPTION

List command is used to view a list of NetBackup users.

OPTIONS

List

Use to view a list of NetBackup users.

EXAMPLES

The following example demonstrates the displayed output when you run the List command.

```
List of NetBackupCLI users:
myuser
test_user
test_user1
test_user2
```


Manage > NetBackupCLI > PasswordExpiry

Manage > NetBackupCLI > PasswordExpiry – Use to manage the NetBackup command-line passwords.

SYNOPSIS

```
PasswordExpiry Age UserName Days
PasswordExpiry Now UserName
PasswordExpiry Show [UserName]
PasswordExpiry Warn UserName Days
```

DESCRIPTION

When you create a NetBackupCLI user account, you can manage the password of that account through the NetBackup Appliance Shell Menu. You have the ability to do the following:

- Set the age of the password in days, for one or more users.
- Force the expiration of a password for one or more users.
- Configure a warning of when a password is set to expire for one or more users.
- Show the current expiry password information of one or more users.

OPTIONS

```
PasswordExpiry Age UserName Days
```

Use this command to specify a maximum number of days that a password is valid for a user or users.

Use the *Days* variable to set the number of days the password is valid. In addition, use the *UserName* variable to specify the user or users that you want this setting to apply. Enter *All* if you want this setting to apply to all users.

```
PasswordExpiry Now UserName
```

Use this command to force a password to expire immediately for one or more users.

Use the *UserName* variable to specify the user or users whose password is about to expire. Enter *All* if you want to expire the password for all users.

```
PasswordExpiry Show [UserName]
```

Use this command to view the password expiry information.

Use the `[UserName]` variable to specify the user or users. Enter `All` if you want to expire the password for all users. You can also enter `Default` to view the default settings.

`PasswordExpiry Warn UserName Days`

Use this command to configure a warning period in which you receive a warning before the password expires. You can also configure one or more users to receive the warning.

Use the `Days` variable to set the number of days or warning before the password expires. In addition, you use the `UserName` variable to specify the user or users who receive the warning. Enter `All` if you want this setting to apply to all users. You can also enter `Default` to specify the default settings.

Main > Manage > OpenStorage view commands

This appendix includes the following topics:

- [Manage > OpenStorage > Install](#)
- [Manage > OpenStorage > List](#)
- [Manage > OpenStorage > Readme](#)
- [Manage > OpenStorage > Share](#)
- [Manage > OpenStorage > Uninstall](#)

Manage > OpenStorage > Install

Manage > OpenStorage > Install – Use this command to install an OpenStorage plug-in

SYNOPSIS

```
Install plugin_name
```

DESCRIPTION

Before the installation of the OST the appliance performs the following steps:

1. Untars the `tar.gz` file and extract its contents.
2. Checks and verifies if the plug-in exists in the install directory.
3. Checks and verifies if the plug-in directory path is correct. The default path is `/usr/opensv/lib/ost-plugins`.
4. Checks if `nbrmms` is running and terminates it.

Note: The `nbrmms` process should be terminated for the installation to proceed. The installer exits if `nbrmms` does not terminate.

5. Copies `libstspi<vendor_name>.so` and `libstspi<vendor_name>MT.so` into a plug-in directory `/usr/opensv/lib/ost-plugins`

Note: If the plug-in already exists, you are prompted with the following message:
`A plugin already exists, do you want to proceed with the installation. Type Y to proceed.`

6. After the installation is completed, the appliance restarts the `nbrmms` process.

OPTIONS

```
Install plugin_name
```

Use this command to install the *plugin_name.tar.gz*.

EXAMPLES

The following online procedure is executed after you run the `Install` command.

Open storage > Install *plugin_name.tar.gz*

Welcome to the installation of plugin *plugin_name.tar.gz*

- [Info] Checking if upgrade is being run from the console... failed

WARNING: Symantec recommends that this upgrade is run from the
appliance console.

>> Are you sure you want to continue? (yes/no) yes

- [Info] Extracting the contents of the tar file ok

- [Info] Terminating the nbrmms process before proceeding
with the installation. ok

- [Info] Executing the install script

- [Info] Install script exited successfully!

- [Info] Restarting nbrmms ok

- Successfully installed the plugin *plugin_name.tar.gz*

Manage > OpenStorage > List

Manage > OpenStorage > List – Use to list software information.

SYNOPSIS

List Available

List Installed

DESCRIPTION

This command displays all the installed OpenStorage plug-ins and their details.

OPTIONS

List Available

Use this command to list all the OST plug-ins that have been downloaded. The plug-ins are validated against their name and format. The valid plug-ins are listed.

List Installed

Use this command to list the OST plug-in that has been installed on the appliance.

EXAMPLES

The following example demonstrates the displayed output when you run the List Available command.

```
Validating the plugin plugin_name.tar.gz    ok
List of plugins downloaded on the appliance:
plugin_name.tar.gz
```

The following example demonstrates the displayed output when the List Installed command is run.

```
OpenStorage> List Installed
```

Details of the installed OpenStorage plugin:

Plugin Info:

Plugin Name: libstspiDataDomainMT.so

Prefix: DataDomain:
Label: Data Domain Plugin
Build Version: 11
Build Version Minor: 1
Operating Version: 11
Vendor Version: 2.4.0.0-246426

Plugin Name: libstspiQuantumMT.so
Prefix: Quantum
Label: Quantum OST plugin
Build Version: 11
Build Version Minor: 1
Operating Version: 11
Vendor Version: 2.6.0.2088 Quantum MT plugin

Manage > OpenStorage > Readme

Manage > OpenStorage > Readme – Use this command to view the instructions for installing the OpenStorage plug-ins.

SYNOPSIS

Readme

DESCRIPTION

The `Readme` command displays the instructions to install the OpenStorage plug-in.

OPTIONS

Use this command to view the instructions to install the OpenStorage plug-in.

EXAMPLES

The following example displays the instructions that are provided when you run the `Readme` command.

```
OpenStorage> readme
```

```
Plugin Readme
=====
```

The following procedures explain how to copy an OpenStorage plugin on to the NetBackup 52xx appliance and install the plugin.

To copy the plugin from a local computer:

1. Login as the user 'admin' to the appliance.
2. Use the 'Share Open' command to open the NFS and CIFS shares so the appliance can receive the plugin.

For NFS: (nbuappliance:/inst/plugin/incoming)

For CIFS: (\\nbuappliance\incoming_plugins)

3. On the local computer, perform the following steps:

- a. Mount/Map the appropriate NFS/CIFS share.
For CIFS, you must map using the appliance
'admin' user's credentials.
 - b. Download the OpenStorage package from the
appropriate source.
 - c. Upload the package to the mounted share.
 - d. Unmap/Unmount the mounted share.
4. Use the 'Share Close' command to close the NFS and CIFS shares.
 5. Use the 'List Available' command to list the available packages.
Note the name of the plugin to install.

To install an OpenStorage plugin on the NetBackup 52xx:

1. Use the 'Install' command to install the plugin.

Use the name of the plugin that you noted in the procedure
above when you entered the 'List Available' command.

Manage > OpenStorage > Share

Manage > OpenStorage > Share – Use this command to share or to stop sharing directory for uploading plug-in.

SYNOPSIS

Share Open

Share Close

DESCRIPTION

The `Share Open` command enables you to share a directory for uploading the OST plug-in. You can then use the `Share Close` command to stop sharing the directory. This operation is accomplished by opening and closing the Network File System (NFS) and Common Internet File System (CIFS) protocol shares.

OPTIONS

Share Open

Use this command to share a directory.

Share Close

Use this command to stop sharing a directory.

EXAMPLES

The following example displays the output when you run the `Share Open` command.

```
OpenStorage> Share open
```

The CIFS share `\server_name\incoming_plugins`

and the NFS share `server_name:/inst/plugin/incoming`

have been opened on this appliance.

The following example displays the output when you run the `Share Close` command.

```
OpenStorage> Share close
```

The plugin share closed successfully.

Manage > OpenStorage > Uninstall

Manage > OpenStorage > Uninstall – Use this command to uninstall the OpenStorage plug-in

SYNOPSIS

```
Uninstall
```

DESCRIPTION

The OST plug-ins can be uninstalled by deleting the shared libraries in `/usr/open/lib/ost-plugins` directory.

OPTIONS

```
Uninstall
```

Use this command to uninstall the plug-in *plugin_name.tar.gz* that is currently installed on the system.

EXAMPLES

The following example demonstrates the process that you need to follow when you run the `Uninstall` command.

```
OpenStorage> Uninstall plugin_name.tar.gz
```

Displays the following message:

```
- [Info] Checking for the installed OpenStorage plugin ...
```

```
>> The plugin package plugin_name.tar.gz is currently installed  
on the system. Do you want to continue uninstalling it? (yes/no) yes
```

```
>> There might be some existing backups on the storage server.
```

```
Are you sure you want to continue uninstalling the plugin? (yes/no) yes
```

```
- [Info] Uninstalling the plugin package plugin_name.tar.gz ..... ok
```

```
- [Info] Successfully uninstalled the plugin package plugin_name.tar.gz
```

Main > Manage > Software view commands

This appendix includes the following topics:

- [Manage > Software > Cancel](#)
- [Manage > Software > Delete](#)
- [Manage > Software > Download](#)
- [Manage > Software > DownloadProgress](#)
- [Manage > Software > Install](#)
- [Manage > Software > List](#)
- [Manage > Software > LiveUpdateClients](#)
- [Manage > Software > Readme](#)
- [Manage > Software > Rollback](#)
- [Manage > Software > Share](#)
- [Manage > Software > UpgradeStatus](#)

Manage > Software > Cancel

`Manage > Software > Cancel` – This command cancels the download process of a software update or the software patch, which can be in any of these installation stages - downloading or stopped or finished, or postcheck.

SYNOPSIS

`Cancel update_name`

DESCRIPTION

Use this command to cancel a patch download. The downloading can be in one of the following stages:

- Downloading - The software update is in the process of being downloaded.
- Stopped - The downloading process stops abruptly and so, the download cannot be completed.
- Finished - The software update is downloaded completely. However, you must run the `Software > List Downloaded` command to view the software updates that are available for installation.
- Postcheck - During downloading, the software update splits into several files. Once the split files are downloaded, they need to be merged into the software update. The merging is termed as Postcheck.

OPTIONS

`Cancel update_name`

This command cancels downloading of patch. Here, *update_name* is the name of the software patch update.

Manage > Software > Delete

Manage > Software > Delete – Delete a software update.

SYNOPSIS

Delete *update_name*

DESCRIPTION

You can use this command to delete a specific software release update, sometimes referred to as a patch. Use the `Main_Menu > Manage > Software > List Downloaded` command to obtain the list of software release updates that are downloaded.

OPTIONS

Delete *update_name*

Type this command to delete a specific release update. Here *update_name* is the specific name of the update that you want to delete.

Manage > Software > Download

Manage > Software > Download – Download a software update.

SYNOPSIS

Download *update_name*

DESCRIPTION

You can use this command to download a specific release update.

OPTIONS

Download *update_name*

Type this command to download a specific update, where *update_name* is the name of the update that you want to download.

Manage > Software > DownloadProgress

Manage > Software > DownloadProgress – This command shows the progress of an online patch download.

SYNOPSIS

```
DownloadProgress
```

DESCRIPTION

Use this command to display the download progress of a software patch.

OPTIONS

```
DownloadProgress
```

This command displays the download progress of a software patch.

Manage > Software > Install

Manage > Software > Install — Use to install a software release update.

SYNOPSIS

```
Install update_name
```

DESCRIPTION

Use this command to install a new or an existing software update or an engineering binary (EEB) to an appliance that you designate.

To use this command you must know the name of the software update or EEB that you want to install. To see a list of the software updates and EEB that are available for you to install, run `Software > List AvailablePatch` command. This command checks the Veritas site for the latest software update. Once you find the software update or EEB that you want to install, you must run the `Software > Download update_name` command, where *update_name* is the name of the software update.

After you have downloaded the software update, you can now run the `Software > Install update_name` command.

OPTIONS

```
Install update_name
```

Use this command option to install a software release update.

update_name is the name of the update that you want to install.

See [“About NetBackup Appliance Shell Menu usage”](#) on page 11.

Manage > Software > List

Manage > Software > List – Lists the available patch information.

SYNOPSIS

```
List AddOns  
List AvailablePatch  
List Details All  
List Details Base  
List Downloaded  
List Downloaded Details [update_name]  
List EEBs  
List Version
```

DESCRIPTION

This command shows the patches that have been applied to a particular appliance. In addition, you can use this command to show the patches that are available for installation for a particular appliance.

OPTIONS

```
List AddOns  
    Use this command to list software add-ons that are installed on the appliance.  
  
List AvailablePatch  
    Use this command to check the Veritas site for any software updates that are available.  
  
List Details All  
    Use this command to view all of the release updates that are available.  
  
List Details Base  
    Use this command to view all the release updates that were applied to your appliance during the factory installation.  
  
List Downloaded  
    Lists downloaded software updates.
```

List Downloaded Details *update_name*

Lists the detailed information of a downloaded software update.

List EEBs

Shows a detailed listing of all of the factory-installed Emergency Engineering Binaries (EEBs).

List Version

Use this command to view the version of your appliance.

See [“About NetBackup Appliance Shell Menu usage”](#) on page 11.

Manage > Software > LiveUpdateClients

Manage > Software > LiveUpdateClients – to update client software on configured clients using LiveUpdate.

SYNOPSIS

LiveUpdateClients

DESCRIPTION

You can use the NetBackup LiveUpdate feature to support upgrades to major releases and minor releases for NetBackup clients. To use the LiveUpdate feature, first you must create a set of live update policies from the NetBackup Java Console. Then, you must set a NetBackup LiveUpdate server by using the NetBackup Appliance Shell Menu. This server can be either a Web server or a shared disk. The only requirement is that it must be accessible by all of the NetBackup clients that you want to update.

This server is used to download and store NetBackup release update files, and to store the client packages that are included with major and minor releases. From this server, the files are distributed and installed on the computers in your NetBackup environment.

More information about the NetBackup LiveUpdate functionality, see the *NetBackup LiveUpdate Guide*.

You can use this command to update the client software on the clients that are configured with your appliance.

Note: This command is available only for a 52xx master appliance.

OPTIONS

LiveUpdateClients

Use to update the client software on the clients that are configured with your appliance using LiveUpdate.

See [“About the NetBackup Appliance Shell Menu”](#) on page 12.

Manage > Software > Readme

Manage > Software > Readme – Defines the NetBackup patch process.

SYNOPSIS

Readme

DESCRIPTION

This command defines the NetBackup patch process.

OPTIONS

Readme

This command defines the NetBackup patch process.

EXAMPLES

This command contains the following patch information.

Patch Readme

=====

The following procedures explain how to copy a software release update on to the NetBackup Appliance and install the update.

To download software update directly from the Symantec Support Web Site:

1. Use the 'List AvailablePatch' command to look for the latest release updates.
2. Use the 'Download' command to download the release update.
3. Use the 'List Downloaded' command to list all of the downloaded release updates. Note the name of the update to install.

To upload a software update from a local computer:

1. Login as the user 'admin' to the appliance.
2. Use the 'Share Open' command to open the NFS and CIFS shares so the appliance can receive the release updates.
For NFS: (nbapp2ff:/inst/patch/incoming)
For CIFS: (\\nbapp2ff\incoming_patches)
3. On the local computer, perform the following steps:
 - a. Mount/Map the appropriate NFS/CIFS share.
For CIFS, you must map using the appliance 'admin' user's credentials.
 - b. Download the release update from the Symantec Support Web site.
 - c. Unzip the release update and review the README file in the zip.

- d. Upload the unzipped release update to the mounted share.
- e. Unmap/Unmount the mounted share.
- 4. Use the 'Share Close' command to close the NFS and CIFS shares.
- 5. Use the 'List Downloaded' command to list all of the downloaded release updates. Note the name of the update to install.

To install a release update on the NetBackup Appliance:

- 1. Use the 'Install' command to install the release update.
Use the name of the release update that you noted in the procedures above when you entered the 'List Downloaded' command.

For more detailed information about this process, see the *NetBackup Appliance Administrator's Guide*.

See [“About NetBackup Appliance Shell Menu usage”](#) on page 11.

Manage > Software > Rollback

Manage > Software > Rollback – Rollback to the last applied software release update. For example, you may roll back to a specific EEB or to a specific software release version.

SYNOPSIS

```
Rollback eeb_name
```

DESCRIPTION

If the current version of NetBackup on your appliance has the Rollback feature enabled, you can use this command to go from your current version to the previously installed version. In addition, if you want to revert back to the previous version immediately after you have installed a software update, then you must log off and then back on to your appliance to see this command in the command line interface. You cannot roll back to a version that is greater than one release back. To roll back to the last version installed, use the following command.

```
Software> Rollback
```

To roll back to the previous software version, you would not specify a value for *eeb_name*. Leaving that value empty means you want to roll back to the last software version.

You can also use this command to rollback any Emergency Engineering Binaries (EEBs) that are installed on your appliance. You can use the `List Applied` command to view the software version and all installed EEBs. You can then specify which EEB you want to roll back in the *eeb_name* field to roll back that particular EEB. For example, you can enter the following command to roll back EEB `SYM_ABC5200_EEB_1-1.2.3.4`.

```
Software> Rollback SYM_ABC5200_EEB_1-1.2.3.4
```

You can only specify one EEB at a time with this command. However, you can use this command multiple times to roll back as many installed EEBs as you want.

OPTIONS

```
Rollback eeb_name
```

Rollback to the last applied software update or specified EEB, where *eeb_name* is the name of the EEB to rollback to. Do not specify a value for *eeb_name* to roll back to the previous software update.

EXAMPLES

To roll back to a previous software version of NetBackup

- 1 Make sure that you have logged off and logged on to the appliance. That ensures that the `Rollback` command is present in the command line interface.
- 2 From the command line interface, enter the following command:

```
Main_Menu> Support> Software> Rollback
```

- 3 At the following prompt, press the Y key to answer yes.

```
Do you want to rollback to x.x.x.x? (y/n)
```

Where x.x.x.x is the previous version number.

This process requires various processes to be stopped and started. In addition, the previous version that is found, is displayed for you to see.

- 4 After the Rollback has completed, log off and then log back on to your appliance.

To roll back an installed EEB

- 1 Make sure that you have logged off and logged on to the appliance. That ensures that the `Rollback` command is present in the command line interface.
- 2 From the command line interface, enter the following command:

```
Main_Menu> Support> Software> Rollback SYM_ABC5200_EEB_1-1.2.3.4
```

Where `SYM_ABC5200_EEB_1-1.2.3.4` is the name of the EEB that you want to roll back.

- 3 At the following prompt, press the Y key to answer yes.

```
Do you want to rollback the EEB SYM_ABC5200_EEB_1-1.2.3.4? (y/n)
```

- 4 After Rollback has completed, log off and then log back on to your appliance.

Manage > Software > Share

Manage > Software > Share – Share or unshare a directory for incoming patches

SYNOPSIS

Share Open

Share Close

DESCRIPTION

You can use this command to share or not share the directory that is used to receive incoming patches for your appliance. This operation is accomplished by opening and closing the Network File System (NFS) and Common Internet File System (CIFS) protocol shares.

OPTIONS

Share Open

Open the NFS and the CIFS shares for the directory that receives incoming patches.

Share Close

Close the NFS and the CIFS shares for the directory that receives incoming patches.

Manage > Software > UpgradeStatus

Manage > Software > UpgradeStatus – Use this command to see the version and the software upgrade status of your appliance.

SYNOPSIS

UpgradeStatus

DESCRIPTION

This command displays the version and the upgrade status of the appliance.

OPTIONS

UpgradeStatus

Use this command to see the version and the upgrade status of the appliance.

EXAMPLES

The following is an example of information that is displayed when you run the `Main > Manage > Software > UpgradeStatus` command:

```
abc123.Software> UpgradeStatus
```

```
Command backup_system_files is completed. The upgrade is 21% completed.
```

Main > Manage > Storage view commands

This appendix includes the following topics:

- [Manage > Storage > Add](#)
- [Manage > Storage > Create](#)
- [Manage > Storage > Delete](#)
- [Manage > Storage > Edit](#)
- [Manage > Storage > Monitor](#)
- [Manage > Storage > Move](#)
- [Manage > Storage > Remove](#)
- [Manage > Storage > Resize](#)
- [Manage > Storage > Scan](#)
- [Manage > Storage > Show](#)

Manage > Storage > Add

Manage > Storage > Add – Use this command to add a new disk. It also displays the disks that are in a `New Available` state and can be added.

SYNOPSIS

```
Add [Disk ID]
```

DESCRIPTION

This command enables you to add a storage disk. The total capacity of the disk gets added to the `Unallocated` space.

OPTIONS

```
Add [Disk ID]
```

Use to add storage disk, where `[Disk ID]` is the ID of the disk. The Disk ID appears when you run the `Show Disk` command. For example, `S0001FB3BC00000A62501ABDA009`. After a disk is added, the total capacity of the disk gets added to the `Unallocated` space.

Note: If the disk ID is not specified with the `Add` command, the appliance lists the disks that can be added. Only a disk in `New Available` state can be added.

EXAMPLES

The following is an example of the information that is displayed when you run the `Add [Disk ID]` command.

```
Storage > Add S0001FB3BC00000A62501ABDA009
- Performing sanity check on disks and partitions... (5 mins approx)
- Checking whether storage configuration exists
- Checking the state of the 'S0001FB3BC00000A62501ABDA009' disk
- Initializing the 'S0001FB3BC00000A62501ABDA009' disk
- Configuring the S0001FB3BC00000A62501ABDA009 disk storage...
- Adding the 'S0001FB3BC00000A62501ABDA009' disk space to 'Unallocated' space
- Succeeded
```

Manage > Storage > Create

Manage > Storage > Create – Use this command to add a new share.

SYNOPSIS

Create Share

DESCRIPTION

This command exists under the `Main > Manage` view. The `Create Share` command lets you add new share partitions.

Note: This command currently only supports adding share partitions.

OPTIONS

Create Share

Use this command to add new share partitions. After you enter the command, you are prompted to enter the following information: share name, description, allocated capacity, Oracle clients, and NFS export options for each client.

EXAMPLES

The following example demonstrates how to create a new share.

```
Manage > Storage > Create Share
- [Info] Checking storage availability ...
>> Enter Share name: share_1
>> Enter a short description: (None) Testing share_1
>> Enter the allocated capacity for Share 'share_1' in GB/TB [5 GB..44.93 GB]: (5 GB) 5 GB
>> Enter comma-separated list of Oracle server clients that can access this Share: 10.182.0.2
- [Info] Enter the NFS export options for each of the Oracle clients
    The following options are supported:
    ro, rw, root_squash, no_root_squash, all_squash, anonuid, anongid, secure, insecure.
    For detailed information about the NFS export command options, refer to the
    NetBackup Appliance Administrator's guide.
>> Enter the export options for '10.182.0.2': (rw,no_root_squash,secure) rw, no_root_squash
- [Info] Summary:
    Name : share_1
    Description : Testing share_1
    Allocated Capacity : 5GB
```

Clients :

10.182.0.2(rw,no_root_squash)

>> Continue? ['yes', 'no'] yes

- [Info] Creating Share share_1
- [Info] 'Share' storage partition does not exist. Creating it now...
- [Info] The estimated time to create the 'Share' partition can range from
0 hours, 2 minutes to 0 hours, 5 minutes depending on the system load.
The greater the system load the longer it takes to complete the resize operation.
- [Info] Creating the 'Share' partition 'share_1'...
- [Info] Mounting the 'Share' partition 'share_1'...
- [Info] Exporting Share 'share_1' at mount point '/shares/share_1'
- [Info] Share share_1 created successfully
- [Info] NOTES:

Share exported at '10.132.1.237:/shares/share_1'.

Please create a mount point with this export path for all Database
Servers that need access to this Share.

See the NetBackup Appliance Administrator's guide for more detailed
mount instructions.

Manage > Storage > Delete

Manage > Storage > Delete – Use this command to delete existing shares.

SYNOPSIS

```
Delete Share ShareName
```

DESCRIPTION

This command exists under the Main > Manage > Storage view. The Delete Share command lets you delete existing shares.

Note: This command currently only supports deleting shares.

OPTIONS

```
Delete Share ShareName
```

This command is used to delete existing shares.

ShareName defines the name of the share you want to delete.

EXAMPLES

The following example demonstrates how to delete a share.

```
Manage > Storage > Delete Share share_192
- [Info] Deleting Share share_192
- [Info] Unmounting the 'Share' partition 'share_192'...
- [Info] Share exported at '/dump/share_192'
- [Info] Deleting the 'Share' partition 'share_192'...
- [Info] Share share_192 deleted successfully
```

Manage > Storage > Edit

Manage > Storage > Edit – Use this command to edit a share.

SYNOPSIS

```
Edit Share ShareName Description
Edit Share ShareName Clients Add
Edit Share ShareName Clients Update
Edit Share ShareName Clients Delete
```

DESCRIPTION

This command exists under the Main > Manage > Storage view. The Edit Share command lets you edit the details of a share. You can change the description and add, modify, or delete clients.

OPTIONS

```
Edit Share ShareName Description
    This command edits the description of a previously created share. You must
    enter a value for ShareName to edit.

Edit Share ShareName Clients Add
    This command enables you to add additional clients to a previously created
    share. You must enter a value for ShareName to add clients.

Edit Share ShareName Clients Update
    This command enables you to update existing clients of a previously created
    share. You must enter a value for ShareName to update clients.

Edit Share ShareName Clients Delete
    This command enables you to delete the clients of a previously created share.
    You must enter a value for ShareName to delete clients.
```

EXAMPLES

The following example demonstrates how to change the name of a share.

```
Manage > Storage > Edit Share share_1 Name
>> Enter new share name (share_1) : new_share_1
- [Info] Successfully modified share name to 'new_share_1'.
```


The following example demonstrates how to change the description of a share.

```
Manage > Storage > Edit Share share_1 Description
- [Info] Old Description :
    "My Test Share description"
>> Enter the New Description ( Enter to keep old description ) : My New Test Share description
- [Info] Successfully edited description of share 'share_1'.
```

The following example demonstrates how to add clients to a share.

```
Manage > Storage > Edit Share share_1 Clients Add
- [Info] List of Oracle server clients that can access this share
    hostA (rw, root_squash,secure)
    10.182.0.2 (rw, root_squash, anonuid=1024, anongid=1024)
>> Enter comma-separated list of Oracle server clients you would like to add : hostC, HostD
>> Enter comma-separated list of NFS export options for the Oracle clients added above.
    The following options are supported:
        ro, rw, no_root_squash, root_squash, all_squash, anonuid, anongid , secure, insecure
    For detailed information about the NFS export command options, refer to
    NetBackup Appliance Administrator's guide.
>> Export options for 'hostC' (rw, no_root_squash, secure) :
    rw, root_squash, anonuid=1024, anongid=1024
>> Export options for 'hostD' (rw, no_root_squash, insecure) :
    rw, no_root_squash, secure

- [Info] Summary of clients:
    hostA (rw, root_squash,secure)
    10.182.0.2 (rw, root_squash, anonuid=1024, anongid=1024)
    hostC (rw, root_squash, anonuid=1024, anongid=1024)
    hostD (rw, root_squash, anonuid=1024, anongid=1024)

- [Info] Successfully edited clients of share 'share_1'.
```

The following example demonstrates how to update the clients of a share.

```
Manage > Storage > Edit Share share_1 Clients Update
- [Info] List of Oracle server clients that can access this share
    hostA (rw, root_squash,secure)
    10.182.0.2 (rw, root_squash, anonuid=1024, anongid=1024)
>> Enter comma-separated list of Oracle server clients you would like to update : hostA
>> Enter comma-separated list of NFS export options for the Oracle clients added above.
    The following options are supported:
        ro, rw, no_root_squash, root_squash, all_squash, anonuid, anongid , secure, insecure
    For detailed information about the NFS export command options, refer to
    NetBackup Appliance Administrator's guide.
```

```
>> Export options for 'hostA' (rw, root_squash, anonuid=1024, anongid=1024) :  
    rw, no_root_squash, secure  
- [Info] Summary of clients:  
    hostA (rw, no_root_squash, secure)  
    10.182.0.2 (rw, root_squash, anonuid=1024, anongid=1024)  
- [Info] Successfully updated clients of share 'share_1'.
```

The following example demonstrates how to delete clients from a share.

```
Manage > Storage > Edit Share share_1 Clients Delete  
- [Info] List of Oracle server clients that can access this share  
    hostA (rw, root_squash,secure)  
    10.182.0.2 (rw, root_squash, anonuid=1024, anongid=1024)  
>> Enter comma-separated list of Oracle server clients you would like to delete : hostA  
- [Info] Summary of clients:  
    10.182.0.2 (rw, root_squash, anonuid=1024, anongid=1024)  
- [Info] Successfully deleted clients of share 'share_1'.
```

Manage > Storage > Monitor

Manage > Storage > Monitor – Use to monitor storage tasks.

SYNOPSIS

Monitor

DESCRIPTION

This command enables you to monitor the current status of storage tasks currently in progress.

OPTIONS

Monitor

Use to monitor the current status of storage tasks currently in progress.

EXAMPLES

The following example displays the initiated procedure when you run the `Monitor` command, during a resize operation.

```
Storage > Monitor
```

```
Press 'CTRL + C' to quit.
```

```
Resizing the AdvancedDisk storage partition...
```

```
The estimated time to resize the partition is 2 to 5 minutes.
```

```
Stopping NetBackup processes... (2 mins approx)
```

Manage > Storage > Move

Manage > Storage > Move – Use to move storage partition from one disk to another.

SYNOPSIS

```
Move Partition SourceDiskID TargetDiskID [Size] [Unit]
```

DESCRIPTION

This command lets you move a storage partition from one disk to another.

OPTIONS

```
Move Partition SourceDiskID TargetDiskID [Size] [Unit]
```

Use to move a partition from one storage disk to another, where:

- *Partition* refers to the storage partition like AdvancedDisk, Configuration, MSDP etc.
The NetBackup Catalog partition cannot be moved.
- *SourceDiskID* refers to the disk ID of the source disk. Use `Show Distribution` to view the disk ID and the partitions on it. A sample disk ID is S0001FB362501ABDA0000009se.
- *TargetDiskID* refers to the disk ID of the target disk. Use `Show Distribution` to view the disk ID and the partitions on it. A sample disk ID is S2301FB362501ABDA0000009se.
- *[Size]* refers to the partition size. Partition size must be greater than 0. If you specify a partition size that is greater than the actual partition size, appliance moves the whole partition. The default value is `[1]`.
- *[Unit]* refers to unit size (GB/TB/PB). The default value is `[PB]`.

Examples

The following example displays the initiated procedure when you run the `Move` command.

```
Storage > Move AdvancedDisk S0001FB362501ABDA0000009se
S2301FB3BC00540A62501ABDA0000009se 5 GB
- [Info] Performing sanity check on disks and partitions...(5 mins approx)
- [Warning] Do not reboot the appliance while the partition move is in
progress.
```

- [Info] The estimated time to move the partition can range from 0 hours, 1 minutes to 0 hours, 2 minutes depending on the system load.
The greater the system load the longer it takes to complete the move operation.
- >> Do you want to continue? (yes/no) yes
Moving part '1/1' disks... Done
- [Warning] No recipients are configured to receive software notifications.
Use 'Settings->Alerts->Email Software Add' command to configure the appropriate Email address.
- [Info] Succeeded.

Manage > Storage > Remove

Manage > Storage > Remove – Use this command to remove a storage disk.

SYNOPSIS

Remove *DiskID*

DESCRIPTION

The command removes a storage disk, and changes the state to *New Available*. You can remove disks with status **In Use** that do not contain any partitions. You can also remove disks with status **Foreign**.

If a disk with status **In Use** has partitions and you want to remove it, you must first move the partitions to other disks. Use the *Show Distribution* command to see the partitions that are on the disk and then use the *Move* command to move the partitions to another disk. Once the partitions have been moved, try removing the disk again.

A disk with status **Foreign** may have data. If you try to remove such a disk, any data present on it is also removed.

OPTIONS

Remove *DiskID*

Use to remove an existing disk and changes the state to *New Available*. The Disk ID can be retrieved by running the *Show Disk* command. For example, a sample Disk ID is *S0001FB3BC00000A62501ABDA0000009se*.

Warning: After removing a storage disk, if the appliance reboots it can hang and display the **Boot splash** screen. Press the **ESC** key to proceed. The RAID controller firmware provides step-by-step instructions to help you boot the appliance

EXAMPLES

The following is an example of the information that is displayed when you run the *Remove Disk ID* command.

```
Storage > Remove S000162501ABDA000009se
- [Info] Performing sanity check on disks and partitions...(5 mins approx)
- [Info] Checking the type of 'S000162501ABDA000009se' disk...
```

- [Info] Checking the state of 'S000162501ABDA000009se' disk...
- [Info] Removing the 'S000162501ABDA000009se' disk space
from 'Unallocated'...
- [Info] Succeeded.

The following output displays the updated status of the removed storage expansion unit, after using the `Show Disk` command.

Storage> Show Disk

Disk ID	Type	Total	Unallocated	Status

SE000000000000000000se	System	150 GB	-	In Use
S0001FB3BC00A0000009se	Base	150 GB	33.968 GB	In Use
S000162501ABDA000009se	Expansion	35 TB	-	New Available

You cannot issue commands for disks with the status 'n/a'.

Storage> Show Disk

Disk ID	Type	Total	Unallocated	Status

SE000000000000000000se	Operating System	150 GB	-	In Use
S0001FB3BC00A0000009se	Base	150 GB	33.968 GB	In Use
S000162501ABDA000009se	Expansion	35 TB	-	New Available

You cannot issue commands for disks with the status 'n/a'.

Manage > Storage > Resize

Manage > Storage > Resize – Use to create, resize, or delete a selected partition.

SYNOPSIS

`Resize Partition Size Unit`

DESCRIPTION

This command enables you to create, resize, or delete the storage partitions in your appliance. The `Resize` command can be used for a single storage partition at a time. You can use this command to resize the storage capacity of a partition to a higher or a lower value. The disk storage cannot be expanded to a size that is greater than the unallocated space.

Note: Shares can only be resized with this command. They cannot be created or deleted. Use the Create and Delete commands to create and delete shares.

Review the following considerations:

- You can create a partition using `Resize` only if the Appliance is configured as a master or a media server.
- You can resize a partition to a higher or lower value depending on the type of partition. The size is expanded by using the unallocated space.
- You can delete a partition using `Resize` only if the Appliance is in a factory state (when it is not configured as a master or media server).

An informational message like the following is displayed when you resize a partition:

```
The estimated time to resize the partition can range from
0 hours, 2 minutes to 0 hours, 5 minutes depending on the
system load. The greater the system load the longer it takes
to complete the resize operation.
```

OPTIONS

`Resize Partition Size Unit`

Use to resize the storage partitions, where:

- `Partition` refers to the name of the partition like `AdvancedDisk`, `Catalog`, `Configuration`, `MSDP`, `Share` etc.

- *Size* refers to the size to which you want to resize the partition.
- *Unit* refers to the unit for resizing the partition in (GB/TB/PB).

EXAMPLES

The following example displays the initiated procedure when you run the `Resize` command.

```
Storage > Resize AdvancedDisk 1 TB
- [Info] Performing sanity check on disks and partitions...(5 mins approx)
- [Info] The estimated time to resize the partition can range from
0 hours, 2 minutes to 0 hours, 5 minutes depending on the system load.
The greater the system load the longer it takes to complete the
resize operation.

Do you want to continue? (yes/no) yes
- [Info] Shrinking the 'AdvancedDisk' storage partition...
- [Warning] No recipients are configured to receive software notifications.
Use Main > Settings > Email Software Add command to configure the
appropriate email address.
- [Info] Succeeded.
```

Manage > Storage > Scan

Manage > Storage > Scan – Use this command to refresh the storage disks and devices information.

SYNOPSIS

Scan

DESCRIPTION

This command enables you to refresh the storage disks and devices information.

Note: Whenever a storage device is connected or disconnected, use this command to detect the storage device, or refresh its status. If the disks of the connected storage device are in a foreign state, import the RAID group, and run the `Scan` command. If the `Scan` command does not display the updated storage device information, then restart the appliance to refresh the storage device information.

OPTIONS

Scan

Use to refresh the storage disks and devices information.

EXAMPLES

The following example displays the initiated procedure when you run the `Scan` command.

```
Storage > Scan
```

```
- [Info] Performing sanity check on disks and partitions...(5 mins approx)
- [Info] The Scan operation can take up to 15 minutes to complete.
- [Info] Initiating refresh of the storage devices...
- [Info] Succeeded.
```

NOTE: If you perform a 'Main-Manage-Storage Show Disk' command and the device information does not appear in the output, verify if the disk drives are in a foreign state. If the disk drives are in foreign state, import them and then perform a 'Main > Manage > Storage Scan' operation to refresh the device information. The device information may appear properly.

If the device information still does not appear, then restart the appliance to refresh the device information.

For 5330 appliances, the connected devices are scanned and the following output may be displayed:

```
Storage> Scan
- [Info] Performing sanity check on disks and partitions... (5 mins approx)
- [Info] The scan operation can take up to 15 minutes to complete.
- [Info] Refreshing the storage devices...
- [Info] Created 14 new disks (RAID groups) on External Storage.
- [Info] Succeeded.

- [Info] The new disks are being initialized. The disk initialization
happens in the background and may take up to 56 hours depending on the
system load. You can continue to use the appliance during this time.
However, if one or more of the new disks are used by partitions during
the disk initialization process, the performance of backup and restore
operations on the specific disks degrades by up to 30%.
```

NOTE: If you run the 'Manage->Storage->Show Disk' command and the device information does not appear in the output, run the 'Manage->Storage->Scan' to import and refresh the device information. If the device information still does not appear, restart the appliance to refresh the device information.

Manage > Storage > Show

Manage > Storage > Show – Use this command to view NetBackup storage information.

SYNOPSIS

Show *[Type]*

DESCRIPTION

This command enables you to view the storage capacity and parameters of the storage devices and partitions within your appliance.

OPTIONS

Show All

This command shows all of the storage information.

Show Disk

This command shows the storage disk information.

Show Distribution

This command shows the storage distribution information.

Show Partition *[Info]* *[PartitionType]* *[Name]*

This command shows the storage partition information.

- *[Info]* - Partition information. The available options are ALL, Configuration, and Usage. Choose Configuration to see names of the disk pools and storage units. Choose Usage to see the disk usage details. The default value is ALL
- *[PartitionType]* - Partition type. The available options are ALL, AdvancedDisk, Configuration, MSDP, MSDPCatalog, NetBackupCatalog, and Share. The default value is ALL.
- *[Name]* - Partition name. The partitions are named by numerals. You can find the name for each partition in the Show All output. The default value is ALL

EXAMPLES

The following example displays a sample output for the Show [All] command.

For a 5230 media appliance, the storage information is displayed as shown in the following example.

```
Storage> Show All
```

```
-[Info] Performing sanity check on disks and partitions...(5 mins approx)
```

```
=====
Disk ID                | Type                | Total|Unallocated| Status
=====
SE000000000000000000se|Operating System    |150 GB|      -      | n/a
S0001FB3BC00A0000009se|Base                |150 GB| 33.968 GB | In Use

S0001FB3BC00A0000009se (Base)
```

```
AdvancedDisk      : 20 GB
MSDP              : 50 GB
Share            : 5 GB
Configuration     : 1 GB
```

Partition	Total	Available	Used	%Used	Status
AdvancedDisk	20 GB	19.778 GB	227.31 MB	2	Optimal
MSDP	300 GB	150 GB	250 GB	2	Optimal
Configuration	1 GB	995.35 MB	28.640 MB	3	Optimal
Share	5 GB	4.94 GB	58.23 MB	2	Optimal
Unallocated	545.84 MB	-	-	-	-

You cannot issue commands for disks with the status 'n/a'.

For a 5330 platform, the appliance displays the storage information as shown in the following example:

- [Info] Performing sanity check on disks and partitions... (5 mins approx)

Disk ID	Type	Total	Unallocated	Status
5E000000000000000000000000000000	System	930.39 GB	-	n/a
7A30D550001B22423721D79081	Base	13.64 TB	10.84 TB	In Use

7A30D550001B22423721D79081 (Base)

```
AdvancedDisk      :    500 GB
```

```
- 0 : 500 GB
Configuration : 25 GB
- 0 : 25 GB
MSDP : 1 TB
- 0 : 1 TB
MSDP Catalog : 43 GB
- 0 : 43 GB
NetBackup Catalog : 250 GB
- 0 : 250 GB
Share : 1 TB
- s1 : 1 TB
```

```
-----
Partition | Total | Available | Used | %Used | Status
-----
AdvancedDisk | 500 GB | 495.81 GB | 4.19 GB | 1 | Optimal
Configuration | 25 GB | 21.52 GB | 3.48 GB | 14 | Optimal
MSDP | 1 TB | 1015.6 GB | 8.36 GB | 1 | Optimal
MSDP Catalog | 43 GB | 42.59 GB | 414.99 MB | 1 | Optimal
NetBackup Catalog | 250 GB | 247.62 GB | 2.38 GB | 1 | Optimal
Share | 1 TB | 1015.6 GB | 8.34 GB | 1 | Optimal
Unallocated | 10.84 TB | - | - | - | -
```

AdvancedDisk

```
-----
Partition | Total | Available | Used | %Used | Status
-----
0 | 500 GB | 495.81 GB | 4.19 GB | 1 | Mounted
```

Configuration

```
-----
Partition | Total | Available | Used | %Used | Status
-----
0 | 25 GB | 21.52 GB | 3.48 GB | 14 | Mounted
```

MSDP

```
-----
Partition | Total | Available | Used | %Used | Status
-----
0 | 1 TB | 1015.6 GB | 8.36 GB | 1 | Mounted
```

MSDP Catalog

Partition	Total	Available	Used	%Used	Status
0	43 GB	42.59 GB	414.99 MB	1	Mounted

NetBackup Catalog

Partition	Total	Available	Used	%Used	Status
0	250 GB	247.62 GB	2.38 GB	1	Mounted

Share

Partition	Total	Available	Used	%Used	Status
s1	1 TB	1015.6 GB	8.34 GB	1	Mounted

AdvancedDisk

Disk Pool (DP)	Storage Unit (STU)
dp_adv_nbapp2br	stu_adv_nbapp2br

MSDP

Disk Pool (DP)	Storage Unit (STU)
dp_disk_nbapp2br	stu_disk_nbapp2br

Share - s1

Description:

None

Clients	Options
appesx30-vm13	no_root_squash, rw, secure

You cannot issue commands for disks with the status 'n/a'.

The sizes that are displayed here for the MSDP partition are different from the MSDP disk pool sizes. See the NetBackup Appliance Administrator's Guide for more information.

Instructions to use a share:

On UNIX systems, a share can be mounted using nbapp2br.engba.symantec.com:/shares/<Name>.

The following example displays the initiated procedure when you run the `Show [Disk]` command on a 52xx appliance.

Storage> Show Disk

Disk ID	Type	Total	Unallocated	Status
SE000000000000se	Operating System	930.39 TB	-	n/a
S0001FB35CC3F2B	Base	2.24 TB	300 GB	In Use
S00ABDD00000001s	Expansion	4.5421 TB	840.92 GB	In Use

You cannot issue commands for devices with the status 'n/a'.

Storage> Show Disk

Disk ID	Type	Total	Unallocated	Status
SE000000000000se	System	930.39 TB	-	n/a
S0001FB35CC3F2B	Base	2.24 TB	300 GB	In Use
S00ABDD00000001s	Expansion	4.5421 TB	840.92 GB	In Use

You cannot issue commands for devices with the status 'n/a'.

For a 5330 platform, the appliance displays the disk information as shown in the following example:

Storage> Show Disk

- [Info] Performing sanity check on disks and partitions..(5 mins approx)

Disk ID	Type	Total	Unallocated	Status
5E00000000000000000000000000000000	System	2.73 TB	-	n/a
5E00000100000000000000000000000000	System	2.73 TB	-	n/a
50001FD36800000796537BB10F	Meta	5.46 TB	5.46 TB	In Use
50001FEE6C000000A38537BB0D5	Meta	5.46 TB	5.37 TB	In Use
50001FD3680000078A537BB0DC	Data	19.10 TB	19.10 TB	In Use
50001FD3680000078C537BB0E4	Data	19.10 TB	19.10 TB	In Use
50001FD3680000078E537BB0EC	Data	19.10 TB	0 GB	In Use
50001FD36800000790537BB0FA	Data	19.10 TB	7.30 TB	In Use
50001FD36800000792537BB102	Data	19.10 TB	19.08 TB	In Use
50001FD36800000794537BB10B	Data	19.10 TB	0 GB	In Use


```
50001FEE6C00000A32537BB0B4|Data      | 19.10 TB |19.10 TB  | In Use
50001FEE6C00000A34537BB0C3|Data      | 19.10 TB |19.10 TB  | In Use
50001FEE6C00000A36537BB0CB|Data      | 19.10 TB |18.20 TB  | In Use
50001FEE6C00000A3A537BB0D8|Data      | 19.10 TB | 0 GB     | In Use
50001FEE6C00000A3C537BB0E1|Data      | 19.10 TB |19.10 TB  | In Use
50001FEE6C00000A3E537BB0EA|Data      | 19.10 TB |19.10 TB  | In Use
```

You cannot issue commands for disks with the status 'n/a'.

The following example displays the initiated procedure when you run the `Show Partition All` command on a 5330 appliance.

- [Info] Performing sanity check on disks and partitions... (5 mins approx)

```
-----
Partition      | Total      | Available  | Used        | %Used | Status
-----
AdvancedDisk    |    500 GB | 495.81 GB |    4.19 GB |    1 | Optimal
Configuration    |    25 GB | 21.52 GB |    3.48 GB |   14 | Optimal
MSDP             |     1 TB | 1015.6 GB |    8.36 GB |    1 | Optimal
MSDP Catalog     |    43 GB | 42.59 GB | 414.99 MB |    1 | Optimal
NetBackup Catalog |   250 GB | 247.62 GB |    2.38 GB |    1 | Optimal
Share           |     1 TB | 1015.6 GB |    8.34 GB |    1 | Optimal
Unallocated      |  10.84 TB |      -    |      -     |    - | -
```

AdvancedDisk

```
-----
Partition | Total      | Available  | Used        | %Used | Status
-----
0          |    500 GB | 495.81 GB |    4.19 GB |    1 | Mounted
```

Configuration

```
-----
Partition | Total      | Available  | Used        | %Used | Status
-----
0          |    25 GB | 21.52 GB |    3.48 GB |   14 | Mounted
```

MSDP

```
-----
Partition | Total      | Available  | Used        | %Used | Status
-----
0          |     1 TB | 1015.6 GB |    8.36 GB |    1 | Mounted
```

MSDP Catalog

```
-----  
Partition | Total      | Available  | Used      | %Used | Status  
-----  
0          | 43 GB      | 42.59 GB  | 414.99 MB | 1     | Mounted
```

NetBackup Catalog

```
-----  
Partition | Total      | Available  | Used      | %Used | Status  
-----  
0          | 250 GB     | 247.62 GB | 2.38 GB   | 1     | Mounted
```

Share

```
-----  
Partition | Total      | Available  | Used      | %Used | Status  
-----  
s1         | 1 TB       | 1015.6 GB | 8.34 GB   | 1     | Mounted
```

AdvancedDisk

```
-----  
Disk Pool (DP) | Storage Unit (STU)  
-----  
dp_adv_nbapp2br | stu_adv_nbapp2br
```

MSDP

```
-----  
Disk Pool (DP) | Storage Unit (STU)  
-----  
dp_disk_nbapp2br | stu_disk_nbapp2br
```

Share - s1

Description:

```
-----  
None  
-----
```

```
-----  
Clients      | Options  
-----  
appesx30-vm13 | no_root_squash, rw, secure  
-----
```

The sizes that are displayed here for the MSDP partition are different from the MSDP disk pool sizes. See the NetBackup Appliance Administrator's Guide for more information.

Instructions to use a share:

On UNIX systems, a share can be mounted using `nbapp2br.engba.symantec.com:/shares/<Name>`.

Note: The Available and Used Size values displayed for the MSDP partition on the **Manage > Storage > Partitions** page or by using the **Manage > Storage > Show** command on the NetBackup Appliance Shell Menu may not be the full space available or used by the MSDP partition. This is because space is reserved by the file system and also by MSDP. The file system reserves space for its own use. In addition, MSDP reserves 4 percent of the storage space for the deduplication database and transaction logs.

Check the MSDP disk pool sizes displayed on the NetBackup Administration Console to know the MSDP statistics.

The following example displays the initiated procedure when you run the `Show [Distribution]` command on a 52xx appliance:

```
Storage> Show Distribution
```

```
- [Info] Performing sanity check on disks and partitions... (5 mins approx)
7A30D550001B22423721D79081 (Base)
-----
AdvancedDisk      :      500 GB
- 0               :      500 GB
Configuration     :       25 GB
- 0               :       25 GB
MSDP              :       1 TB
- 0               :       1 TB
MSDP Catalog      :       43 GB
- 0               :       43 GB
NetBackup Catalog :      250 GB
- 0               :      250 GB
Share             :       1 TB
- s1              :       1 TB
```

The following example displays the initiated procedure when you run the `Show [Distribution]` command on a 5330 appliance:

```
- [Info] Performing sanity check on disks and partitions... (5 mins approx)
5000298708000002CD55031660 (Data)
-----
Configuration     :       25 GB
- 0               :       25 GB
MSDP              :      15.00 TB
```

- 10 : 15.00 TB

5000298708000002D05503166A (Data)

MSDP : 19.10 TB

- 8 : 19.10 TB

5000298708000002D35503166F (Data)

AdvancedDisk : 10 TB

- 0 : 10 TB

Share : 15 GB

- share_1 : 5 GB

- share_2 : 10 GB

5000298708000002D655031675 (Meta)

MSDP Catalog : 5.46 TB

- 0 : 5.46 TB

5000298708000002D955031678 (Data)

MSDP : 19.10 TB

- 3 : 19.10 TB

5000298708000002DC5503167E (Data)

MSDP : 19.10 TB

- 0 : 19.10 TB

5000298708000002DF55031685 (Data)

MSDP : 19.10 TB

- 2 : 19.10 TB

5000298E5C0000026955031634 (Data)

MSDP : 19.10 TB

- 1 : 19.10 TB

5000298E5C0000026C55031639 (Data)

MSDP : 19.10 TB

- 5 : 19.10 TB

5000298E5C00000026F5503163E (Data)

MSDP : 19.10 TB

- 6 : 19.10 TB

5000298E5C00000027255031648 (Data)

MSDP : 19.10 TB

- 7 : 19.10 TB

5000298E5C0000002755503164F (Data)

MSDP : 19.10 TB

- 9 : 19.10 TB

5000298E5C00000027855031655 (Data)

MSDP : 19.10 TB

- 4 : 19.10 TB

5000298E5C00000027B55031658 (Meta)

MSDP Catalog : 5.45 TB

- 0 : 5.45 TB

Main > Manage > Tapes view commands

This appendix includes the following topics:

- [Manage > Tapes > Cleaning](#)
- [Manage > Tapes > Delete](#)
- [Manage > Tapes > Eject](#)
- [Manage > Tapes > Freeze](#)
- [Manage > Tapes > Inventory](#)
- [Manage > Tapes > List](#)
- [Manage > Tapes > ListNetBackupMedia](#)
- [Manage > Tapes > Suspend](#)
- [Manage > Tapes > Unfreeze](#)
- [Manage > Tapes > Unsuspend](#)

Manage > Tapes > Cleaning

Manage > Tapes > Cleaning – Designate that a tape is the cleaning tape.

SYNOPSIS

Cleaning *mediaid*

DESCRIPTION

Use this command to designate which tape in a tape library is the cleaning tape.

OPTIONS

Cleaning *mediaid*

Use to indicate which tape is the cleaning tape.

mediaid is the media identifier.

See [“About NetBackup Appliance Shell Menu usage”](#) on page 11.

Manage > Tapes > Delete

Manage > Tapes > Delete – Delete media from a NetBackup database.

SYNOPSIS

Delete *mediaid*

DESCRIPTION

Use this command to identify a piece of media to delete from a NetBackup database.

OPTIONS

Delete *mediaid*

Use to delete media from a NetBackup database.

mediaid is the media identifier.

See [“About the commands under the Manage view”](#) on page 16.

See [“About NetBackup appliance commands”](#) on page 10.

See [“Logging into the NetBackup Appliance Shell Menu ”](#) on page 11.

See [“About NetBackup Appliance Shell Menu usage”](#) on page 11.

Manage > Tapes > Eject

Manage > Tapes > Eject – Eject media from a tape library.

SYNOPSIS

`Eject mediaid`

DESCRIPTION

Use this command to identify and eject media from a tape library.

OPTIONS

`Eject mediaid`

Use to eject media from a tape library.

mediaid is the media identifier.

Manage > Tapes > Freeze

Manage > Tapes > Freeze – Freeze media in a NetBackup database.

SYNOPSIS

`Freeze mediaid`

DESCRIPTION

Use this command to select a piece of media to freeze in a NetBackup database.

OPTIONS

`Freeze mediaid`

Use to freeze media in a NetBackup database.

mediaid is the media identifier.

Manage > Tapes > Inventory

`Manage > Tapes > Inventory` – Inventory all of the libraries for the volumes that have been added or removed.

SYNOPSIS

`Inventory`

DESCRIPTION

Use this command to inventory all of the libraries for the volumes that have been added or removed.

OPTIONS

`Inventory`

Inventory all libraries for added or removed volumes.

Manage > Tapes > List

Manage > Tapes > List – Show a list of the media.

SYNOPSIS

List

DESCRIPTION

Use this command to list the media. This command provides the following types of information about the media:

- Media ID
- Media type
- Robot type
- Robot number
- Robot slot
- Side/face
- Optical partner
- Number of mounts and cleanings
- Last mount time

OPTIONS

List

Lists the media.

Manage > Tapes > ListNetBackupMedia

Manage > Tapes > ListNetBackupMedia – Show a list of the media that NetBackup uses.

SYNOPSIS

ListNetBackupMedia

DESCRIPTION

Use this command to show a list of the media that NetBackup uses.

OPTIONS

ListNetBackupMedia

List the media that NetBackup uses.

Manage > Tapes > Suspend

Manage > Tapes > Suspend – Suspend media in a NetBackup database.

SYNOPSIS

`Suspend mediaid`

DESCRIPTION

Use this command to select and suspend media in a NetBackup database.

OPTIONS

`suspend mediaid`

Use to suspend media in a NetBackup database.

mediaid is the media identifier.

Manage > Tapes > Unfreeze

Manage > Tapes > Unfreeze – Unfreeze the media that has been frozen in a NetBackup database.

SYNOPSIS

```
Unfreeze mediaid
```

DESCRIPTION

Use this command to unfreeze the media that has been frozen in a NetBackup database.

OPTIONS

```
Unfreeze mediaid
```

Unfreeze the frozen media in a NetBackup database.

mediaid is the media identifier.

Manage > Tapes > Unsuspend

Manage > Tapes > Unsuspend – Unsuspend the media that has been suspended in a NetBackup database.

SYNOPSIS

```
Unsuspend mediaid
```

DESCRIPTION

Use this command to unsuspend the media that had been suspended in a NetBackup database.

OPTIONS

```
Unsuspend mediaid
```

Unsuspend media in a NetBackup database.

mediaid is the media identifier.

Main > Manage > Certificates

This appendix includes the following topics:

- [Manage > Certificates > Generate](#)
- [Manage > Certificates > Delete](#)

Manage > Certificates > Generate

Manage > Certificates > Generate – Use the Generate command to generate and download a certificate for a vCenter or SCVMM client.

SYNOPSIS

Generate *hostname*

DESCRIPTION

Use the Generate command to create new certificates for vCenter or SCVMM clients on the NetBackup appliance. After the certificate has been generated, it is downloaded to the following location:

`/usr/opensv/var/global/wsl/credentials/clients/hostname.zip`

OPTIONS

Generate *hostname*

Use to generate a certificate for the NetBackup client. Enter the client hostname for which you want to generate a certificate.

Manage > Certificates > Delete

Manage > Certificates > Delete – Use the Delete command to delete an existing certificate.

SYNOPSIS

Delete *hostname*

DESCRIPTION

Use the Delete command to delete an existing certificate for a vCenter or SCVMM client on the NetBackup appliance.

OPTIONS

Delete *hostname*

Use to delete a damaged certificate. Specify a client hostname that you want to delete.

Main > Monitor view commands

This appendix includes the following topics:

- [Monitor > Beacon](#)
- [Monitor > MemoryStatus](#)
- [Monitor > NetBackup](#)
- [Monitor > NetworkStatus](#)
- [Monitor > SDCS](#)
- [Monitor > Top](#)
- [Monitor > Uptime](#)
- [Monitor > Who](#)

Monitor > Beacon

`Monitor > Beacon` – This command flashes or stops flashing lights on your appliance.

SYNOPSIS

`Beacon Duration`

`Beacon Stop`

DESCRIPTION

The Beacon command enables you to flash the disk drive lights or to stop flashing the lights on the specified storage shelf (or enclosure) or hard disk drives of a 52xx appliance. When two storage shelves are attached to a 5220 or 5230 appliance, you can use the `Beacon` command to identify a specific storage shelf.

OPTIONS

`Beacon Duration Enclosure EnclosureID [Minutes]`

Use this command to specify an amount of time to allow all the disk drives lights of an enclosure to flash. Here, *EnclosureID* is the device ID of the enclosure and [Minutes] is the duration of time, in minutes, that lights can flash. [Minutes] is an optional parameter. If you do not enter a value for this parameter, it takes the default value of 10 minutes.

`Beacon Duration HDD EnclosureID SlotNo [Minutes]`

Use this command to specify an amount of time to allow a disk drive light to flash. Here, *EnclosureID* is the device ID of the enclosure and *SlotNo* is the slot number of the disk. [Minutes] is the duration of time, in minutes, that lights can flash. [Minutes] is an optional parameter. If you do not enter a value for this parameter, it takes the default value of 10 minutes.

`Beacon Duration WWID [WWID] [Minutes]`

Use this command to specify an amount of time to allow all the disk drives lights of an expansion unit to flash. Here, [WWID] is the device ID of the expansion unit and [Minutes] is the duration of time, in minutes, that lights can flash. [Minutes] is an optional parameter. If you do not enter a value for this parameter, it takes the default value of 10 minutes.

`Beacon Stop Enclosure EnclosureID`

Use this command to stop flashing the lights of all the disk drives of an enclosure. Here, *EnclosureID* is the device ID of the enclosure.

Beacon Stop HDD *EnclosureID SlotNo*

Use this command to stop flashing the light of a disk drive. Here, *EnclosureID* is the device ID of the enclosure and *SlotNo* is the slot number of the disk.

Beacon Stop WWID [WWID]

Use this command to stop flashing the lights of the disk drives of an expansion unit. Here, [WWID] is the device ID of the expansion unit. If you do not enter a value for this parameter, it displays a list of available expansion WWIDs.

Monitor > MemoryStatus

`Monitor > MemoryStatus` – Displays memory usage statistics of the appliance in KB.

SYNOPSIS

`MemoryStatus`

DESCRIPTION

Use this command to report memory usage statistics in KB.

OPTIONS

Use this command to report memory usage statistics in KB.

See [“About the NetBackup Appliance Shell Menu”](#) on page 12.

EXAMPLES

The following is an example of information that is displayed when you run the `Main > Monitor > MemoryStatus` command.

```
abc123.Monitor> MemoryStatus
```

	total	used	free	shared	buffers	cached
Mem:	8065028	6617948	1447080	0	347384	5111668
-/+ buffers/cache:		1158896	6906132			
Swap:	10993656	0	10993656			
Total:	19058684	6617948	12440736			

	total	used	free	shared	buffers	cached
Mem:	8065028	6617940	1447088	0	347384	5111664
-/+ buffers/cache:		1158892	6906136			
Swap:	10993656	0	10993656			
Total:	19058684	6617940	12440744			

	total	used	free	shared	buffers	cached
Mem:	8065028	6617940	1447088	0	347384	5111664
-/+ buffers/cache:		1158892	6906136			
Swap:	10993656	0	10993656			
Total:	19058684	6617940	12440744			

	total	used	free	shared	buffers	cached
Mem:	8065028	6618328	1446700	0	347384	5111712
-/+ buffers/cache:		1159232	6905796			
Swap:	10993656	0	10993656			
Total:	19058684	6618328	12440356			

	total	used	free	shared	buffers	cached
Mem:	8065028	6618320	1446708	0	347384	5111716
-/+ buffers/cache:		1159220	6905808			
Swap:	10993656	0	10993656			
Total:	19058684	6618320	12440364			

	total	used	free	shared	buffers	cached
Mem:	8065028	6618320	1446708	0	347384	5111716
-/+ buffers/cache:		1159220	6905808			
Swap:	10993656	0	10993656			
Total:	19058684	6618320	12440364			

	total	used	free	shared	buffers	cached
Mem:	8065028	6618304	1446724	0	347384	5111716
-/+ buffers/cache:		1159204	6905824			
Swap:	10993656	0	10993656			
Total:	19058684	6618304	12440380			

	total	used	free	shared	buffers	cached
Mem:	8065028	6618148	1446880	0	347384	5111712
-/+ buffers/cache:		1159052	6905976			
Swap:	10993656	0	10993656			
Total:	19058684	6618148	12440536			

	total	used	free	shared	buffers	cached
Mem:	8065028	6617636	1447392	0	347384	5111720
-/+ buffers/cache:		1158532	6906496			
Swap:	10993656	0	10993656			
Total:	19058684	6617636	12441048			

	total	used	free	shared	buffers	cached
Mem:	8065028	6617636	1447392	0	347384	5111724
-/+ buffers/cache:		1158528	6906500			
Swap:	10993656	0	10993656			
Total:	19058684	6617636	12441048			

	total	used	free	shared	buffers	cached
Mem:	8065028	6618212	1446816	0	347384	5111724
-/+ buffers/cache:		1159104	6905924			
Swap:	10993656	0	10993656			
Total:	19058684	6618212	12440472			

Monitor > NetBackup

Monitor > NetBackup – Display and control various aspects of backup jobs

SYNOPSIS

```
NetBackup Jobs All
```

```
NetBackup Jobs Failed
```

DESCRIPTION

This command exists under the `Main > Monitor` view. Use this command to display all of the backup jobs that are configured for your appliance or the failed jobs.

Note: This command is available only for a Master appliance.

OPTIONS

```
NetBackup Jobs All
```

Display backup job information.

```
NetBackup Jobs Failed
```

Display the failed backup job IDs.

See [“About NetBackup Appliance Shell Menu usage”](#) on page 11.

Monitor > NetworkStatus

Monitor > NetworkStatus – Displays the network statistics for the appliance.

SYNOPSIS

NetworkStatus

DESCRIPTION

Use this command to view network statistics for the appliance.

OPTIONS

Use this command to view the network statistics for the appliance.

EXAMPLES

The following example display information that is displayed when you run the Main > Manage > NetworkStatus command.

```
abc123.Monitor> NetworkStatus
```

eth0		eth1		eth2		eth3	
KB/s in	KB/s out	KB/s in	KB/s out	KB/s in	KB/s out	KB/s in	KB/s out
0.00	0.00	0.00	0.00	18.27	0.42	0.00	0.00
0.00	0.00	0.00	0.00	19.11	0.26	0.00	0.00
0.00	0.00	0.00	0.00	5.40	0.26	0.00	0.00
0.00	0.00	0.00	0.00	14.69	0.26	0.00	0.00
0.00	0.00	0.00	0.00	11.07	0.26	0.00	0.00
0.00	0.00	0.00	0.00	21.99	0.26	0.00	0.00
0.00	0.00	0.00	0.00	15.97	0.26	0.00	0.00
0.00	0.00	0.00	0.00	22.95	0.26	0.00	0.00
0.00	0.00	0.00	0.00	7.91	0.26	0.00	0.00
0.00	0.00	0.00	0.00	15.99	0.26	0.00	0.00
0.00	0.00	0.00	0.00	16.54	0.58	0.00	0.00
0.00	0.00	0.00	0.00	10.63	0.26	0.00	0.00
0.00	0.00	0.00	0.00	4.43	0.26	0.00	0.00
0.00	0.00	0.00	0.00	16.60	0.26	0.00	0.00

See [“About the NetBackup Appliance Shell Menu”](#) on page 12.

Monitor > SDCS

`Monitor > SDCS` – Configure and monitor Symantec Data Center Security (SDCS) for the appliance.

SYNOPSIS

`Audit`

`ServerInfo`

DESCRIPTION

Use this command to monitor Symantec Data Center Security (SDCS) events and configuration on the appliance.

OPTIONS

The following commands and options are available under `Monitor > SDCS`:

`Audit`

Search, filter, and edit the retention settings of the SDCS audit log.

- Use the `Audit Search <search_string>` command to search the audit log for the specified string. Use quotation marks if your search string contains multiple words.
- Use the `Audit SetSettings FileNumber <file_number>` command to set the number of of SDCS audit files that are maintained.
- Use the `Audit SetSettings RetentionPeriod <days>` command to set the number of days that the audit files are maintained.
- Use the `Audit ShowSettings` command to view the retention period (days) of the audit files.
- Use the `Audit View` command and options to filter and display the audit log based on available criteria.
 - `Audit View Date <mm/dd/yyyy[-hh:mm:ss]>`
View audit records using the `FromDate` to `ToDate` parameters. If `FromDate` is omitted, it equals `ToDate` with `hh:mm:ss` set to zeroes.
 - `Audit View EventID <ID#>`
Retrieve the detailed view of the audit record that contains the given event ID.

- `Audit View EventType <event_code>`
Retrieve the audit records that match the given event type. Each event type is represented by a four-letter code that appears in the SDCS audit log. You can view the available codes using the `Audit View EventTypeCodes` command.
- `Audit View EventTypeCodes`
Display the event type codes that can be used with the `Audit View EventType` command, along with a brief description of each code.
- `Audit View Filter <criteria>`
View the audit records that match the filter criteria.
- `Audit View Severity <severity_code>`
Retrieve the audit records that match the given severity. Each event is represented by a one-letter code that appears in the SDCS audit log. You can view the available codes using the `Audit View SeverityCodes` command.
- `Audit View SeverityCodes`
Display the severity codes that can be used with the `Audit View Severity` command, along with a brief description of each code.

`ServerInfo`

Set and display SDCS server information to make the appliance a managed agent.

- Use the `ServerInfo GetServerCert <hostname> <port>` command to get an SDCS server certificate. The `<hostname>` parameter is the fully qualified domain name of the SDCS server. The port is the port number of the SDCS server. The default port is 443.
- Use the `SDCS > ServerInfo Set` command to define the SDCS server information to make the appliance a managed agent.
- Use the `SDCS > ServerInfo Show` command to display the SDCS management server configuration.

Monitor > Top

Monitor > Top – Display the top process information.

SYNOPSIS

Top

DESCRIPTION

This command exists under the `Main > Monitor` view. You can use this command to view the top process information.

OPTIONS

Top

Use to display the top process information.

EXAMPLES

The following is an example of process information that is displayed for the `Main > Monitor > Top` command.

```
abc123.Monitor> Top
top - 10:44:02 up 1 day, 23:05,  5 users,  load average: 0.01, 0.03, 0.05
Tasks: 576 total,   1 running, 575 sleeping,   0 stopped,   0 zombie
CPU(s):  0.1%us,   0.2%sy,   0.0%ni, 99.7%id,   0.0%wa,   0.0%hi,   0.0%si,   0.0%st
Mem:    128636M total,    9053M used,    119583M free,     251M buffers
Swap:    66671M total,       0M used,    66671M free,    2762M cached
```

PID	USER	PR	NI	VIRT	RES	SHR	S	%CPU	%MEM	TIME+	COMMAND
58718	root	20	0	1315m	43m	11m	S	1	0.0	21:11.19	nbappdbsrv
119378	root	20	0	9176	1604	868	R	1	0.0	0:00.12	top
60796	root	20	0	490m	42m	25m	S	1	0.0	3:37.96	nbsl
1937	root	20	0	0	0	0	S	0	0.0	0:01.33	kdmflush
2046	root	20	0	0	0	0	S	0	0.0	0:06.31	flush-253:9
4285	root	39	19	0	0	0	S	0	0.0	11:14.74	kipmi0
11254	root	20	0	9268	964	476	S	0	0.0	1:49.97	irqbalance
57836	root	20	0	63.3g	84m	9.9m	S	0	0.1	34:30.40	NB_dbsrv
57892	root	20	0	652m	21m	12m	S	0	0.0	1:06.68	nbevtmgr

Monitor > Uptime

`Monitor > Uptime` – Display the uptime statistics for the current host.

SYNOPSIS

`Uptime`

DESCRIPTION

Use this command to display the uptime statistics for the current host.

OPTIONS

`Uptime`

Display the uptime statistics for the current host.

See [“About NetBackup Appliance Shell Menu usage”](#) on page 11.

Monitor > Who

Monitor > Who – Display current logon sessions on the current host.

SYNOPSIS

Who

DESCRIPTION

Use this command to display current logon sessions on the current host.

OPTIONS

Who

Display current logon sessions on the current host.

EXAMPLES

The following is an example of information that is displayed when you run the Main > Monitor > Who command.

```
abc123.Monitor> Who
 10:44:37 up 1 day, 23:05,  5 users,  load average: 0.01, 0.02, 0.05
USER      TTY      LOGIN@  IDLE   JCPU   PCPU WHAT
admin     tty1     Mon11   46:59m 0.11s  0.01s login -- admin
admin     pts/0    Mon11   46:41m 0.09s  0.18s sshd: admin [priv]
admin     pts/1    Mon12   46:40m 0.11s  0.18s sshd: admin [priv]
admin     pts/2    09:43   1:01m  0.11s  0.02s sshd: admin [priv]
admin     pts/3    10:17   0.00s  0.14s  0.01s sshd: admin [priv]
```

See [“About NetBackup Appliance Shell Menu usage”](#) on page 11.

Main > Monitor > Hardware view commands

This appendix includes the following topics:

- [Monitor > Hardware ShowComponents](#)
- [Monitor > Hardware ShowErrors](#)
- [Monitor > Hardware ShowHealth](#)
- [Monitor > Hardware ShowPreviousRun](#)
- [Monitor > Hardware ShowPreviousRunErrors](#)

Monitor > Hardware ShowComponents

Monitor > Hardware ShowComponents – Use this command to display the hardware components of an appliance.

SYNOPSIS

ShowComponents

DESCRIPTION

This command displays the appliance hardware components, such as the appliance and the 52xx storage shelf or the 5330 primary storage shelf, and the items that are associated with these components.

The fan, disk, temperature, etc. are the items that are associated with the components.

OPTIONS

ShowComponents

Use this command to display all the hardware components and items of an appliance.

EXAMPLES

The following is an example of the information that is displayed when you run the Main > Monitor > Hardware ShowComponents command.

-----+		
Component		Item
-----+-----		
Appliance	fan,cpu,disk,fibrechannel,...,firmware,connection,partition,storagestatus	
+-----+		
-----+		
Component	IDs	Item
-----+-----		
Primary Storage Shelf	99 disk,network,fan,...,volume,raid,product,connection	
+-----+		
-----+		
Component	IDs	Item
-----+-----		

Monitor > Hardware ShowErrors

`Monitor > Hardware ShowErrors` – Use this command to view the errors that are related to the hardware components.

SYNOPSIS

`ShowErrors`

DESCRIPTION

Use this command to view the errors that are related to the hardware components of an appliance. You can use this information to acknowledge errors, or clear the acknowledge errors, or to notify Veritas Technical Support of the errors.

OPTIONS

`ShowErrors`

This command displays all the errors that are related to hardware status.

EXAMPLES

When you run the `Main > Monitor > Hardware ShowErrors` command, the following information is displayed.

Node abc123

Time Monitoring Ran: Wed Aug 1 07:11:49 2012

Power Supply Information						
ID	Status	Wattage	HighWaterMark	State	Acknowledge	
2	Failure detected	0.00 Watts	920.00 Watts	Warning	No	

See [“About the commands under the Manage view”](#) on page 16.

See [“About the NetBackup Appliance Shell Menu”](#) on page 12.

Monitor > Hardware ShowHealth

Monitor > Hardware ShowHealth — Use this command to view the health of various hardware components.

SYNOPSIS

```
ShowHealth Appliance [Item]
ShowHealth StorageShelf [Item]
ShowHealth PrimaryShelf [Item]
ShowHealth ExpansionShelf [ExpansionShelfID] [Item]
```

DESCRIPTION

This command displays the performance and status of various hardware components of the appliance and the attached storage.

OPTIONS

```
ShowHealth Appliance [Item]
```

Use this command to view the performance and status of various hardware components of the appliance, where [Item] defines the name of the hardware part for which the data is queried. You can select any of the following options for the [Item] parameter:

For a 52xx appliance:

```
(All/Fan/CPU/Disk/Fibrechannel/RAID/Power/Temperature/Product/
PCI/Network/Firmware/Adapter/Partition/MSDP) [all]
```

For a 5330 appliance:

```
(All/Fan/CPU/Disk/Fibrechannel/RAID/Power/Temperature/Product/
PCI/Network/Firmware/Connection/StorageStatus/Partition) [all]
```

```
ShowHealth StorageShelf [Item]
```

Use this command to view the performance and status of various hardware components of the storage shelf that is attached to a 52xx appliance. Here, [Item] defines the name of the hardware part for which the data is queried. You can select any of the following options for the [Item] parameter:

```
(All/Fan/Disk/Power/Temperature/Product) [all]
```

Note: The [Item] parameter is optional. If you do not enter a value for the [Item] parameter, the data is displayed for all of the items that are associated with the hardware component.

The following commands options are available only for a 5330 appliance.

ShowHealth PrimaryShelf [Item]

Use this command to view the performance and status of the primary storage shelf of the NetBackup 5330. You can select any of the following options for the [Item] parameter:

(All/Fan/Disk/RAID/Power/Temperature/Product/Firmware/BBU/Controller/Volume/Connection)
[all]

ShowHealth ExpansionShelf [ExpansionShelfID] [Item]

Use this command to view the performance and status of all or specific expansion storage shelf unit that is attached to a 5330 appliance.

Where [ExpansionShelfID] is the ID of a specific expansion shelf. To check the expansion shelf IDs, use Main > Monitor > Hardware ShowComponents command.

Note: The [ExpansionShelfID] parameter is optional. If you do not enter a value for the [ExpansionShelfID] parameter, the data is displayed for all the storage shelves.

You can select any of the following options for the [Item] parameter:

(All/Fan/Disk/Power/Temperature/Product) [all]

Note: The [Item] parameter is optional. If you do not enter a value for the [Item] parameter, the data is displayed for all of the items that are associated with the hardware component.

ShowHealth Appliance Partition ExportCSV

Use the command to export the status of all the partitions on an appliance. Follow the instructions on the Shell Menu to find the CSV file for more details.

EXAMPLES

The following is an example of the information that is displayed when you run the Main > Monitor > Hardware ShowHealth Appliance Disk command, where *Disk* is the value for the [Item] parameter.

Disk Information											
ID	Slot	Status	Foreign	HotSpare	Firmware	Serial	Capacity	Type	Enclosure	State	
Number			State	Type	Version	Number			ID		
- 0		Online, Spun Up	None	N/A	0003	Z1W0SFWZ	931.51GB	SAS	252	OK	
- 0		Online, Spun Up	None	N/A	0003	Z1W0SFCP	931.51GB	SAS	65535	OK	
- 1		Online, Spun Up	None	N/A	0003	Z1W0SHZ5	931.51GB	SAS	252	OK	
- 1		Online, Spun Up	None	N/A	0003	Z1W0SGLY	931.51GB	SAS	65535	OK	
- 2		Online, Spun Up	None	N/A	0003	Z1W0SGAL	931.51GB	SAS	252	OK	
- 3		Online, Spun Up	None	N/A	0003	Z1W0SF57	931.51GB	SAS	252	OK	
- 4		Online, Spun Up	None	N/A	0003	Z1W0SG41	931.51GB	SAS	252	OK	
- 5		Online, Spun Up	None	N/A	0003	Z1W0SF9Z	931.51GB	SAS	252	OK	
- 6		Online, Spun Up	None	N/A	0003	Z1W0SFQJ	931.51GB	SAS	252	OK	
- 7		Hot Spare, Spun Down	None	Global	0003	Z1W0SFTV	931.51GB	SAS	252	OK	

The following is an example of the information that is displayed when you run the Main > Monitor > Hardware ShowHealth Appliance Adapter command, where *Adapter* is the value for the [Item] parameter.

```
Adapters and BBU Information
+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
|ID|Adapter|Adapter|BBU|Rebuild|BBU Learn|Charge|Charging|Voltage|Temp|Mfg. |State||
|Model|Status|Status|Rate %|Cycle|Active| | | | | |Date|
+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
|-|Intel(R)
RAID
Controller
RS25SB008|OK|OK|30|No|283|None|9405|31|2012-|OK
| |06-15
+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
|-|Intel(R)
Integrated
RAID
Module
RMS25CB080|OK|OK|100|No|314|None|9483|33|2013-|OK
| |03-23
+-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
```

The following is an example of the information that is displayed when you run the Main > Monitor > Hardware ShowHealth Appliance [Partition] command, where *Partition* is the value for the [Item] parameter.

```
+-----+
|
| Partition Information
|
+-----+
|ID|Partition|Total|Used|Status|State|Acknowledge|
|---+-----+-----+-----+-----+-----+-----|
|1|MSDP|982.0 GB|1 % *|Optimal|OK|N/A|
|---+-----+-----+-----+-----+-----+-----|
|2|Configuration|25 GB|2 %|Optimal|OK|N/A|
|---+-----+-----+-----+-----+-----+-----|
|3|AdvancedDisk|1 TB|1 %|Optimal|OK|N/A|
|---+-----+-----+-----+-----+-----+-----|
|4|System|92 GB|8 %|Optimal|OK|N/A|
|---+-----+-----+-----+-----+-----+-----|
|5|Log|367 GB|2 %|Optimal|OK|N/A|
|---+-----+-----+-----+-----+-----+-----|
|
| * The value displayed here may be different from the backup space|
| that is available or used on the MSDP partition. The backup space|
| MSDP partition can be obtained by checking the MSDP disk pool |
| sizes from statistics for the NetBackup Administration Console. |
|
```



```
|+-----+|
+-----+
```

To determine the serial number of your appliance, run the `Monitor > Hardware ShowHealth Appliance [Product]` command, where `[Product]` is the value for the `[Item]` parameter.

```
abc123.Monitor> Hardware ShowHealth Appliance
```

```
Hardware ShowHealth Appliance [Item]
Show Appliance Hardware Health.
```

```
Item    Appliance items to query for data.
```

```
(All/Fan/CPU/Disk/Fibrechannel/RAID/Power/Temperature/Product/
PCI/Network/.../MSDP) [all]
```

```
abc123.Monitor> Hardware ShowHealth Appliance Product
```

Gathering hardware information. It might take about a minute...

```
Compute Node abc123.engba.symantec.com
```

```
Time Monitoring Ran: Thu Mar 21 2013 04:47:09 PDT
```

```
Node does not have any errors.
```

```
+-----+
|                                     |
|               Hardware monitor information               |
|+-----+
||               name               | manufacturer         | serial           ||
||-----+-----+-----+-----+-----+-----+-----+
||NetBackup 5230                    |Symantec              |abc123serno      ||
|+-----+
+-----+
```

The following examples are for the command options available for a 5330 appliance.

The following is an example of the information that is displayed when you run the `Main > Monitor > Hardware ShowHealth PrimaryShelf [Controller]` command, where *Controller* is the value for the `[Item]` parameter.

Node abc122

Time Monitoring Ran: Thu Mar 27 2014 07:17:52

Compute node does not have any errors.

Primary Storage Shelf Controller Information								
ID	Location	Data Cache	Controller	NVSRAM Firmware	Status	State	Acknowledge	
1	Tray 99	8192 MB/	08.10.03.00	N5501-810898-403	Online	OK	N/A	
	Slot A	10240 MB						
2	Tray 99	8192 MB/	08.10.03.00	N5501-810898-403	Online	OK	N/A	
	Slot B	10240 MB						

The following is an example of the information that is displayed when you run the Main > Monitor > Hardware ShowHealth ExpansionShelf [1] [Fan] command, where 1 is the value for the [ExpansionShelfID] parameter, and Fan is the value for the [Item] parameter.

Node abc122

Time Monitoring Ran: Thu Mar 27 2014 07:20:43

Compute node does not have any errors.

Expansion Storage Shelf 1 Fan Information				
ID	Location	Status	State	Acknowledge
1	Tray 1 Right	Optimal	OK	N/A
2	Tray 1 Left	Optimal	OK	N/A
3	Tray 1 Right	Optimal	OK	N/A
4	Tray 1 Left	Optimal	OK	N/A

```
|+-----+|
+-----+
```

The following is an example of the information that is displayed when you run the `Main > Monitor > Hardware ShowHealth StorageShelf [Fan]` command on a 52xx appliance where *Fan* is the value for the [Item] parameter.

Compute Node nb-appliance

Time Monitoring Ran: Wed Mar 09 2016 13:23:09 PST

```
+-----+
|
|           StorageShelf 1 Fan Information
|+-----+-----+-----+-----+-----+-----+
|| ID | Name                | Status | Speed | Low Watermark | State |
|+-----+-----+-----+-----+-----+-----+
|| 1  | Enclosure 32 Fan 0 | OK     | -     | -             | OK    |
|+-----+-----+-----+-----+-----+-----+
|| 2  | Enclosure 32 Fan 1 | OK     | -     | -             | OK    |
|+-----+-----+-----+-----+-----+-----+
|| 3  | Enclosure 32 Fan 2 | OK     | -     | -             | OK    |
|+-----+-----+-----+-----+-----+-----+
|| 4  | Enclosure 32 Fan 3 | OK     | -     | -             | OK    |
|+-----+-----+-----+-----+-----+-----+
|
|
+-----+
+-----+
|
|           StorageShelf 2 Fan Information
|+-----+-----+-----+-----+-----+-----+
|| ID | Name                | Status | Speed | Low Watermark | State |
|+-----+-----+-----+-----+-----+-----+
|| 1  | Enclosure 28 Fan 0 | OK     | -     | -             | OK    |
|+-----+-----+-----+-----+-----+-----+
|| 2  | Enclosure 28 Fan 1 | OK     | -     | -             | OK    |
|+-----+-----+-----+-----+-----+-----+
|| 3  | Enclosure 28 Fan 2 | OK     | -     | -             | OK    |
|+-----+-----+-----+-----+-----+-----+
|| 4  | Enclosure 28 Fan 3 | OK     | -     | -             | OK    |
|+-----+-----+-----+-----+-----+-----+
|
|
+-----+
```

Monitor > Hardware ShowPreviousRun

Monitor > Hardware ShowPreviousRun – Use this command to display hardware status information from the previous scheduled run.

SYNOPSIS

ShowPreviousRun

DESCRIPTION

This command displays information about the hardware status from the previous scheduled run. The information includes the timestamp that helps you determine the exact date and time of the previous scheduled run.

OPTIONS

ShowPreviousRun

Use this command to display hardware status information from the previous scheduled run.

EXAMPLES

The following is an example of the information that is displayed when you run the Main > Monitor > Hardware ShowPreviousRun command.

Node abc123

Time Monitoring Ran: Wed Aug 1 07:09:02 2012

-----+ Hardware monitor information -----+ manufacturer serial -----+ Symantec abc123serno -----+ Firmware Information -----+ ID Name Version ---+-----+ 1 BIOS SE5C600.86B.01.02.0006.032920121341 ---+-----+ 2 Intel_X520 0x61c10001 			
---	--	--	--

Disk Information										
ID	Slot	Status	Foreign	Serial	Capacity	Type	Enclosure	State	Acknowledge	
	Number		State	Number			ID			
1	0	Online, Spun Up	None	0002Z1P13ZCF	1.817TB	SAS	99	OK	N/A	
2	1	Online, Spun Up	None	0002Z1P1453W	1.817TB	SAS	99	OK	N/A	
RAID Information										
ID	Name	Status	Capacity	Type	Disks	Write	Enclosure	HotSpare	State	Acknowledge
						Policy	ID	Available		
1	VD-0	Optimal	1.817TB	RAID-1	0 1	WriteBack	99	no	OK	N/A
Fan Information										
ID	Status	Speed	LowWaterMark	State	Acknowledge					
1	OK	5292.00 RPM	1715.00 RPM	OK	N/A					
2	OK	5390.00 RPM	1715.00 RPM	OK	N/A					
3	OK	5292.00 RPM	1715.00 RPM	OK	N/A					
4	OK	5341.00 RPM	1715.00 RPM	OK	N/A					
5	OK	5292.00 RPM	1715.00 RPM	OK	N/A					

See [“About the commands under the Manage view”](#) on page 16.

See [“About the NetBackup Appliance Shell Menu”](#) on page 12.

Monitor > Hardware ShowPreviousRunErrors

Monitor > Hardware ShowPreviousRunErrors – Use this command to display hardware-related errors from the previous run.

SYNOPSIS

ShowPreviousRunErrors

DESCRIPTION

This command displays all the hardware-specific errors that occurred from the previous run. This information might help you in determining whether you encounter a particular error frequently and report it to Veritas Technical Support.

OPTIONS

ShowPreviousRunErrors

Use this command to view the hardware health errors from the previous run.

EXAMPLES

The following is an example of the information that is displayed when you run the Main > Monitor > Hardware ShowPreviousRunErrors command.

Compute Node abc123

Time Monitoring Ran: Fri May 2 2014 18:15:08 UTC

Power Supply Information						
ID	Status	Wattage	HighWaterMark	State	Acknowledge	
2	Power Supply AC lost	0.00 Watts	920.00 Watts	Warning	No	

Main > Network view commands

This appendix includes the following topics:

- [Network > Configure](#)
- [Network > Date](#)
- [Network > DNS](#)
- [Network > Gateway](#)
- [Network > Hostname](#)
- [Network > Hosts](#)
- [Network > IPv4](#)
- [Network > IPv6](#)
- [Network > LinkAggregation](#)
- [Network > NetStat](#)
- [Network > NTPServer](#)
- [Network > Ping](#)
- [Network > SetProperty](#)
- [Network > Show](#)
- [Network > TimeZone](#)
- [Network > TraceRoute](#)

- [Network > Unconfigure](#)
- [Network > VLAN](#)
- [Network > WANOptimization](#)

Network > Configure

`Network > Configure` – Use to configure the NetBackup appliance to a network.

SYNOPSIS

```
Configure IPAddress Netmask GatewayIPAddress [InterfaceNames]  
[BondingMode]
```

DESCRIPTION

During the initial configuration of the appliance, you can use the `Configure` command to configure the IP address of a single interface on the network that you want to connect your appliance to. After the initial configuration, you can use this command to change the IP address and connect your appliance to a different network. When you use this command, you need to define the IP address, the netmask address, and the gateway address. If multiple interfaces with separate IP addresses are used, use the `Network > IPv4` or the `Network > IPv6` commands to configure each network interface individually.

Use the `Network > Gateway` command to add the routing information for default route or to add route for VLAN interfaces.

OPTIONS

```
Configure IPAddress Netmask GatewayIPAddress [dev]
```

You can use this command to configure the IP address and default gateway for the appliance. The command configures the IP address and sets the default gateway.

Where *IPAddress* is the IPv4 or IPv6 address, *Netmask* is the netmask, *GatewayIPAddress* is the default gateway IP address, and [*dev*] is the name of the device.

This device can be a physical interface, or a bond, or a VLAN interface.

Remember that you should not use both IPv4 and IPv6 address in the same command. For example, you cannot use `Configure 9ffe::9 255.255.255.0 1.1.1.1..` You should use `Configure 9ffe::46 64 9ffe::49 eth1` to configure an interface using IPv6 address.

In the [*InterfaceNames*] field the following applies:

- If you enter a single interface name, then the IP address is configured on that device.

- If you enter a comma-separated list of interface names, then a bond is created and the IP address is configured on the bonded device. You must ensure that the interfaces that comprise the list are of same type, either **FIBRE** or **COPPER**). In addition, the interfaces must support the same speed and at least one of the interfaces in the list is cabled.
- If you do not enter an interface name, the best possible interface or interfaces are selected based on the port type (**FIBRE** or **COPPER**), speed, and the link status.

You define the bonding mode in the `BondingMode` field. You can enter one of the following modes:

- `balance-rr`
- `active-backup`
- `balance-xor`
- `broadcast`
- `802.3ad`
- `balance-tlb`
- `balance-alb` (This bonding mode is the default value.)

EXAMPLES

The following examples show how to configure your appliance using the Auto selection, specifying a specific interface, or multiple interfacing and creating a bond.

- Specify explicit interfaces such as `eth2` and `eth3` to create a bond. For this example, you provide the IPAddress, NetMask, Gateway IPAddress, interface names, and the bonding mode, in that order.

```
Network > Configure 10.180.2.3 255.255.255.0 eth2, eth3 balance-alb
```

You can also create a bond and configure it using IPv6 addresses:

```
Network > Configure 9ffe::207 64 9ffe::49 eth,eth3
```

See [“About NetBackup Appliance Shell Menu usage”](#) on page 11.

Network > Date

Network > Date – Use to set or show the computer system time.

SYNOPSIS

Date Set *Month Day HHMMSS Year*

Date Show

DESCRIPTION

You can use this command to set or show the system time.

OPTIONS

Date Set *Month Day HHMMSS Year*

Use this command to set the system time.

Where *Month* is the name of the month. *Day* is the day of the month and has a range of zero to 31. The variable *HHMMSS* is the hour, minute, and seconds in a 24-hour format and the fields are separated by semi-colons, for example, HH:MM:SS. The variable *Year* is the current year and the range for this field is 1970 through 2037.

The following is sample entry for this command:

Date Set Apr 29 23:44:34 2011

Date Show

Use this command to show the system date and time.

See [“About NetBackup Appliance Shell Menu usage”](#) on page 11.

Network > DNS

Network > DNS – Use to configure the DNS information for the appliance.

SYNOPSIS

```
DNS Add NameServer IPAddress
DNS Add SearchDomain DomainName
DNS Delete Domain
DNS Delete NameServer IPAddress
DNS Delete SearchDomain DomainName
DNS Domain Name
DNS Show
```

DESCRIPTION

You can use this command to perform the following tasks:

- Add or delete a name server to the DNS configuration.
- Add or delete a domain name to the DNS search list.
- Set the appliance DNS domain name.
- Show the current DNS information.

OPTIONS

```
DNS Add NameServer IPAddress
```

Use to add a DNS nameserver to the DNS configuration.

Where *IPAddress* is the IP address of the DNS name server.

```
DNS Add SearchDomain DomainName
```

Use to add a DNS search domain to the configuration.

Where *DomainName* is the target domain to add for searching.

```
DNS Delete Domain
```

Use to delete a DNS domain name.

```
DNS Delete NameServer IPAddress
```

Use to delete a DNS named server from the configuration.

Where *IPAddress* is the IP address of the DNS name server.

DNS Delete SearchDomain *DomainName*

Use to delete a DNS search domain from the configuration.

Where *IPAddress* is the IP address of the DNS name server.

DNS Domain *Name*

Use this command to set the appliance domain name, where *Name* is the domain name of the appliance

DNS Show

Use to show the current DNS information.

See [“About NetBackup Appliance Shell Menu usage”](#) on page 11.

Network > Gateway

Network > Gateway — Use this command to add or delete routing information.

SYNOPSIS

```
Gateway Add GatewayIPAddress [TargetNetworkIPAddress] [Netmask]  
[InterfaceName]
```

```
Gateway Delete TargetNetworkIPAddress
```

```
Gateway Show [IPVersion]
```

DESCRIPTION

Use this command to add or delete a route from the kernel routing table. With this command you can also view the kernel routing table. Refer to Linux route man page for more advanced use cases.

With this command you can define the IPv4 or IPv6 address that you plan to add or delete as well as display the current gateway information. If multiple networks are added to the appliance configuration, you can use the Gateway Add command to add the gateway to all of the destination networks.

Remember that you should not use both IPv4 and IPv6 address in the same command. For example, you cannot use `Gateway Add 9ffe::3 255.255.255.0 eth1`. You should use `Gateway Add 9ffe::3 6ffe:: 64 eth1`.

OPTIONS

```
Gateway Add GatewayIPAddress [TargetNetworkIPAddress] [Netmask]  
[InterfaceName]
```

Use this command to add a route to a kernel routing table.

Where the *GatewayIPAddress* variable is the new IPv4 or IPv6 gateway address. The *TargetNetworkIPAddress* is the target network IPv4 or IPv6 address. The *Netmask* variable is the target network netmask, and *InterfaceName* is the interface name. The *TargetNetworkIPAddress*, *Netmask*, and *InterfaceName* are optional when you set up the default gateway. After the default gateway has been added, you must use these fields to add any additional gateways

```
Gateway Delete TargetNetworkIPAddress
```

Use this command to delete the route from the kernel routing table.

Where *TargetNetworkIPAddress* is the target network address.

Gateway Show [IPVersion]

Use to display the gateway and the route information. Here, [IPVersion] parameter is an optional parameter. It defines the IP protocols - IPv4 and IPv6. If you do not enter a value for the [IPVersion] parameter, the information is displayed for IPv4.

To know the gateway information for a VLAN interface, enter the VLAN interface ID for the [IPVersion] parameter.

EXAMPLE

Use the following example to set the default gateway.

```
Gateway Add 10.180.1.1
```

Use the following example to add a route to the destination network 192.168.2.0.

```
Gateway Add 191.168.2.1 192.168.2.0 255.255.255.0
```

```
Gateway Add 9ffe::49 6ffe:: 64 eth1
```

Use the following example to delete the default gateway.

```
Gateway Del default
```

Use the following example to delete a route to the destination network, 10.180.0.0 or 6ffe::/64.

```
Gateway Delete 10.180.0.0
```

```
Gateway Delete 6ffe::/64
```

See [“About NetBackup Appliance Shell Menu usage”](#) on page 11.

Network > Hostname

Network > Hostname – Use to set or show the hostname for your appliance.

SYNOPSIS

Hostname Set *Name*

Hostname Show

DESCRIPTION

You can use this command to set the host name of the appliance.

OPTIONS

Hostname Set *Name*

Set the host name.

The *Name* variable contains the short host name or the fully qualified domain name (FQDN) of the host.

Note: The host name can only be set during an initial configuration session. After the initial configuration has completed successfully, you can re-enter initial configuration by performing a factory reset on the appliance. See the *NetBackup Appliance Administrator's Guide* for more information.

Hostname Show

Display the host name.

See [“About NetBackup Appliance Shell Menu usage”](#) on page 11.

Network > Hosts

Network > Hosts – Use to manage the IP address and host name mapping.

SYNOPSIS

```
Hosts Add IPAddress FQHN ShortName
```

```
Hosts Delete IPAddress
```

```
Hosts Show
```

DESCRIPTION

You can use this command to view the hosts configuration information, such as the IP address and host name mapping. You can also use this command to add or delete an IP address from the hosts file.

OPTIONS

```
Hosts Add IPAddress FQHN ShortName
```

Use to add a IP address to the host name mapping.

IPAddress is the IPv4 or IPv6 address to add.

FQHN is the fully qualified host name. And *ShortName* is the short host name.

```
Hosts Delete IPAddress
```

Use to delete IP address to the host name mapping.

IPAddress is the IPv4 or IPv6 address to add.

```
Hosts Show
```

Use to display the IP address and host name mapping.

Network > IPv4

`Network > IPv4` – Use to change the IPv4 address of a network interface.

SYNOPSIS

```
IPv4 IPAddress NetMask [InterfaceNames]
```

DESCRIPTION

Use this command to change the IPv4 address of a network interface. You can use this command to configure multiple network interfaces. To do that, you repeat the command for each network that you want to add.

OPTIONS

```
IPv4 IPAddress NetMask [InterfaceNames]
```

Use to change the IPv4 address of a network interface.

Where *IPAddress* is the name of the new IPv4 address. The *NetMask* variable is the name of the netmask. The [*InterfaceNames*] parameter is a comma-separated list of interface names. The [*InterfaceNames*] field is optional. If an interface name is not provided, the command searches for an interface and configures it.

You may enter a VLAN interface ID for the [*InterfaceNames*] parameter. However, unlike the physical interface or bond interface, if you do not provide a value for the for the [*InterfaceNames*] parameter, the command does not search for VLAN interfaces.

Network > IPv6

Network > IPv6 – Use to add IPv6 address without specifying a gateway address.

SYNOPSIS

```
IPv6 IP Address Prefix [InterfaceNames]
```

DESCRIPTION

Use this command to configure the IPv6 address of a network interface. You cannot use this command to configure multiple interfaces.

OPTIONS

```
IPv6 IPAddressPrefix [InterfaceNames]
```

Use to change the IPv6 address of a network interface.

Where *IPAddress* is the IPv6 address, *Prefix* is the prefix length, and [*InterfaceNames*] is the name of the device.

The [*InterfaceNames*] parameter is a comma-separated list of interface names. The [*InterfaceNames*] parameter is an optional field. If an interface name is not provided, the command searches for an interface and configures it.

You may enter a VLAN interface ID for the [*InterfaceNames*] parameter. However, unlike the physical interface or bond interface, if you do not provide a value for the for the [*InterfaceNames*] parameter, the command does not search for VLAN interfaces.

EXAMPLES

Use the following example to assign an IPv6 address to a specific interface:

```
IPv6 9ffe::9 64 eth1
```

Use the following example to create a bond when multiple interfaces are given:

```
IPv6 9ffe::9 64 eth2,eth3
```

Network > LinkAggregation

Network > LinkAggregation – Use to manage link aggregation.

SYNOPSIS

```
LinkAggregation Create Slaves [BondingMode]  
LinkAggregation Delete InterfaceNames  
LinkAggregation Disable [InterfaceName]  
LinkAggregation Enable [Slaves] [BondingMode]  
LinkAggregation Show [InterfaceNames]  
LinkAggregation Status
```

DESCRIPTION

You can use this command to manage link aggregation.

You can use this command to enable bonding (link aggregation), across the available network cards. If only one port is configured, bonding is not available. If multiple ports are configured on your appliance, they are identified automatically.

You have the ability to bond multiple ports or define specific ports to bond by what you enter in the [Slaves] option. To bond multiple ports, you must use a comma to separate the device names. In addition, you should ensure that all of the ports that participate in a bond are connected to the same switch. And make sure that is no additional port configuration is done at the switch.

There are eight different bond modes that you can choose from. Some of the bond modes require additional configuration on the switch or the router. You should take additional care when you select a bond mode.

For more information about the bond modes and any required switch configuration, see the following documentation:

<http://www.kernel.org/doc/Documentation/networking/bonding.txt>

You can also use this command to do the following:

- To create a bond without associating an IP address to it.
- To delete a existing bond.
- To display the status of the link aggregation.
- To show the link aggregation properties of one or more interfaces.

- To turn off the link aggregation.

OPTIONS

`LinkAggregation Create Slaves [BondingMode]`

Use this command to create a bond.

Here, the *Slaves* variable defines the device name that you want to bond and the [BondingMode] parameter is used to define the bond mode in which to configure bonding, or link aggregation. The eight available modes are, balance-rr | active-backup | balance-xor | broadcast | 802.3ad | balance-tlb | balance-alb. The default mode is balance-alb.

Conform to following guidelines to create a bond:

- Ensure that the interfaces that participate in bond formation have the same port speed (i.e. either 1GB or 100GB).
- At least one of the interfaces that participates in bond formation must be plugged.
- Ensure that none of the interfaces that are selected for creating the bond have any VLANs tagged to them.
- Verify that any of the selected interfaces are not, already, a part of another bond.

You can create this bond with or without assigning an IP address to it. The criteria for assigning or not assigning an IP address to the bond depends solely on the interfaces that are selected for creating the bond.

Consider the following two cases to understand IP address assignment to a bond:

- IP address is assigned to a newly created bond, if any of the interfaces that are selected for creating a bond already have an IP address assigned to them.
- IP address is not assigned to a newly created bond, if the interfaces that are selected for creating a bond do not have IP addresses assigned to them. A bond without an IP address associated to it is prerequisite for tagging a VLAN to a bonded interface.

If the selected interfaces are configured with IP addresses, an error message is displayed to indicate that a single interface must be configured with an IP address to create the bond.

Note: You may use the `Create` and `Enable` commands to configure a bond over a private interface, forexample, `eth0`. This option is not available through the NetBackup Appliance Web Console.

`LinkAggregation Delete InterfaceNames`

Use this command to delete a bond. Here, *InterfaceNames* defines the bond device name that you want to disable.

Note: To delete a bond, ensure that the no IP address is configured on the bond. If an IP address is configured to the bond, you must first unconfigure the IP address. To unconfigure the IP address, run the `Network > Unconfigure` command.

`LinkAggregation Disable [InterfaceName]`

Turns off the link aggregation. The `[InterfaceName]` option is optional. You use this option to define the bond device name that you want to disable. You can use the `LinkAggregation > Status` command to obtain the device name.

LinkAggregation cannot be turned-off if there are multiple bonds present. To turn-off link aggregation on a specific bond, you must enter the bond name in the `[InterfaceName]` parameter.

`LinkAggregation Enable [Slaves] [BondingMode]`

Use to turn on link aggregation. This command assigns IP address to the newly created bond.

The `[Slaves]` option defines the device names that you want to bond. Use a comma as a delimiter between the device names. This field is optional. The device names are identified automatically based on the current network settings and properties.

The `[BondingMode]` parameter is used to define the bond mode in which to configure bonding, or link aggregation. The eight available modes are, `balance-rr` | `active-backup` | `balance-xor` | `broadcast` | `802.3ad` | `balance-tlb` | `balance-alb`. The default mode is `balance-alb`.

`LinkAggregation Status [HostName]`

Show the status of the link aggregation. If no interfaces have been configured, the following message appears:

No virtual interfaces have been configured.

`LinkAggregation Show [InterfaceNames]`

Show the link aggregation properties of one or more interfaces.

Use the [InterfaceNames] option to define the interface or interfaces that you want to view the properties of. Use a comma to separate the interface names if you want to view the properties of more than one.

Network > NetStat

Network > NetStat — Identify network statistical information

SYNOPSIS

NetStat a

NetStat an

NetStat ia

NetStat s

DESCRIPTION

This command exists under the `Main_Menu > Network` view. The `NetStat` command displays various network-related information such as network statistical information.

OPTIONS

NetStat a

Examine network connections for all interfaces, textually.

NetStat an

Examine network connections for all interfaces, numerically.

NetStat ia

Examine network interface stats.

NetStat s

Examine network summary stats for all interfaces, numerically.

Network > NTPServer

Network > NTPServer – Use to manage the NTP Servers.

SYNOPSIS

NTPServer Add *Server*

NTPServer Delete *Server*

NTPServer Show

DESCRIPTION

Use this command manage the NTP servers. With this command, you can to do the following:

- Add an NTP server to the sync time.
- Delete an NTP server.
- Show the known NTP Servers.

OPTIONS

NTPServer Add *Server*

Use this command to add an NTP Server. Where *Server* is the name of the server to add.

NTPServer Delete *Server*

Use this command to delete an NTP Server. Where *Server* is the name of the server to delete.

NTPServer Show

Use this command to show the known NTP Servers.

Network > Ping

`Network > Ping` – An attempt to reach a host or IP address with `ICMP ECHO_REQUESTs`

SYNOPSIS

`Ping Host`

DESCRIPTION

This command exists under the `Main_Menu > Network` view. Use this command to test whether a particular host is reachable across an Internet Protocol (IP) network. The command sends a small packet of information to a hostname or an IP address to test network communications. It then provides information on how long the packet took to come back to its origin.

OPTIONS

`Ping Host`

Used to send a small packet of `ICMP ECHO_REQUESTs` to a host name or an IPv4 or IPv6 address of the target computer to test the network communications.

Where *Host* is the hostname or the IPv4 or IPv6 address of the target computer.

Network > SetProperty

Network > SetProperty – Use to set the Ethernet interface property.

SYNOPSIS

```
SetProperty InterfaceName Property Value
```

DESCRIPTION

You can use this command to set Ethernet interface property. You can define the name of the device, the property name such as an MTU. And you can define the property value, such as 1500 for the MTU.

OPTIONS

```
SetProperty InterfaceName Property Value
```

Use this command to set Ethernet interface property.

Enter the name of the interface name in the *InterfaceName* variable. An example of this value is **eth1**. The *Property* variable is the property name, such as **mtu**. The *Value* variable is the property value, for example 1500.

The following is sample entry for this command:

```
SetProperty eth1 mtu 1500
```

This command changes the Maximum transmission unit (MTU) of interface (eth1) to 1500.

See [“About NetBackup Appliance Shell Menu usage”](#) on page 11.

Network > Show

Network > Show – List the network properties.

SYNOPSIS

Show Configuration

Show Properties [InterfaceNames]

Show Status

DESCRIPTION

Use this command to list the network properties.

OPTIONS

Show Configuration

This command displays the network interface properties.

Show Properties [InterfaceNames]

Display the network properties. The *InterfaceNames* option contains the interface names. Interface can be a physical interface, bonded interface, or a VLAN interface. The *InterfaceNames* is an optional parameter. If you enter multiple interface names, separate the names with a comma.

Show Status

Use this command to view the following network status information:

- Device status
- Routing status
- Link aggregation status
- VLAN interface status

Network > TimeZone

Network > TimeZone – Use to set the time zone.

SYNOPSIS

TimeZone Reset

TimeZone Set

TimeZone Show

DESCRIPTION

You can use this command to set time zone for which your appliance is located. You can reset the time zone to the Coordinated Universal Time (UTC) or show the currently configured time zone.

OPTIONS

TimeZone Reset

Use this command to reset the time zone to UTC.

TimeZone Set

Use this command to set the time zone.

TimeZone Show

Use this command to show the currently configured time zone.

Network > TraceRoute

Network > TraceRoute – Displays the network packet route

SYNOPSIS

```
TraceRoute Host
```

DESCRIPTION

This command exists under the `Main_Menu > Network` view. Use this command to display the network path of Internet routers that a packet takes as it travels from the appliance to the destination IP address or host.

OPTIONS

```
TraceRoute Host
```

Display the network route that a packet took to a destination host name or the IPv4 or IPv6 address of the target computer.

Where *Host* is the hostname or the IPv4 or IPv6 address of the target computer.

Network > Unconfigure

`Network > Unconfigure` – Removes the IP address and shuts down the interface.

SYNOPSIS

```
Unconfigure InterfaceNames [IPAddress]
```

DESCRIPTION

Use this command to remove the IP address and shut down the interface.

This network interface can be a physical interface, a bonded interface , or a VLAN interface

OPTIONS

```
Unconfigure InterfaceNames [IPAddress]
```

Use to remove the IP address and shut down the interface. Where *InterfaceNames* is the name of the interface such as a VLAN interface, or a ethernet interface, or a bonded interface. [*IPAddress*] is the IPv4 or IPv6 address. [*IPAddress*] is an optional parameter.

Network > VLAN

`Network > VLAN` – Use the Virtual LAN (VLAN) commands to tag a VLAN, to view its properties and status, or to delete a tagged VLAN.

SYNOPSIS

```
VLAN Delete VLANID
```

```
VLAN Show Properties Interfaces InterfaceNames
```

```
VLAN Show Status Interfaces InterfaceNames
```

```
VLAN Tag VLANID InterfaceNames [IPAddress] [Netmask]
```

DESCRIPTION

Use these commands to configure and manage VLAN for your NetBackup Appliances in your existing network environments.

To tag a VLAN using a bond or a physical interface, conform to the following guidelines

- Ensure that the selected interface or ethernet device is plugged.
- Verify that the selected interface is not a part of a bond.
- The selected interface must not have an IP address configured to it. If the selected interface is configured with an IP address, you must first unconfigure the IP address and then tag a VLAN to it. To unconfigure the IP address, run the `Network > Unconfigure` command.

Note: A VLAN can be tagged to a private network interface (for example, eth0) only through the NetBackup Appliance Shell Menu and not through the NetBackup Appliance Web Console.

Use the `VLAN Show` command options to view the properties and statuses of your network interfaces.

OPTIONS

```
VLAN Delete VLANID
```

Use this command to delete a protocol-based VLAN. Here, *VLANID* is a numeric identifier for a tagged VLAN.

If the VLAN interface is configured with an IP address, you must first unconfigure the IP address to delete the VLAN.

VLAN Show Properties Interfaces *InterfaceNames*

Use this command to view all the properties of a VLAN, where *InterfaceNames* is the name of the interface to which a VLAN is tagged. If you do not provide a value for the [InterfaceNames] parameter, the commands displays properties for all the network interfaces that are available. Some of the properties types that are included are MAC address, speed, and port type.

VLAN Show Status Interfaces *InterfaceNames*

Use this command to view the status of a VLAN. The VLAN status can be *PLUGGED* or *UNPLUGGED*. Here, *InterfaceNames* is the name of the interface to which a VLAN is tagged.

VLAN Tag *VLANID* *InterfaceNames* [IPAddress] [Netmask]

Use this command to tag a VLAN to a physical interface or a bond. Here, *VLANID* is the VLAN identifier, which is numeric value and it can range between 1 - 4094. *InterfaceNames* is the name of the interface to which you want to tag the VLAN. [IPAddress] can be an IPv4 or an IPv6 address and [Netmask] is netmask for IPv4 or prefix length for IPv6. The *VLANID* and *InterfaceNames* are mandatory variable; whereas [IPAddress] and [Netmask] are optional parameters.

EXAMPLES

The following is an example of information that is displayed when you run the `Main > Network > VLAN Show Properties` command.

```
nb-appliance.Network> VLAN Show properties
```

```
Card: vlan12  [  PLUGGED|UP  ]

      BOOTPROTO      : |static          |
      DESCRIPTION    : |test          |
      DEVICE         : |vlan12        |
      ETHERDEVICE     : |eth4          |
      ETHTOOL_OPTIONS : |undef         |
      IPADDR         : |10.10.10.10   |
      MTU            : |1400          |
      NETMASK        : |255.255.255.0 |
      NETWORK        : |undef         |
      REMOTE_IPADDR   : |undef         |
      STARTMODE      : |auto          |
      USERCONTROL    : |no            |
      VLAN           : |yes           |
      BUS_ID         : |undef         |
```

FLAGS	:	RBMU	
ID	:	12	
LINK	:	yes	
MAC	:	00:50:56:B5:74:13	
MASTER	:	undef	
MODEL	:	undef	
PORT_TYPE	:	Twisted Pair	
SERIAL	:	undef	
SKIP_ADDITIONAL_DISCOVERY	:	0	
SKIP_LINKSTATE_DISCOVERY	:	0	
SPEED	:	1Gb/s	
VIRTUAL_DEV	:	undef	
VLANCOUNT	:	0	
ADMINPORT	:	No	
VIRTUAL	:	No	
IPADDR_V6	:	undef	

Network > WANOptimization

Network > WANOptimization – Manages wide area network data throughput optimization.

SYNOPSIS

```
WANOptimization  
WANOptimization > Enable  
WANOptimization > Disable  
WANOptimization > Status
```

DESCRIPTION

Use this option to manage the WAN Optimization settings.

The WAN Optimization feature uses various techniques for increasing data-transfer efficiencies across wide-area networks. As a result, using WAN optimization can improve inbound and outbound data transfers to and from your appliance.

This feature includes the following benefits:

- Improves NetBackup Auto Image Replication (AIR) performance.
NetBackup AIR is a disaster recovery solution. Its purpose is to create off-site copies of mission critical backups to protect against site loss.
For example, the backups that are generated in one NetBackup domain can be replicated to storage in other NetBackup domains. These other NetBackup domains may be located in diverse geographical locations. Because WAN optimization can improve wide area network data throughput to and from your appliance, more efficient backup data transfers and disaster recovery transfers can occur.
- Benefits appliances for which data is sent across slower networks. For example, such as networks with a latency greater than 20 milliseconds and packet loss rates greater than 0.01% (1 in 10,000).
- Operates on individual TCP connections. Evaluates each inbound and outbound network connection to determine whether the performance can be improved.
- Improves the network performance with minimal dependency on the outbound network traffic.
- Improves the network performance of optimized duplications.
- Improves the network performance of restores to remote clients.

- Imposes no network overhead. WAN optimization is non-intrusive, as it does not impose any network overhead in situations where the overall network data transfers are high. In some scenarios, when the overall network data transfer is high, the connection speed may not be optimized despite this feature being enabled.

OPTIONS

The WAN Optimization menu includes the following options:

```
WANOptimization > Enable [all] | [port or individual NIC bond]
```

Use this command to enable WAN optimization for individual network interface (NIC/eth) ports on the appliance. The command also lets you enable WAN optimization for all network ports at the same time.

You can also optimize NIC bonds with this command. Bonds consist of two or more physical NIC/eth ports that have been teamed together to form a logical network port. The logical network port is called a bond.

Note: When configuring multiple network interfaces as a NIC bond, use the NetBackup Appliance Shell Menu command `Network > LinkAggregation` to comprise the bond. You can also use the **Network** page of the NetBackup Appliance Web Console (**Settings > Network > Network Configuration > Create Bond**). NIC bonds that are configured with tools other than the abovementioned appliance tools appear as *Disabled* when you run the WAN optimization `Status` command. They also appear as *Disabled* when you view them in the NetBackup Appliance Web Console.

Use either the NetBackup Appliance Shell Menu or the NetBackup Appliance Web Console to enable these NIC bonds.

`Enable` command-line parameters include:

- `all` - Lets you enable WAN optimization for all appliance network interface ports and NIC bonds at the same time.
- `[port or individual NIC bond]` - Lets you enable WAN optimization for selected NIC ports or NIC bonds. Note however, that individual NIC ports cannot be optimized for WAN communications if they are teamed in a NIC bond. When you enable WAN optimization for a bond, WAN optimization is applied to each NIC port in the bond.

The following are examples of how to use the `Enable` command and its parameters:

- `myappliance1.WANOptimization> Enable all` (provided the ports are not part of a bond)
- `myappliance1.WANOptimization> Enable eth2` (provided the port is not part of a bond)
- `myappliance1.WANOptimization> Enable bond0`
- `myappliance1.WANOptimization> Enable eth0,eth1` (provided the ports are not part of a bond)
- `myappliance1.WANOptimization> Enable bond1,bond2`
- `myappliance1.WANOptimization> Enable eth0,bond1` (provided the port is not part of a bond)

Note: If you run a factory reset of the appliance, note the following:

A factory reset disables WAN optimization for all network interface bonds when you retain your network configuration. To retain your network configuration, you can select **Retain network configuration** in the NetBackup Appliance Web Console (**Manage > Appliance Restore > Retain network configuration**). After the factory reset completes, you can then enable WAN optimization again for the network interface bonds.

If you choose *not* to retain your network configuration, all network interface bonds are lost during the factory reset. After the reset completes, the appliance automatically enables WAN optimization for all network interface ports, including those that comprised the bonds.

`WANOptimization > Disable [all] | [port or individual NIC bond]`

Use this command to disable WAN optimization for individual network interface (NIC/eth) ports on the appliance. The command also lets you disable WAN optimization for all network ports at the same time.

You can also disable WAN optimization for NIC bonds with this command. Bonds consist of two or more physical NIC/eth ports that have been teamed together to form a logical network port. The logical network port is called a bond.

`Disable` command-line parameters include:

- `all` - Lets you disable WAN optimization for all appliance network interface ports and NIC bonds at the same time.
- `[port or individual bond]` - Lets you disable WAN optimization for selected NIC ports or NIC bonds, unless the selected port has been teamed together with another port to form a bond. To disable WAN optimization for the ports

within the bond, you must specify the bond name when you run the `Disable` command.

The following are examples of how to use the `Disable` command and its parameters:

- `myappliancel.WANOptimization> Disable all`
- `myappliancel.WANOptimization> Disable eth2` (provided the port is not part of a bond)
- `myappliancel.WANOptimization> Disable bond0`
- `myappliancel.WANOptimization> Disable eth0,eth1` (provided the ports are not part of a bond)
- `myappliancel.WANOptimization> Disable bond1,bond2`
- `myappliancel.WANOptimization> Disable eth0,bond1` (provided the port is not part of a bond)

Note: When you disable WAN optimization for a bond, WAN optimization is disabled for each port within the bond.

WANOptimization > Status

Shows the current WAN optimization status.

The appliance displays the optimization status in a table that resembles the following example:

Bond	Interface	State	IP address	WAN Optimization
bond0	eth4	Plugged		Disabled
	eth5	Plugged		
	eth0	Unplugged	192.168.000.000	Enabled
	eth1	Plugged	192.168.00.00	Disabled
	eth2	Plugged		Enabled
	eth3	Plugged		Enabled

Main > Network > Security (IPsec) view commands

This appendix includes the following topics:

- [Network > IPsec > Configure](#)
- [Network > IPsec > Delete](#)
- [Network > IPsec > Export](#)
- [Network > IPsec > Import](#)
- [Network > IPsec > Provision](#)
- [Network > IPsec > Refresh](#)
- [Network > IPsec > Show](#)
- [Network > IPsec > Unconfigure](#)

Network > IPsec > Configure

Network > IPsec > Configure – Configure IPsec between any two hosts.

SYNOPSIS

```
Configure Host1Info [Host2Info]
```

DESCRIPTION

You can use this command to configure IPsec between any two hosts. You can define the hosts by the host name. You can also identify them by the user ID and password.

OPTIONS

```
Configure Host1Info [Host2Info]
```

Use this command to configure IPsec between any two hosts. The *Host1Info* variable can contain the following information that is separated by a comma. The host name, the user ID (optional), and the password (optional). The [*Host2info*] variable can contain the host name, the user ID (optional), and the password (optional).

See [“About the NetBackup Appliance Shell Menu”](#) on page 12.

Network > IPsec > Delete

`Network > IPsec > Delete` – Remove IPsec policies for a list of remote hosts on a local system.

SYNOPSIS

`Delete Hosts`

DESCRIPTION

You can use this command to remove IPsec policies for a list of remote hosts on a local system.

OPTIONS

`Delete Hosts`

Remove IPsec policies for a list of remote hosts on a local system. Use the *Hosts* variable to define one or more host names. Use a comma to separate multiple host names.

Network > IPsec > Export

Network > IPsec > Export – Export the IPsec credentials.

SYNOPSIS

```
Export [EnterPasswd] [PathValue]
```

DESCRIPTION

Use this command to export the IPsec credentials to a specified location.

Note: The IPsec credentials are removed during a reimage process. The credentials are unique for each appliance and are included as part of the original factory image.

The IPsec credentials are not included on the USB drive that is used to reimage the appliance.

OPTIONS

```
Export [EnterPasswd] [PathValue]
```

Use this command to export the IPsec credentials. The `EnterPasswd` field is used to answer the question, "Do you want to enter a password?". You must enter a value of **yes** or **no** in this field. In addition, you must specify a path that defines where you want to place the exported credentials.

Network > IPsec > Import

Network > IPsec > Import – Import the IPsec credentials.

SYNOPSIS

```
Import [EnterPasswd] [PathValue]
```

DESCRIPTION

Use this command to import the IPsec credentials to a specified location.

OPTIONS

```
Import [EnterPasswd] [PathValue]
```

Use this command to import the IPsec credentials. The `EnterPasswd` field is used to answer the question, "Do you want to enter a password?". You must enter a value of **yes** or **no** in this field. In addition, you must specify a path that defines where you want to place the imported credentials.

Network > IPsec > Provision

`Network > IPsec > Provision` – Provision IPsec policies for a list of remote hosts on a local system.

SYNOPSIS

`Provision Hosts`

DESCRIPTION

Use this command to provision IPsec policies for a list of remote hosts on a local system.

OPTIONS

`Provision Hosts`

Provision IPsec policies for a list of remote hosts on a local system. Use the *Hosts* variable to define one or more host names. Use a comma to separate multiple host names.

Network > IPsec > Refresh

`Network > IPsec > Refresh` – Use to reload the IPsec configuration.

SYNOPSIS

`Refresh [Auto]`

DESCRIPTION

Use this command to reload the IPsec configuration. With auto-refresh, refresh the configurations on all referenced hosts. The default setting for this command is `NoAuto`.

OPTIONS

`Refresh [Auto]`

Use this command to reload the IPsec configuration. The `[Auto]` options defines whether the configurations on all referenced hosts are refreshed or not. You can enter **Auto** or **NoAuto**. The default value is **NoAuto**.

Network > IPsec > Show

`Network > IPsec > Show` – Display the IPsec policies for a local host or a provided host.

SYNOPSIS

```
Show [Verbose] [HostInfo]
```

DESCRIPTION

You can use this command to display the IPsec policies for a local host or a provided host. You can define whether the output in verbose or not. And you define the host.

OPTIONS

```
Show [Verbose] [HostInfo]
```

Display the IPsec policies for a local host or a provided host. The `[Verbose]` options is used to define whether the output is verbose or not. The values that you can enter in this field are `VERBOSE` or `NOVERBOSE`. The default value is `NOVERBOSE`.

The `[HostInfo]` option can contain the following information that is separated by a comma. The host name, the user ID (optional), and the password (optional).

Network > IPsec > Unconfigure

Network > IPsec > Unconfigure – Unconfigure IPsec between any two hosts.

SYNOPSIS

```
Unconfigure Host1Info [Host2Info]
```

DESCRIPTION

You can use this command to unconfigure IPsec between any two hosts.

OPTIONS

```
Unconfigure Host1Info [Host2Info]
```

Use this command to unconfigure IPsec between any two hosts. The *Host1Info* variable can contain the following information that is separated by a comma. The host name, the user ID (optional), and the password (optional). The [*Host2info*] variable can contain the host name, the user ID (optional), and the password (optional).

Main > Reports view commands

This appendix includes the following topics:

- [Reports > Deduplication](#)
- [Reports > Process](#)

Reports > Deduplication

Reports > Deduplication – Show the deduplication statistics for the appliance.

SYNOPSIS

Deduplication

DESCRIPTION

Use this command to show the deduplication statistics for the appliance.

OPTIONS

Deduplication

Shows the deduplication statistics for the appliance.

EXAMPLES

The following command shows an example of how the Deduplication statistics are displayed.

```
.Reports> Deduplication
```

```
Deduplication statistics
Deduplication technology  MSDP
Deduplication rate       79.019%
Data Protected           301622 MB
Space Used For Protection 63282 MB
Physical free space      9735902 MB
Logical free space       0 MB
Total free space         9735902 MB
Maximum Disk Space       10065305 MB
Used Disk Space          329402 MB
```

Reports > Process

Reports > Process — Show the status of a current process.

SYNOPSIS

Process

DESCRIPTION

Use this command to show the status of a current process.

OPTIONS

Process

Show the status of a current process.

EXAMPLES

The following is an example of the output that appears when you run this command.

```
Reports> Process
NB_dbsrv:      Down          bpcd:          Running Responding
bpdbm:         Down          bpjobd:        Down
bprd:          Down          nbars:         Down
nbemm:         Down          nbjm:          Down
nbpem:         Down          nbrb:          Down
nbrmms:        Running       nbsl:          Running
nbstserv:      Down          nbsvcmon:      Running
postmaster:    Running       spad:          Running
spoold:        Running       vmd:           Running Responding
vnetd:         Running
```

Main > Settings view commands

This appendix includes the following topics:

- [Settings > Deduplication](#)
- [Settings > FibreTransport](#)
- [Settings > LifeCycle](#)
- [Settings > LiveUpdateServer](#)
- [Settings > NetBackup](#)
- [Settings > Password](#)
- [Settings > Share](#)
- [Settings > Sysctl](#)
- [Settings > SystemLocale](#)

Settings > Deduplication

Settings > Deduplication – Use to change the deduplication parameters.

SYNOPSIS

Defaults

Show

Tune BACKUPRESTORERANGE *Addresses*

Tune BANDWIDTH_LIMIT *Limit*

Tune COMPRESSION *Comp*

Tune DONT_SEGMENT_TYPES Append *FileTypes*

Tune DONT_SEGMENT_TYPES Change *FileTypes*

Tune ENCRYPTION *Value*

Tune LOCAL_SETTINGS *Override*

Tune LOGLEVEL *Value*

Tune MAX_IMG_MBSIZE *Value*

Tune MAX_LOG_MBSIZE *Value*

Tune OPTDUP_BANDWIDTH *Value*

Tune OPTDUP_COMPRESSION *Value*

Tune OPTDUP_ENCRYPTION *Value*

Tune OPTDUP_TIMEOUT *Time*

Tune WS_RETRYCOUNT *Count*

Tune WS_TIMEOUT *Time*

DESCRIPTION

You can use the `Deduplication` command with the `Default` and `Show` options to display the default values for each of the `Deduplication` parameters and the current parameter values, respectively. You can use the `Deduplication Tune` command to adjust the following parameters:

Table R-1 Deduplication parameters and default values

Setting	Default value	Possible values	Action
BACKUPRESTORERANGE	N/A	Classless Inter-Domain Routing format or comma-separated list of IP addresses	Specifies the IP address or range of addresses of the local network interface card (NIC) for backups and restores.
BANDWIDTH_LIMIT	0	0 (no limit) to the practical system limit, in KBs/sec	Determines the maximum bandwidth that is allowed when backing up or restoring data between the media server and the deduplication pool. The value is specified in KBytes/second. The default is no limit.
COMPRESSION	1	0 (off) or 1 (on)	Specifies whether you want compression. By default, files are compressed. If you do not want compression, change the value to 0.

Table R-1 Deduplication parameters and default values (*continued*)

Setting	Default value	Possible values	Action
DONT_SEGMENT_TYPES	N/A	Any file extension	<p>You can specify a list of comma-separated file name extensions. Files in the backup stream that have the specified extensions are given a single segment if smaller than 16 MB. Larger files are deduplicated using the maximum 16-MB segment size.</p> <p>Example:</p> <pre>DONT_SEGMENT_TYPES = mp3,avi</pre> <p>This setting prevents NetBackup from analyzing and managing segments within the file types that do not deduplicate globally.</p>
ENCRYPTION	0	0 (off) or 1 (on)	<p>Specifies whether to encrypt the data. By default, files are not encrypted. If you want encryption, change the value to 1.</p> <p>If you set this parameter to 1 on all hosts, the data is encrypted during transfer and on the storage.</p>

Table R-1 Deduplication parameters and default values (*continued*)

Setting	Default value	Possible values	Action
LOCAL_SETTINGS	0	0 (allow override) or 1 (always use local settings)	Specifies whether to allow the <code>pd.conf</code> settings of the deduplication storage server to override the settings in the local <code>pd.conf</code> file.
LOGLEVEL	0	An integer, 0 to 10 inclusive	Specifies the amount of information that is written to the log file. The range is from 0 to 10, with 10 being the most logging. Note: Change this value only when directed to do so by a Veritas representative.
MAX_IMG_MBSIZE	50,000	0 to 50,000, in MBs	The maximum backup image fragment size in megabytes. Note: Change this value only when directed to do so by a Veritas representative.
MAX_LOG_MBSIZE	500	0 to 50,000, in MBs	The maximum size of the log file in megabytes.
OPTDUP_BANDWIDTH	0	0 (no limit) to the practical system limit, in KBs/sec	Determines the maximum bandwidth that is allowed for optimized duplication. The value is specified in KBytes/second.

Table R-1 Deduplication parameters and default values (*continued*)

Setting	Default value	Possible values	Action
OPTDUP_COMPRESSION	1	0 (off) or 1 (on)	Specifies whether to compress optimized duplication data. By default, files are not compressed. If you want compression, change the value to 1.
OPTDUP_ENCRYPTION	0	0 (off) or 1 (on)	<p>Specifies whether to encrypt the optimized duplication data. By default, files are not encrypted. If you want encryption, change the value to 1.</p> <p>If you set this parameter to 1 on all hosts, the data is encrypted during transfer and on the storage.</p>
OPTDUP_TIMEOUT	N/A	The value, expressed in minutes	Specifies the number of minutes before the optimized duplication times out. Indicated in minutes.
WS_RETRYCOUNT	3	Integer	<p>This parameter applies to the PureDisk Deduplication Option only. It does not affect NetBackup deduplication.</p> <p>The <code>WSRetryCount</code> parameter lets you configure the amount of retries that are attempted in case the Web service fails or times out.</p>

Table R-1 Deduplication parameters and default values (*continued*)

Setting	Default value	Possible values	Action
WS_TIMEOUT	120	Integer	<p>This parameter applies to the PureDisk Deduplication Option only. It does not affect NetBackup deduplication.</p> <p>The <code>WSTimeout</code> parameter lets you increase or decrease the timeout value for Web service calls made from NetBackup media servers to PureDisk storage units.</p>

OPTIONS

`Deduplication Defaults`

Use this command to display the default values for the Deduplication parameters.

`Deduplication Show`

Use this command to display the current values for the Deduplication parameters.

`Deduplication Tune BACKUPRESTORERANGE Addresses`

Specifies the IP addresses or range of addresses of the local network interface card for backup and restore. The *Addresses* variable contains an IP addresses list or a range of addresses.

`Deduplication Tune BANDWIDTH_LIMIT Limit`

The maximum bandwidth that is allowed when backing up or restoring data between the media server and the deduplication pool. The *limit* variable contains the maximum bandwidth limit. The value for this variable is in KBytes/second.

`Deduplication Tune COMPRESSION Comp`

Whether you want compression. The *Compression* variable lets you enable or disable compression. You enter either `Enable` or `Disable`.

Deduplication Tune DONT_SEGMENT_TYPES Append *FileTypes*

Use this command to append new file types to the list of file types that NetBackup does not analyze or manage segments. The *FileTypes* variable lists the file types.

Deduplication Tune DONT_SEGMENT_TYPES Change *FileTypes*

Use this command to change the whole list of file types. The *FileTypes* variable lists the file types.

Deduplication Tune ENCRYPTION *Value*

Use this command to decide whether you want to encrypt the data. Use the *Value* variable to enable or disable encryption. The values that you can enter are, Enable, or Disable.

Deduplication Tune LOCAL_SETTINGS *Override*

Whether to allow settings of the deduplication server to override the local settings. The *Override* variable determines whether to allow an override to occur. The values that you can enter in this field are, AllowOverride, or UseLocalSetting.

Deduplication Tune LOGLEVEL *Value*

The amount of information that is written to the log file. The *Value* variable sets the range from 0 to 10. A value of 10 provides the most logging.

Deduplication Tune MAX_IMG_MBSIZE *Value*

Use this command to set the maximum backup image fragment size. The *Value* variable contains the maximum size of the backup image fragment in megabytes. You can enter a value between zero and 50000.

Deduplication Tune MAX_LOG_MBSIZE *Value*

Use this command to set the maximum size of the log file. The *Value* variable contains the maximum size of the log file in megabytes. You can enter a value between zero and 50000.

Deduplication Tune OPTDUP_BANDWIDTH *Value*

The maximum bandwidth that is allowed for optimized duplication. The *Value* variable contains the maximum bandwidth in KBs/sec.

Deduplication Tune OPTDUP_COMPRESSION *Value*

Whether to compress the optimized duplication data. The *Value* variable lets you enable or disable compression. The values for this field are: Enable or Disable.

Deduplication Tune OPTDUP_ENCRYPTION *Value*

Whether to encrypt the optimized duplication data. The *Value* variable lets you enable or disable encryption. The values for this field are: Enable or Disable.

Deduplication Tune OPTDUP_TIMEOUT *Time*

The number of minutes before the optimized duplication times out. The *Time* variable is the number of minutes before the optimized duplication times out.

Deduplication Tune WS_RETRYCOUNT *Count*

The amount of retries that are attempted in case the Web service fails or times out. The *Count* variable is the amount of retries that are attempted in case the Web service fails or times out.

Deduplication Tune WS_TIMEOUT *Time*

The timeout value for Web service calls made from NetBackup media servers to PureDisk storage units. The *Time* variable is the timeout value for Web service calls made from NetBackup media servers to PureDisk storage units.

EXAMPLES

The `Defaults` command shows the values of each of the Deduplication parameters:

```
Deduplication> Defaults
BACKUPRESTORERANGE           : N/A
BANDWIDTH_LIMIT               : 0
COMPRESSION                   : 1
DONT_SEGMENT_TYPES            : N/A
ENCRYPTION                    : 0
LOCAL_SETTINGS                : 0
LOGLEVEL                      : 0
MAX_IMG_MBSIZE                : 50000
MAX_LOG_MBSIZE                : 500
OPTDUP_BANDWIDTH              : 0
OPTDUP_COMPRESSION            : 1
OPTDUP_ENCRYPTION             : 0
OPTDUP_TIMEOUT                : N/A
SEGKSIZE                      : 128
WS_RETRYCOUNT                : 3
WS_TIMEOUT                    : 120
```

Settings > FibreTransport

Settings > FibreTransport – Administer Fibre Transport for this appliance.

SYNOPSIS

```
FibreTransport NBUAppliances Disable
FibreTransport NBUAppliances Enable
FibreTransport NBUAppliances Show
FibreTransport SANClient Disable
FibreTransport SANClient Enable
FibreTransport SANClient Show
FibreTransport Deduplication Disable
FibreTransport Deduplication Enable FactoryDefault
FibreTransport Deduplication Enable [Current]
FibreTransport Deduplication Show
```

DESCRIPTION

Use this command to do the following:

- administer Fibre Transport for SAN client backups and restores
- administer Fibre Transport for duplication to another appliance
- administer Fibre Transport for duplication on this appliance as a target host

Note: To use this appliance as a target host, you must enable the NBUAppliances service on the source host(s). To enable that service, you must log on that appliance, and run the `Main > Settings> FibreTransport NBUAppliances Enable` command from the NetBackup Appliance Shell Menu.

Note: You must restart the appliances in the FC zone if you have caused the physical state of a port in the zone to change by disabling or enabling this appliance as a target host for data duplication.

See [Manage > FibreChannel > Show](#) on page 48.

OPTIONS

`FibreTransport NBUApliances Disable`

Disables Fibre Transport for duplication to another appliance. By default, Fibre Transport to another appliance is disabled.

This option restarts the deduplication storage daemons. Therefore, any active backup, restore, or duplication jobs fail.

`FibreTransport NBUApliances Enable`

Enables Fibre Transport for duplication to another appliance.

This option restarts the deduplication storage daemons. Therefore, any active backup, restore, or duplication jobs fail.

`FibreTransport NBUApliances Show`

This command displays the status of the Fibre Transport services to another appliance.

`FibreTransport SANClient Disable`

Disables Fibre Transport for SAN client backups and restores to this appliance. By default, Fibre Transport for backups and restores is disabled.

This option restarts the NetBackup SAN client daemons. Therefore, any active backup, restore, or duplication jobs fail.

`FibreTransport SANClient Enable`

Enables Fibre Transport for SAN client backups and restores to this appliance.

This option restarts the NetBackup SAN client daemons. Therefore, any active backup, restore, or duplication jobs fail.

`FibreTransport SANClient Enable [2|4]`

Enables Fibre Transport for SAN Client backups and restores to this appliance.

By default, the feature is disabled on new appliances or on appliances that have been factory reset.

The available port number settings are optional, since they are typically configured using the `Manage > FibreChannel > Configure` command. The options are as follows:

- No ports specified
If you enter the command without specifying the number of ports, the feature is enabled but the port configuration does not change. For new appliances or appliances that have been factory reset, the port configuration remains at 2 by default.
- 2
Sets Port 1 to the target mode on the following FC HBA cards:

NetBackup 5220 - cards in slots 2 and 4

NetBackup 5230 and 5330 - cards in slots 5 and 6

■ 4

Sets Ports 1 and 2 to the target mode on the following FC HBA cards:

NetBackup 5220 - cards in slots 2 and 4

NetBackup 5230 and 5330 - cards in slots 5 and 6

Changing this option restarts the NetBackup SAN client daemons. Therefore, any active backup, restore, or duplication jobs fail.

`FibreTransport SANClient Show`

Displays the status of the Fibre Transport server for SAN client backups and restores.

`FibreTransport Deduplication Disable`

Disables Fibre Transport on the appliance as a target host for optimized duplication and Auto Image Replication. This reverts the physical state of all the target mode ports to initiator.

`FibreTransport Deduplication Enable FactoryDefault`

Enables Fibre Transport on the appliance as a target host for optimized duplication and Auto Image Replication. The factory default port configuration is used.

When the feature has been enabled, you can use this command to restore the customized port configuration to the factory default state.

Note: This command restarts the Deduplication service if the feature state is changed from disabled to enabled. The service restart causes the ongoing jobs fail, and then failover to LAN. It is recommended that you cancel or suspend all jobs before changing the feature state.

`FibreTransport Deduplication Enable [Current]`

Enables Fibre Transport on the appliance as a target host for optimized duplication and Auto Image Replication. The preexisting port configuration is used.

If no HBA port has been configured before you enable this feature, the factory default port configuration is used.

Note: This command restarts the Deduplication service if the feature state is changed from disabled to enabled. The service restart causes the ongoing jobs fail, and then failover to LAN. It is recommended that you cancel or suspend all jobs before changing the feature state.

`FibreTransport Deduplication Show`

Shows whether the appliance is enabled as a target host for optimized duplication and Auto Image Replication.

EXAMPLES

The following is an example of information when you run the `FibreTransport SANClient Show` command.

```
- [Info] Fibre Transport Sever enabled.
```

The following is an example of information when you run the `FibreTransport NBUAppliances Show` command.

```
fc transport enabled.
```

The following is an example of information when you run the `FibreTransport Deduplication Disable` command.

```
[Info] Fibre Transport Deduplication is disabled.
```

The following is an example of information when you run the `FibreTransport Deduplication Enable` command.

```
[Info] Fibre Transport Deduplication is enabled.
```

The following is an example of information when you run the `FibreTransport Deduplication Show` command.

```
[Info] Fibre Transport Deduplication is disabled.
```

Settings > LifeCycle

Settings > LifeCycle – Use to change the backup image life cycle parameter settings.

SYNOPSIS

```
Lifecycle Defaults
```

```
LifeCycle Show
```

```
LifeCycle Tune CLEANUP_SESSION_INTERVAL Interval Unit
```

```
LifeCycle Tune DUPLICATION_GROUP_CRITERIA Criteria
```

```
LifeCycle Tune IMAGE_EXTENDED_RETRY_PERIOD Interval Unit
```

```
LifeCycle Tune JOB_SUBMISSION_INTERVAL Interval Unit
```

```
LifeCycle Tune MAX_SIZE_PER_DUPLICATION_JOB Size Unit
```

```
LifeCycle Tune MAX_TIME_TIL_FORCE_SMALL_DUPLICATION_JOB Time
```

```
LifeCycle Tune MIN_SIZE_PER_DUPLICATION_JOB Size Unit
```

```
LifeCycle Tune REPLICA_METADATA_CLEANUP_TIMER Time
```

```
LifeCycle Tune TAPE_RESOURCE_MULTIPLIER Value
```

```
LifeCycle Tune VERSION_CLEANUP_DELAY Time Unit
```

DESCRIPTION

You can use the `LifeCycle` command with the `Default` and `Show` options to display the default values for each of the `LifeCycle` parameters and the current parameter values, respectively.

You can use the `LifeCycle Tune` command to adjust the following parameters:

- `CLEANUP_SESSION_INTERVAL` - To define how often the deleted life cycle policies should be cleaned up.
- `DUPLICATION_GROUP_CRITERIA` - To define how batches are created.
- `IMAGE_EXTENDED_RETRY_PERIOD` - To define how long NetBackup waits before an image copy is added to the next duplication job.
- `JOB_SUBMISSION_INTERVAL` - Set the frequency of job submission for all operations.

- `MAX_SIZE_PER_DUPLICATION_JOB` - To define how large the batch of images is allowed to grow.
- `MAX_TIME_TIL_FORCE_SMALL_DUPLICATION_JOB` - To define how old any image in the group can become before the batch is submitted as a duplication job.
- `MIN_SIZE_PER_DUPLICATION_JOB` - To define the size that the batch of images should reach before one duplication job is run for the entire batch.
- `REPLICA_METADATA_CLEANUP_TIMER` - Set the number of days after which the Import Manager stops trying to import the image.
- `TAPE_RESOURCE_MULTIPLIER` - Set the multiplier for the number of concurrently active duplication jobs that can access a single storage unit.
- `VERSION_CLEANUP_DELAY` - To define how much time must pass since an inactive version was the active version.

OPTIONS

`LifeCycle Defaults`

Use this command to show the default values of each of the parameters.

`LifeCycle Show`

Use this command to show the current values of each of the parameters.

`LifeCycle Tune CLEANUP_SESSION_INTERVAL Interval Unit`

How often the deleted life cycle policies should be cleaned up. The *Interval* variable denotes the time interval after which the policies are to be cleaned. The *Unit* variable is used to provide the unit for the time interval in Seconds, Minutes, Hours, Days, Weeks, Months, or Years. The default value is 24 hours. You must enter a value that is greater than 10 Seconds when the unit is set to Seconds.

`DUPLICATION_GROUP_CRITERIA Criteria`

Use this command to define how batches are created. Batches are created based on the life cycle policy name or the duplication job priority. You enter either `PolicyName` or `JobPriority`

`LifeCycle Tune IMAGE_EXTENDED_RETRY_PERIOD Interval Unit`

How long NetBackup waits before an image copy is added to the next duplication job. The *Unit* variable is used to provide the unit for the time interval in Seconds, Minutes, Hours, Days, Weeks, Months, or Years. The default value is 2 hours. You must enter a value that is greater than 10 Seconds when the unit is set to Seconds.

LifeCycle Tune JOB_SUBMISSION_INTERVAL *Interval Unit*

Use this command to set the frequency of job submission for all operations. The *Interval* variable is defined in minutes. The *Unit* variable is used to provide the unit for the time interval in Seconds, Minutes, Hours, Days, Weeks, Months, or Years. The default value is 5 minutes. You must enter a value that is greater than 10 Seconds when the unit is set to Seconds. The maximum interval for this variable is not identified.

LifeCycle Tune MAX_SIZE_PER_DUPLICATION_JOB *Size Unit*

How large the batch of images is allowed to grow. The *Size* variable is the size of the duplication job. The *Unit* variable is used to provide the unit for the time interval in Bytes, KB, MB, GB, TB, or PB. If you select the unit as Bytes, you cannot enter a size that is less than 1024 Bytes. The maximum value is 2147483647. The default value is 100 GB.

LifeCycle Tune MAX_TIME_TIL_FORCE_SMALL_DUPLICATION_JOB *Time Unit*

How old any image in the group can become before the batch is submitted as a duplication job. The *Time* variable is the time of the image. The *Unit* variable is used to provide the unit for the time interval in Seconds, Minutes, Hours, Days, Weeks, Months, or Years. The default value is 30 minutes. You must enter a value that is greater than 10 Seconds when the unit is set to Seconds. The maximum seconds number is 2147483647.

The logical maximum number for the other unit options is as follows:

- Minutes: 35,791,394
- Hours: 396,523
- Days: 24,855
- Weeks: 3,550
- Months: 828
- Years: 68

If a user enters a higher number than the maximum, it automatically uses the allowed maximum number.

LifeCycle Tune MIN_SIZE_PER_DUPLICATION_JOB *Size Unit*

The size that the batch of images should reach before one duplication job is run for the entire batch. The *Size* variable denotes the size of the duplication job. The *Unit* variable denotes unit of size in Bytes, KB, MB, GB, TB, or PB. The default value is 8 GB. You must enter a value that is greater than 1024 Bytes.

LifeCycle Tune REPLICATION_METADATA_CLEANUP_TIMER *Time*

Use this command to set the number of days after which the Import Manager stops trying to import the image. The *Time* variable is defined in the number of days. You turn this parameter off if you enter a value of zero.

LifeCycle Tune TAPE_RESOURCE_MULTIPLIER *Value*

Use this command to set the multiplier for the number of concurrently active duplication jobs that can access a single storage unit. The *Value* variable contains the multiplier value that is between 1 to 2147483647. The default value is 2.

LifeCycle Tune VERSION_CLEANUP_DELAY *Time Unit*

How much time must pass since an inactive version was the active version. The *Time* variable denotes the time that must pass since an inactive version was the active version. The *Unit* variable is used to provide the unit for the time interval in Seconds, Minutes, Hours, Days, Weeks, Months, or Years. The default value is 14 hours. You must enter a value that is greater than 10 Seconds when the unit is set to Seconds.

Examples

The `Defaults` command shows the values of each of the LifeCycle parameters:

```
LifeCycle > Defaults
CLEANUP_SESSION_INTERVAL           : 24 hours
DUPLICATION_GROUP_CRITERIA        : 1
IMAGE_EXTENDED_RETRY_PERIOD       : 2 hours
JOB_SUBMISSION_INTERVAL           : 5 minutes
MAX_SIZE_PER_DUPLICATION_JOB      : 100 GB
MAX_TIME_TIL_FORCE_SMALL_DUPLICATION_JOB : 30 minutes
MIN_SIZE_PER_DUPLICATION_JOB      : 8 GB
REPLICATION_METADATA_CLEANUP_TIMER : 0 hours
TAPE_RESOURCE_MULTIPLIER           : 2
VERSION_CLEANUP_DELAY              : 14 days
```

See [“About the commands under the Settings view”](#) on page 26.

See [“About the NetBackup Appliance Shell Menu”](#) on page 12.

Settings > LiveUpdateServer

Settings > LiveUpdateServer – Use to configure the LiveUpdate server.

SYNOPSIS

```
LiveUpdateServer Set Name
```

```
LiveUpdateServer Show
```

DESCRIPTION

You can use this command to define and show the LiveUpdate server.

OPTIONS

```
LiveUpdateServer Set Name
```

Use this command to configure the LiveUpdate Web server. The *Name* variable contains the name of the Web server that contains the LiveUpdate files.

```
LiveUpdateServer Show
```

Use this command to show the LiveUpdate server name.

Settings > NetBackup

Settings > NetBackup – Use to configure and adjust NetBackup settings.

SYNOPSIS

```
NetBackup AdditionalServers Add Servers
NetBackup AdditionalServers Delete Servers
NetBackup AdditionalServers Show
NetBackup AdditionalServers ShowAll
NetBackup DataBuffers Number Defaults
NetBackup DataBuffers Number Disk Count
NetBackup DataBuffers Number FT Count
NetBackup DataBuffers Number Restore Count
NetBackup DataBuffers Number Show
NetBackup DataBuffers Number Tape Count
NetBackup DataBuffers Size Defaults
NetBackup DataBuffers Size Disk Size
NetBackup DataBuffers Size FT Size
NetBackup DataBuffers Size Show
NetBackup DataBuffers Size Tape Size
NetBackup DataBuffers Size MULTICOPY Size
NetBackup DataBuffers Size NDMP Size
NetBackup Misc Defaults
NetBackup Misc Show
NetBackup Misc Tune DEFERRED_IMAGE_LIMIT Size
NetBackup Misc Tune DPS_PROXYDEFAULTRECVTMO Time
```

DESCRIPTION

You can use the `NetBackup` command to adjust various NetBackup settings. With this command, you can do the following:

- Add or delete additional servers to NetBackup on 52xx appliances in master or media server roles only.
- Show the number of NetBackup data buffers. You can also display the default numbers of the NetBackup data buffers.
- Adjust the number of NetBackup data buffers for the following:
 - Disk
 - Fibre Transport
 - Tape
- Show the current values or the default values for the following:
 - Deferred image limit, `DEFERRED_IMAGE_LIMIT`. The default value is 64.
 - The Data Protection Server (DPS), proxy timeout, `DPS_PROXYDEFAULTRECVTMO`. The default value is 800.
- Change the number of images that you want to defer.
- Change the proxy default received timeout.

OPTIONS

`NetBackup AdditionalServers Add Servers`

Add servers to NetBackup additional servers list, where *Servers* is the list of server names or IP address.

Note: Only available on 52xx appliances in master server role.

`NetBackup AdditionalServers Delete Servers`

Delete servers from NetBackup additional servers list, where *Servers* is the list of server names or IP address.

Note: Only available on 52xx appliances in master server role.

`NetBackup AdditionalServers Show`

View the list of NetBackup additional servers excluding media servers.

Note: Only available on 52xx appliances in master server role.

`NetBackup AdditionalServers ShowAll`

View the list of all NetBackup additional servers. This list includes media servers.

Note: Only available on 52xx appliances in master server role.

NetBackup DataBuffers Number Defaults

Use this command to view the default numbers of NetBackup data buffers.

NetBackup DataBuffers Number Disk *Count*

Tune the number of NetBackup data buffers for a disk. The parameter name is `NUMBER_DATA_BUFFERS_DISK` and the default value is 30. The *Count* variable contains the number of data buffers.

NetBackup DataBuffers Number FT *Count*

Tune the number of NetBackup data buffers for Fibre Transport. The parameter name is `NUMBER_DATA_BUFFERS_FT` and the default value is 16. The *Count* variable contains the number of data buffers.

NetBackup DataBuffers Number Restore *Count*

Use this command to tune the number of NetBackup data buffers for restore. The *Count* variable contains the number of data buffers.

NetBackup DataBuffers Number Show

Use this command to show the number of data buffers.

NetBackup DataBuffers Number Tape *Count*

Tune the number of NetBackup data buffers for Tape. The parameter name is `NUMBER_DATA_BUFFERS` and the default value is 30. The *Count* variable contains the number of data buffers.

NetBackup DataBuffers Size Defaults

Use this command to set the NetBackup default data buffer size in Bytes.

NetBackup DataBuffers Size Disk *Size*

Use this command to set the NetBackup data buffer size for disk in Bytes. The *Size* variable contains the new size for data buffers.

NetBackup DataBuffers Size FT *Size*

Use this command to set the NetBackup data buffer size for tape in Bytes. The *Size* variable contains the new size for data buffers.

NetBackup DataBuffers Size Show

Use this command to show the NetBackup data buffer sizes for disk and tape in Bytes.

NetBackup DataBuffers Size Tape *Size*

Use this command to set the NetBackup data buffer size for tape in Bytes. The *Size* variable contains the number of data buffers.

`NetBackup DataBuffers Size MULTICOPY Size`

Use this command to set the NetBackup data buffer size in Bytes. The *Size* variable contains the number of data buffers.

`NetBackup DataBuffers Size NDMP Size`

Use this command to set the NetBackup data buffer size for NDMP (Network Data Management Protocol) in Bytes. The *Size* variable contains the number of data buffers.

`NetBackup Misc Defaults`

Use this command to show default value for miscellaneous NetBackup settings.

`NetBackup Misc Show`

Use this command to show all of the values for miscellaneous NetBackup settings.

`NetBackup Misc Tune DEFERRED_IMAGE_LIMIT Size`

Use this command to adjust the limit by which you want to defer an image. The default value is 64.

`NetBackup Misc Tune DPS_PROXYDEFAULTRECVTMO Time`

Use this command to adjust the timeout value for the DPS proxy default. The *Time* variable contains the timeout value. The default value is 800.

Settings > Password

Settings > Password – Change the user password.

SYNOPSIS

`Password UserName`

DESCRIPTION

Use this command to change the user password.

New passwords can be seven or eight characters in length. Seven character passwords must include all of the following requirements, while eight character passwords must include at least three:

one uppercase letter, one lowercase letter, one number (0-9), one special character.

Valid passwords must include the following:

- Eight or more characters
- At least one lowercase letter
- At least one number (0-9)

Uppercase letters and special characters can be included, but they are not required.

The following describes password restrictions:

- Dictionary words are considered weak passwords and are not accepted.
- The last seven passwords cannot be reused, and the new password cannot be similar to previous passwords.

OPTIONS

`Password UserName`

Use this command to change the password on your appliance. *UserName* is the name of the user.

Settings > Share

Settings > Share – Use this command to configure a media share.

SYNOPSIS

```
Share ClientInstall
```

DESCRIPTION

Use these commands to configure a media share for CIFS and NFS. You may open or close the client installation using these commands.

OPTIONS

```
Share ClientInstall Close
```

This command closes client installation media share for CIFS and NFS.

```
Share ClientInstall Open
```

This command opens client installation media share for CIFS and NFS.

Settings > Sysctl

`Settings > Sysctl` – Use this command to set, view, and list the sysctl parameter value.

SYNOPSIS

`ApplianceDefault`

`List`

`Show`

`Tune`

DESCRIPTION

This command lets you modify your sysctl parameter value. Sysctl is used to modify kernel parameters at runtime.

OPTIONS

`ApplianceDefault Parameter`

Use this command to set a parameter to the default value for the appliance installation. Here, *Parameter* is the name of the sysctl parameter.

`List`

Use this command to list the sysctl parameters that can be modified.

`Show Parameter`

Use this command to display the sysctl parameter value. Here, *Parameter* is the name of the sysctl parameter.

`Tune Parameter Value`

Use this command to set a sysctl parameter value. Here, *Parameter* is the name of the sysctl parameter and *Value* is the parameter value.

EXAMPLES

The following is an example of information that is displayed when you run the `Settings > Sysctl` command.

```
abc123.Sysctl> List
net.ipv4.tcp_keepalive_time
```

```
vm.zone_reclaim_mode  
vm.min_free_kbytes
```

See [“About the commands under the Settings view”](#) on page 26.

Settings > SystemLocale

`Settings > SystemLocale` – Use this command to change the system locale of the NetBackup Appliance to correctly display, backup, and restore the files and the folders that are named with non-7-bit ASCII characters. For example, Chinese, Japanese, Korean, German Umlaut, or French accents.

SYNOPSIS

```
SystemLocale List  
SystemLocale Set  
SystemLocale Show
```

DESCRIPTION

Use these commands to view or change the system locale of your appliance for international support.

OPTIONS

The following options are available under the SystemLocale command:

```
SystemLocale List Language
```

Use this command to list all available locales for a given language. Here, *Language* is the ISO 639-1 language code in 2 letters, for example, fr, ja, zh, fr, de, es, ru, and so on. This command displays all the system locales that are available and sorts them by the language code that you have specified.

```
SystemLocale Set Locale
```

Use this command to change the existing system locale of the appliance to another locale. Here, *Locale* is the value for a locale string.

If you want to back up a UNIX or a Linux system, you must set the appliance locale to the locale that your UNIX or Linux client is running on. For example, if your Solaris client is running on a French locale and it supports the Euro currency (fr_FR.ISO8859 -15), you must set *fr_FR@euro* as the system locale for your appliance.

Note: The locale names vary among various operating systems. The NetBackup Appliance uses the locale naming convention same as Red Hat Linux.

If you want to back up a Windows system, you must set an appropriate UTF-8 locale because the NetBackup client sends the path information to the NetBackup database by converting it from the active code page to UTF-8. For example, you have installed a NetBackup client into a German Windows server and you want to back up a file named with a “ß” (Eszett) letter on it. In this case, you must set *de_DE.UTF-8* as the system locale for your appliance.

Note: Do not set the appliance system locale as per the locale that is used by the active code page on which your Windows client is running.

SystemLocale Show

Use this command to view the current system locale on the appliance.

EXAMPLE

The following is an example of the information that is displayed when you run the Main > Setting > SystemLocale Show command.

```
abc123.Settings> SystemLocale Show
Current system locale is: en_US.UTF-8
```

The following is an example of the information that is displayed when you run the Main > Setting > SystemLocale List ja command. This command displays all Japanese locales that are currently available on the appliance.

```
abc123.Settings> SystemLocale List ja
ja_JP.UTF-8          ja_JP.eucJP          ja_JP.eucjp
ja_JP.shiftjisx0213  ja_JP.sjis           ja_JP.utf8
```

The following is an example of the information that is displayed when you run the Main > Setting > SystemLocale Set ja_JP.UTF-8 command.

```
abc123.Settings> SystemLocale Set ja_JP.UTF-8
Updating /etc/sysconfig/language ... ok
Updating /etc/init.d/netbackup ... ok
Updating /etc/init.d/nbappws ... ok
The appliance system locale has been set to ja_JP.UTF-8.
>> Reboot the appliance for the changes to take effect? (yes/no)yes
- [Info] Rebooting appliance ...
```

Broadcast message from root (pts/0) (Mon Jan 28 00:16:26 2013):

The system is going down for reboot NOW!

Main > Settings > Alerts view commands

This appendix includes the following topics:

- [Settings > Alerts > CallHome](#)
- [Settings > Alerts > Email](#)
- [Settings > Alerts > Hardware](#)
- [Settings > Alerts > SNMP](#)

Settings > Alerts > CallHome

Settings > Alerts > CallHome — Use this command to add appliance-specific and customer-specific information for Veritas Technical Support. Veritas Technical Support uses this information when your appliance encounters an issue and you require assistance to resolve the issue.

SYNOPSIS

```
CallHome Disable
CallHome Enable
CallHome NBInventory Disable
CallHome NBInventory Enable
CallHome Proxy Add name port [username] [passwd]
CallHome Proxy Disable
CallHome Proxy DisableTunnel
CallHome Proxy Enable
CallHome Proxy EnableTunnel
CallHome Registration ApplianceName ApplianceName
CallHome Registration City City
CallHome Registration CompanyName CompanyName
CallHome Registration ContactName Person
CallHome Registration Country Country
CallHome Registration Phone Number
CallHome Registration Setemail email
CallHome Registration Show
CallHome Registration State State
CallHome Registration Street Street
CallHome Registration ZipCode Zip
CallHome Show
CallHome Test
```


DESCRIPTION

The `CallHome` command provides important information about your appliance and yourself to Veritas Technical Support when an issue occurs. Use this command to enable or disable Call Home. This command lets you update the following information:

- The email address that Veritas Technical Support uses to contact you and resolve issues
- The address of the company and the phone number of the person to contact
- Details for the proxy servers

You can use the `CallHome Enable` and `CallHome Disable` commands to instruct the appliance whether or not to send the appliance health status to Veritas Technical Support. Veritas uses the health status to automatically open Support cases to resolve problems faster. The functionality is enabled by default.

You can use the `CallHome NBInventory Enable` and `CallHome NBInventory Disable` commands to instruct the appliance whether or not to send installation deployment and product usage information to Veritas for use in the quality improvement program. The functionality is enabled by default.

In addition, you can use the `CallHome Proxy` command to specify proxy server information. If your appliance environment has a proxy server between the environment and external Internet access, you must enable the proxy settings on the appliance. The proxy settings include both, a proxy server and a port. The proxy server must accept https connections from the Veritas Call Home server. This feature is disabled by default. To use this feature, the proxy server on your site must be able to handle https requests.

OPTIONS

`CallHome Disable`

This command disables the Call Home feature. Disabling Call Home also disables the Product Improvement Program.

`CallHome Enable`

This command enables the Call Home feature. Enabling the feature lets you send the health status of the appliance to Veritas Technical Support. In case of any failure, Veritas Technical Support uses this information to resolve the issue.

`CallHome NBInventory Disable`

This command disables the Product Improvement Program. Disabling the program prevents Veritas from capturing installation deployment and product usage information from your appliance.

`CallHome NBInventory Enable`

This command enables the Product Improvement Program. Enabling the program allows Veritas to capture installation deployment and product usage information. The information that Veritas receives becomes part of a continuous quality improvement program that helps Veritas understand how customers configure, deploy, and use the product.

You cannot enable the Product Improvement Program if Call Home is disabled.

`CallHome Proxy Add name port [username] [passwd]`

Use this command to add a proxy server to the appliance. Here, *name* is the name of the proxy server that is either the TCP/IP address or the fully qualified name of the proxy server. *Port* is the proxy port number on the proxy server. The [username] is the name of the user for the proxy server authentication and [passwd] is the password for the proxy server authentication.

If you do not add "http(s):" at the start of the server name then by default http:// is added to it.

`CallHome Proxy Disable`

Use this command to disable the use of the proxy server settings.

`CallHome Proxy DisableTunnel`

Use this command to disable SSL tunneling for the proxy server.

`CallHome Proxy Enable`

Use this command to enable the use of the proxy server settings.

`CallHome Proxy EnableTunnel`

Use this command to enable SSL tunneling for the proxy server.

`CallHome Registration ApplianceName ApplianceName`

Use this command to set a user name for the appliance. You must enter a value for the *ApplianceName* variable within double quotes.

`CallHome Registration City City`

Use this command to set a city for primary contact. You must enter a value for this variable within double quotes.

`CallHome Registration CompanyName CompanyName`

Use this command to set the name of your company as a primary contact. You must enter a value for this variable within double quotes.

`CallHome Registration ContactName Person`

Use this command to list a person as a primary contact. Here *Person* is the name of the person who is the first point of contact and responsible for the appliance. In case of any failure, Veritas tries to contact this person. You must enter a value for this variable within double quotes. To enter multiple contact names, separate the names with a comma.

`CallHome Registration Country Country`

Use this command set a country for primary contact. You must enter a value for this variable within double quotes.

`CallHome Registration Phone Number`

Use this command to enter the phone number of the contact person. Here, *Number* is the phone number of the contact person. You must enter a value for this variable within double quotes.

`CallHome Registration Setemail email`

Use this command to add an email address, where *email* is the email address of the contact person. To add multiple email addresses, use a semicolon as the separator.

`CallHome Registration Show`

Use this command to view registration details for the appliance.

`CallHome Registration State State`

Use this command to add a state as primary contact state. You must enter a value for this variable within double quotes.

`CallHome Registration Street Street`

Use this command to add a name or a number for street. You must enter a value for this variable within double quotes.

`CallHome Registration Zipcode Zip`

Use this command to set a ZIP Code or a PIN code. You must enter a value for this variable within double quotes.

`CallHome Show`

Use this command to view the Call Home and proxy settings that are currently configured for your appliance.

`CallHome Test`

Use this command to validate whether or not the appliance is able to send Call Home information to Veritas Technical Support.

EXAMPLES

The following example demonstrates how to add a proxy server to your appliance and the confirmation message that is returned.

```
Settings> Alerts> CallHome Proxy Add abc123.com 1234
```

```
Successfully set proxy server
```

The following example demonstrates how to disable the Call Home proxy server and the confirmation message that is returned.

```
Settings> Alerts> CallHome Proxy Disable
```

```
Successfully disabled proxy
```

The following example demonstrates how to disable SSL tunneling for the Call Home proxy server and the confirmation message that is returned.

```
Settings> Alerts> CallHome Proxy DisableTunnel
```

```
- [Info] Successfully added proxy tunnel flag
```

```
Successfully set proxy tunneling
```

The following example demonstrates how to add a proxy server to your appliance and the confirmation message that is returned.

```
Settings> Alerts> CallHome Proxy Enable
```

```
Proxy enabled successfully
```

The following example demonstrates how to enable SSL tunneling for the Call Home proxy server and the confirmation message that is returned.

```
Settings> Alerts> CallHome Proxy EnableTunnel
```

```
- [Info] Successfully added proxy tunnel flag
```

```
Successfully set proxy tunneling
```

The following example demonstrates how to add multiple contact names that are associated with the appliance.

```
Settings> Alerts> CallHome Registration ContactName "Jane Doe, John S"
```

```
Contact added successfully
```

To let Veritas Technical Support know where the appliance is physically located, run the following commands to add the country, state, and street.

```
Settings> Alerts> CallHome Registration Country "USA"
```

```
Country added successfully
```

```
Settings> Alerts> CallHome Registration State "CA"
```

```
State added successfully
```

```
Settings> Alerts> CallHome Registration Street "Ellis Street"
```

```
Street added successfully
```

The following example demonstrates how to add a phone number for the contact person.

```
Settings> Alerts> CallHome Registration Phone "1-555-555-5555"
```

```
Phone number added successfully
```

The following example demonstrates how to add multiple email addresses of the contacts that administer the appliance.

```
Settings> Alerts> CallHome Registration Setemail "john@abc.com"
```

```
Email address as been added successfully
```

The following is an example of the information that is displayed when you run the Settings > Alerts > CallHome Registration Show command.

```
Settings> Alerts> CallHome Registration Show
```

```
Registration Information
```

```
+-----+
| Contact Name |john          |
|-----+-----|
| Email ID    |john@abc.com |
|-----+-----|
| Contact Number |121          |
|-----+-----|
| Appliance Name |app          |
|-----+-----|
| Company Name  |Symantec     |
|-----+-----|
| Street Name/Number|Ellis street |
|-----+-----|
| City          |Mountain View|
|-----+-----|
```

Zip/Pin	9999
State	CA
Country	USA

The following is an example of information that is displayed when you run the `Settings > Alerts > CallHome Show` command.

```
abc123.Alerts> CallHome Show
CallHome and Proxy Settings
+-----+
| CallHome State |Disabled|
+-----+
|NBInventory State|Disabled|
+-----+
| Proxy State    |Disabled|
+-----+
| Tunnelling     |Enabled |
+-----+
| Proxy Server   |http://eng.symantec.com|
+-----+
| Proxy Port     |443      |
+-----+
| Proxy UserName |admin    |
+-----+
```

Note: NBInventory refers to the NetBackup Appliance Product Improvement Program

Settings > Alerts > Email

Settings > Alerts > Email — Use to configure email support for the appliance.

SYNOPSIS

```
Email Hardware Add Addresses
Email Hardware Delete Addresses
Email NotificationInterval time
Email SenderID Reset
Email SenderID Set Address
Email Show
Email SMTP Add Server [Account] [Password]
Email SMTP Delete
Email Software Add Addresses
Email Software Delete Addresses
```

DESCRIPTION

Use this command to add, replace, or show the email address that the appliance uses. You can use this command to define one or more emails.

OPTIONS

Email Hardware Add *Addresses*

Use to add or append a hardware administrator's email account for NetBackup to use.

Where *Addresses* is the user's email address. To define multiple emails, separate them with a semi-colon.

Email Hardware Delete *Addresses*

Use to delete a hardware administrator's email account for NetBackup to use.

Where *Addresses* is the user's email address. To define multiple emails, separate them with a semi-colon.

Email NotificationInterval *time*

Enables you to define the time span between the alert emails that are sent to the administrator.

Where *time* is the time between the alert emails that are sent to the administrator. This variable is defined in minutes.

Email SenderID Reset

Use this command to reset the current email ID to default email ID that is used for the emails that are received from the appliance.

Email SenderID Set Address

Use this command to set a sender email ID that is used for the emails that are received from appliance. Here, *Address* is the email address of the sender.

Email Show

Use this command to view your email or SMTP settings

Email SMTP Add Server [Account] [Password]

This command enables you to add an SMTP server that NetBackup can use.

The *Server* variable is the host name of the target SMTP server that is used to send emails. The *Account* option identifies the name of the account that was used or the authentication to the SMTP server. The *Password* option is the password for authentication to the SMTP server.

Email SMTP Delete

Use to delete the SMTP server that NetBackup uses.

Email SMTP Enable

Use to enable the SMTP server that NetBackup uses.

Email Software Add Addresses

Use to add or append a software administrator's email account for NetBackup to use.

Where *Addresses* is the user's email address. To define multiple emails, separate them with a semi-colon.

Email Software Delete Addresses

Use to delete a software administrator's email account for NetBackup to use.

Where *Addresses* is the user's email address. To define multiple emails, separate them with a semi-colon.

Settings > Alerts > Hardware

Settings > Alerts > Hardware — Use this command to set or view a threshold value for the disk space of any partition.

SYNOPSIS

```
Hardware DiskspaceThreshold Set
```

```
Hardware DiskspaceThreshold Show
```

DESCRIPTION

You can set a threshold value for a disk space using this command and receive alerts when the disk space of any partition passes this threshold value.

OPTIONS

```
Hardware DiskspaceThreshold Set DiskThreshold
```

Use this command to set a threshold value for the disk space. The default value for diskspace threshold is 80%. Here, the *DiskThreshold* variable defines a threshold value for the disk space in the range 1-99 in percent.

```
Hardware DiskspaceThreshold Show
```

Use this command to view the threshold value that is set for your disk space.

Settings > Alerts > SNMP

Settings > Alerts > SNMP – Add SNMP information on your media server that enables the media server to send SNMP notifications for hardware monitoring.

SYNOPSIS

SNMP Disable

SNMP Enable

SNMP Set *Server* [Community] [Port]

SNMP Show

SNMP ShowMIB

DESCRIPTION

The NetBackup appliance uses the SNMPv2-SMI application protocol to monitor appliance hardware. Use this command to add or change SNMP parameters on the server. You can use the following commands to display the current parameters and the changes that were made to the SNMP information. You can use this command to enable and disable SNMP notifications for hardware monitoring.

When you create and enable an SNMP community you enable hardware monitoring to occur on the appliance through the SNMP protocol. Notifications or traps are programmed to occur on the appliance hardware. In addition, you can use this command to see the notification traps that have been configured for the appliance. The following list is an example of the types of hardware notifications that are monitored through SNMP for the appliance:

- CPU
- Disk
- Fan
- Fibre Channel
- Power Supply
- RAID
- Temperature

OPTIONS

SNMP Disable

This command disables the ability to send SNMP notifications (traps) for hardware monitoring.

SNMP Enable

This command enables the ability to send SNMP notifications (traps) for hardware monitoring.

SNMP Set *Server* [Community] [Port]

This command lets you add information about SNMP. Here, *Server* is the name of the SNMP server, [Community] is the SNMP community, and [Port] is the SNMP port.

Note: The NetBackup Appliance supports all the SNMP servers in the market. However, the ManageEngine™ SNMP sever and the HP OpenView SNMP server are tested and certified for version 2.6 and later.

SNMP Show

This command displays the parameters that are set after you have run an `SNMP Set Server` command. If you run this command before you have run a `SNMP Set Server` command, then default values for [Community] and [Port] are displayed and no value is displayed for *Server*.

SNMP ShowMIB

Use this command to display the contents of the Management Information Base (MIB) file. This file contains the notification traps that are configured to monitor the appliance hardware.

EXAMPLES

You can use either of the following methods to configure a public SNMP community on port 8080. The example uses the [Community] and [Port] options.

```
abc123.Alerts> SNMP Set pqr222.xyz.com public 8080
Successfully set SNMP manager
```

When you run the `Settings> Alerts > SNMP ShowMIB` command, an output similar to the following is displayed.

```
SYMANTEC-APPLIANCE-MONITORING-MIB DEFINITIONS ::= BEGIN
```

```
IMPORTS
```

```
DisplayString, mib-2 FROM RFC1213-MIB
enterprises, OBJECT-TYPE, NOTIFICATION-TYPE, MODULE-IDENTITY FROM SNMPv2-

applianceMonitoringMib MODULE-IDENTITY
LAST-UPDATED "201408250000Z"
ORGANIZATION "Symantec Corporation"
CONTACT-INFO "350 Ellis Street
              Mountain View, CA 94043 US
              Subject: appliance.mib"
DESCRIPTION "The MIB module for Symantec Appliance Monitoring"

REVISION      "201408250000Z"
DESCRIPTION   "Add StorageStatus trap."

::= { products 9 }

symantecsoftware      OBJECT IDENTIFIER ::= { enterprises 393 }
products              OBJECT IDENTIFIER ::= { symantecsoftware 3 }

systems              OBJECT IDENTIFIER ::= { applianceMonitoringMib 1 }
software              OBJECT IDENTIFIER ::= { applianceMonitoringMib 2 }

-- system traps

symcssystemName OBJECT-TYPE
    SYNTAX DisplayString (SIZE(0..80))
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION "System Name"
    ::= { systems 1 }

symcfanTrap NOTIFICATION-TYPE
    OBJECTS { symcssystemName }
    STATUS current
    DESCRIPTION "Traps fan failures"
    ::= { systems 3 }

symcpowerTrap NOTIFICATION-TYPE
    OBJECTS { symcssystemName }
    STATUS current
    DESCRIPTION "Traps power failures"
    ::= { systems 4 }
```

```
symcfibrechannelTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Traps FibreChannel failures"
::= { systems 5 }

symctemperatureTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Traps temperature failures"
::= { systems 6 }

symccpuTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Traps cpu failures"
::= { systems 7 }

symcdiskTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Traps disk failures"
::= { systems 8 }

symcraidgroupTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Traps raid failures"
::= { systems 9 }

symcenclosurefanTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Traps enclosure fan failures"
::= { systems 10 }

symcenclosurepowerTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Traps enclosure power failures"
::= { systems 11 }
```

```
symcenclosuretemperatureTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Traps enclosure temperature failures"
::= { systems 12 }
```

```
symcenclosurediskTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Traps enclosure disk failures"
::= { systems 13 }
```

```
symcadapterTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Traps adapter failures"
::= { systems 14 }
```

```
symcfirmwareTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Traps firmware failures"
::= { systems 15 }
```

```
symcpciTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Traps pci failures"
::= { systems 16 }
```

```
symcnetworkcardTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Traps network card failures"
::= { systems 17 }
```

```
symcvolumeTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Traps volume failures"
::= { systems 18 }
```

```
symcbbuTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Traps BBU failures"
::= { systems 19 }

symcconnectionTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Traps connection failures"
::= { systems 20 }

symcpartitionTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Partition alert traps"
::= { systems 21 }

symcstoragestatusTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Traps StorageArray HealthStatus failures"
::= { systems 22 }

-- software traps

symcfailedJobsTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Job failures Trap"
::= { software 1 }

symcprocessTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Processes stopped traps"
::= { software 2 }

symcdiskSpaceTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Low disk space traps"
::= { software 3 }
```

```
symcsoftwareUpdateSuccessTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Software update success trap"
::= { software 4 }

symcsoftwareUpdateFailedRollbackSuccessTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Software update failed but rollback was successful trap"
::= { software 5 }

symcsoftwareUpdateFailedRollbackFailedTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Software update and rollback failed trap"
::= { software 6 }

symcrollbackSuccessTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Software rollback success trap"
::= { software 7 }

symcrollbackFailedTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Software rollback failed trap"
::= { software 8 }

symccclusterStateTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Cluster node failed trap"
::= { software 9 }

symcdiskPerfTrap NOTIFICATION-TYPE
    OBJECTS { symcsystemName }
    STATUS current
    DESCRIPTION "Disk performance alert trap"
::= { software 10 }
```


END

See [“About NetBackup Appliance Shell Menu usage”](#) on page 11.

Main > Settings > Notifications view commands

This appendix includes the following topics:

- [Settings > Notifications > LoginBanner](#)

Settings > Notifications > LoginBanner

Settings > Notifications > LoginBanner – set and manage a text banner that appears before a user logs on to the appliance.

SYNOPSIS

Remove

Set

Show

SyncNetBackup

DESCRIPTION

The `LoginBanner` command lets you create a text banner message for your appliance that appears before a user logs on through one of the appliance.

When you set a login banner, it appears with the following appliance login methods:

- NetBackup Appliance Shell Menu
- IPMI console session
- NetBackup Appliance Web Console
- NetBackup Administration Console (optional)

Note: Before NetBackup Appliance 2.6.1.2, the name of this command was `PolicyBanner`.

OPTIONS

Remove

Removes the current login banner from the appliance. The option is also given to remove the login banner from the NetBackup Administration Console.

Set

Set a new appliance login banner. When you use this option, the appliance prompts you to enter a login banner heading and message to be displayed when a user tries to log on to the appliance.

The banner heading and banner message are both mandatory. Typing **return** for the heading text or the message text exits the banner configuration without saving any changes.

Login banner text parameters:

- Banner heading maximum characters: 250
- Banner message maximum characters: 29,000
- Standard English alphabet

Show

View the current login banner.

SyncNetBackup

Set the existing appliance login banner in the NetBackup Administration Console. This command overwrites the existing NetBackup login banner content with the appliance login banner content. If you run this command when there is no existing appliance login banner, the NetBackup login banner is removed.

EXAMPLES

Example 1 - set a new login banner for the appliance and NetBackup using the `LoginBanner Set` command:

```
appliance123.Notifications> LoginBanner Set
Enter a heading for the login banner (250 characters limit) or type
'return' to exit:
```

This is a test banner heading

Enter the message text for the login banner (type 'end' on a new line to indicate the end of message text):

This is a test banner message.
end

Preview:

```
*****
This is a test banner heading
*****
```

This is a test banner message.

The existing banner will be overwritten and the SSH daemon will be restarted. Do you want to proceed? [y,n]: (y) **y**
Setting the login banner... **done**

```
Do you want to use this banner for the NetBackup Administration
Console as well? (Any existing NetBackup login banner will
be overwritten.) [y,n]: (y) y
Setting the login banner in NetBackup... done
```

Once the login banner is set, it displays for any user that tries to access the appliance using SSH and IPMI. See the following example:

```
ssh admin@appliance123.com
*****
This is a test banner heading
*****
```

This is a test banner message.

Password:

Example 2 - remove the login banner from the appliance and NetBackup using the LoginBanner Remove command:

```
appliance123.Notifications> LoginBanner Remove
The existing banner will be removed and the SSH daemon
will be restarted. Do you want to proceed? [y,n]: (y) y
Removing the login banner... done
```

```
Do you want to remove the banner from the NetBackup
Administration Console as well? [y,n]: (y) y
Removing the login banner from NetBackup... done
```

Example 3 - Set the current Appliance login banner to the NetBackup Administration Console using the LoginBanner SyncNetBackup command:

```
appliance123.Notifications> LoginBanner SyncNetBackup
Are you sure you want to use the current appliance login banner
for the NetBackup Administration Console as well?
(Any existing NetBackup login banner will be overwritten.) [y, n]: (y) y
Setting the login banner in NetBackup... done
```

Main > Settings > Security view commands

This appendix includes the following topics:

- [Settings > Security > Authorization](#)

Settings > Security > Authorization

Settings > Security > Authorization – authorize users to access the appliance by assigning them various roles (permissions).

SYNOPSIS

```
Grant  
List  
Revoke  
SyncGroupMembers
```

DESCRIPTION

The `Authorization` commands let you manage permissions for appliance users and user groups. The users include local users, LDAP users, Active Directory (AD) users, and NIS users. The user groups include LDAP user groups, AD user groups, and NIS user groups.

You can use the `Authorization` commands to do the following:

- Grant access privileges to the users and user groups that have been added to the appliance.
- List all of the users and user groups that have been added to the appliance, along with their designated permissions.
- Revoke access privileges from the users and user groups that have been added to the appliance.

OPTIONS

```
Grant Administrator Group groups
```

Grant the Administrator role to a user group. Here, *groups* is a comma-separated list of registered user groups that have been added to the appliance from a configured remote directory service (such as LDAP, AD, or NIS).

```
Grant Administrator Users users
```

Grant the Administrator role to a user. Here, *users* is a comma-separated list of local users, or registered users that have been added to the appliance from a configured remote directory service (such as LDAP, AD, or NIS).

Grant NetBackupCLI Group *groups*

Grant the NetBackupCLI role to a user group. Here, *groups* is a comma-separated list of registered user groups that have been added to the appliance from a configured remote directory service (such as LDAP, AD, or NIS).

Grant NetBackupCLI Users *users*

Grant the NetBackupCLI role to a user. Here, *users* is a comma-separated list of registered users that have been added to the appliance from a configured remote directory service (such as LDAP, AD, or NIS).

Note: You cannot grant the NetBackupCLI role to an existing local user. However, you can create a local NetBackupCLI user by using the `Main_Menu > Manage > NetBackupCLI > Create` command from the NetBackup Appliance Shell Menu.

Note: NetBackupCLI users are solely restricted to run the NetBackup CLI and do not have access outside the scope of NetBackup software directories. Once these users log in, they are provided restricted access to the NetBackup Appliance Shell Menu for managing NetBackup. These users do not have access to NetBackup Appliance Web Console or the other menus of the NetBackup Appliance Shell Menu.

List

List all of the users and user groups that have been added to the appliance, along with their designated roles. The users include local users, or the registered users that have been added to the appliance from a configured remote directory service (such as LDAP, AD, or NIS). The user groups include those that have been added to the appliance from a configured remote directory service (such as LDAP, AD, or NIS).

Revoke Administrator Group *groups*

Revoke the Administrator role from a user group. Here, *groups* is a comma-separated list of registered user groups that have been added to the appliance from a configured remote directory service (such as LDAP, AD, or NIS).

Revoke Administrator Users *users*

Revoke the Administrator role from a user. Here, *users* is a comma-separated list of local users, or registered users that have been added to the appliance from a configured remote directory service (such as LDAP, AD, or NIS).

`Revoke NetBackupCLI Group groups`

Revoke the NetBackupCLI role from a user group. Here, *groups* is a comma-separated list of registered user groups that have been added to the appliance from a configured remote directory service (such as LDAP, AD, or NIS).

`Revoke NetBackupCLI Users users`

Revoke the NetBackupCLI role from a user. Here, *users* is a comma-separated list of local users, or registered users that have been added to the appliance from a configured remote directory service (such as LDAP, AD, or NIS).

`SyncGroupMembers AddTask HHMM`

Use this command to add a daily task that is synchronized for registered groups. Here, *HHMM* is the time of the day in hours and minutes.

`SyncGroupMembers DeleteTask`

Delete the daily tasks that are synchronized for registered groups.

`SyncGroupMembers Now`

Force synchronization for registered groups now.

`SyncGroupMembers ShowTask`

View the daily tasks that are synchronized for registered groups.

Main > Settings > Security > Authentication view commands

This appendix includes the following topics:

- [Settings > Security > Authentication > ActiveDirectory](#)
- [Settings > Security > Authentication > Kerberos](#)
- [Settings > Security > Authentication > LDAP](#)
- [Settings > Security > Authentication > LocalUser](#)

Settings > Security > Authentication > ActiveDirectory

Settings > Security > Authentication > ActiveDirectory – configure and manage Active Directory (AD) user registration and authentication on the appliance.

SYNOPSIS

Configure

Groups

List

Status

Unconfigure

Users

DESCRIPTION

You can use the `ActiveDirectory` command to perform the following tasks:

- Configure the appliance for AD user authentication.
- Add or remove one or more AD user groups.
- List all AD users and user groups.
- Add or remove one or more AD users.
- Unconfigure AD user authentication for the appliance.

OPTIONS

The following commands and options are available under `Authentication > ActiveDirectory`:

Configure

Configure the appliance for AD user authentication.

Groups

Add or remove one or more AD user groups. Only the user groups that already exist on the AD server can be added to the appliance.

- Use the `Groups Add <groupname>` command to add a comma-separated list of AD user groups.

- Use the `Groups Remove <groupname>` command to delete a comma-separated list of AD user groups.

List

List all of the AD users and user groups that have been added to the appliance.

Status

View the status of AD authentication on the appliance.

Unconfigure

Unconfigure AD user authentication for the appliance.

Note: Before you unconfigure the AD server, you must revoke the roles from all of the AD users that have been added to the appliance. Otherwise the operation fails.

Warning: Unconfiguring AD user authentication disables and deletes the current AD configuration. The AD users are deleted from the appliance, but not from the AD server.

Users

Add or remove one or more AD users. Only the users that already exist on the AD server can be added to the appliance.

- Use the `Users Add <username>` command to add a comma-separated list of AD users.
- Use the `Users Remove <username>` command to delete a comma-separated list of AD users.

Note: As a matter of best practice, you should delete a registered user or user group from the appliance before deleting it from the LDAP server, AD server, or NIS server. If a user is removed from the remote directory service first (and not removed from appliance), the user is listed as a registered user on the appliance but won't be able to log on.

Settings > Security > Authentication > Kerberos

Settings > Security > Authentication > Kerberos – configure and manage Network Information Service (NIS) user registration with Kerberos authentication on the appliance.

SYNOPSIS

Configure

Groups

List

Status

Unconfigure

Users

DESCRIPTION

You can use the `Kerberos` command to perform the following tasks:

- Configure the appliance for NIS-Kerberos user authentication.
- Add or remove one or more NIS user groups.
- List all NIS users and user groups.
- Add or remove one or more NIS users.
- Unconfigure NIS-Kerberos user authentication for the appliance.

OPTIONS

The following commands and options are available under `Authentication > Kerberos`:

Configure

Configure the appliance for NIS-Kerberos user authentication.

- Use the `Configure NIS <NIS Server FQDN or IP> <NIS Domain> <KDC Server FQDN or IP> <Kerberos Default Realm> [<Kerberos Default Domain>]` command to add and configure NIS-Kerberos user authentication.

Note: The `Kerberos Default Domain` parameter is not required to complete NIS-Kerberos configuration.

Groups

Add or remove one or more NIS user groups. Only the user groups that already exist on the NIS server can be added to the appliance.

- Use the `Groups Add <groupname>` command to add a comma-separated list of NIS user groups.
- Use the `Groups Remove <groupname>` command to delete a comma-separated list of NIS user groups.

List

List all of the NIS users and user groups that have been added to the appliance.

Status

View the status of NIS-Kerberos authentication on the appliance.

Unconfigure

Unconfigure NIS-Kerberos user authentication for the appliance.

Note: Before you unconfigure the NIS-Kerberos server, you must revoke the roles from all of the NIS users that have been added to the appliance. Otherwise the operation fails.

Warning: Unconfiguring NIS-Kerberos user authentication disables and deletes the current NIS-Kerberos configuration. The NIS users are deleted from the appliance, but not from the NIS server.

Users

Add or remove one or more NIS users. Only the users that already exist on the NIS server can be added to the appliance.

- Use the `Users Add <username>` command to add a comma-separated list of NIS users.
- Use the `Users Remove <username>` command to delete a comma-separated list of NIS users.

Note: As a matter of best practice, you should delete a registered user or user group from the appliance before deleting it from the LDAP server, AD server, or NIS server. If a user is removed from the remote directory service first (and not removed from appliance), the user is listed as a registered user on the appliance but won't be able to log on.

Settings > Security > Authentication > LDAP

Settings > Security > Authentication > LDAP – configure and manage Lightweight Directory Access Protocol (LDAP) user registration and authentication on the appliance.

SYNOPSIS

Attribute
Certificate
ConfigParam
Configure
Disable
Enable
Export
Groups
Import
List
Map
Show
Status
Unconfigure
Users

DESCRIPTION

You can use the `LDAP` command to perform the following tasks:

- Add or delete LDAP configuration attributes.
- Set or show the trusted LDAP server certificate.
- Set, unset, or show the various LDAP configuration parameters.
- Configure the appliance for LDAP user authentication.
- Disable LDAP user authentication.
- Enable LDAP user authentication.

- Export LDAP configuration as an XML file.
- Add or remove one or more LDAP user groups.
- Import LDAP configuration from an XML file.
- List all LDAP users and user groups.
- Add, delete, or show NSS map attributes or object classes.
- Show the LDAP configuration.
- Show the status of LDAP authentication.
- Unconfigure LDAP user authentication for the appliance.
- Add or remove one or more LDAP users.

OPTIONS

The following commands and options are available under `Authentication > LDAP`:

Attribute

Add or delete LDAP configuration attributes.

- Use the `Attribute Add <parameter_name> <attribute>` command to add a new attribute.
- Use the `Attribute Delete <attribute_name>` command to delete an existing attribute.

Certificate

Set, view, or disable the SSL certificate.

- Use the `Certificate Set <filename>` command to enable and add the SSL certificate. The SSL certificate must be stored in the `/inst/patch/incoming` directory.

Note: When you use the `ssl=StartTLS` and `ssl=Yes` options during LDAP or AD configuration on the appliance, the initial setup is done over a non-SSL channel. After the LDAP connection and initial discover phase is over, the SSL channel is turned on. Even at this phase, establishing the SSL channel does not perform the server-side certificate validation. This validation starts after the server's root certificate is explicitly set using the **LDAP > Certificate Set <path>** option.

- Use the `Certificate Show` command to view the certificate applicable for the LDAP server.

- Use the `Certificate Unset` command to disable the SSL certificate.

`ConfigParam`

Set, view, and unset the LDAP configuration parameters.

Note: The `ConfigParam` command is only used to set the various LDAP configuration parameters. Once you set all of the necessary parameters, use the `Configure` command to enable the LDAP configuration and establish a connection with the LDAP server.

- Use the `ConfigParam Set` command to add or change the following LDAP configuration parameters:

* Required parameters

- `*ConfigParam Set base <base_DN>`

Enter the base directory name which is the top level of the LDAP directory tree.

- `ConfigParam Set binddn <bind_DN>`

Enter the bind directory name. The bind DN is used as an authentication to externally search the LDAP directory within the defined search base.

- `ConfigParam Set bindpw <password>`

Enter the password to access the LDAP server.

- `ConfigParam Set groupList <group_name(s)>`

Enter the name of an existing LDAP user group that resides on the LDAP server. To enter multiple groups, separate each group name with a comma (,).

- `*ConfigParam Set host <server_name or IP>`

Enter the FQDN or IP address of the LDAP server.

Note: The specified LDAP server should comply with RFC 2307bis. The RFC2307bis specifies that hosts with IPv6 addresses must be written in their preferred form, such that all components of the address are indicated and leading zeros are omitted.

- `*ConfigParam Set ssl <No|Yes|StartTLS>`

Enable SSL certificate for the LDAP server.

Note: When you use the `StartTLS` and `Yesoptions` during LDAP configuration, the initial setup is done over a non-SSL channel. After the LDAP connection and initial discover phase is over, the SSL channel is turned on. Even at this phase, the established SSL channel doesn't do the server-side certificate validation. This validation starts after the server's root certificate is explicitly set using the `LDAP > Certificate Set` command.

- `ConfigParam Set userList <user_name(s)>`
Enter the name of an existing LDAP user that resides on the LDAP server. To enter multiple users, separate each user name with a comma (.).
- Use the `ConfigParam Show` command to view the existing LDAP configuration parameters.
- Use the `ConfigParam Unset <parameters>` command to unset the LDAP configuration parameters.

Configure

Configure the appliance for LDAP user authentication.

After setting the LDAP parameters using the `ConfigParam` command, run the `Configure` command to complete the configuration and enable LDAP authentication on the appliance.

Disable

Disable LDAP user authentication on the appliance. This command does not remove the configuration and you can reenable it using the `Enable` command.

Enable

Enable a disabled LDAP configuration on the appliance.

Export <file_name>

Export the existing LDAP configuration as an XML file. The file is saved at `/inst/patch/incoming/<file_name>`. This file can be imported to configure LDAP on other appliances.

Groups

Add or remove one or more LDAP user groups. Only the user groups that already exist on the LDAP server can be added to the appliance.

- Use the `Groups Add <groupname>` command to add a comma-separated list of LDAP user groups.

- Use the `Groups Remove <groupname>` command to delete a comma-separated list of LDAP user groups.

Import `<path>`

Import the LDAP configuration from an XML file. The XML file must reside at `/inst/patch/incoming/<file_name>`.

List

List all of the LDAP users and user groups that have been added to the appliance.

Map

Add, delete, or show NSS map attributes.

- Use the `Map Add` command to set the NSS map attributes.
- Use the `Map Delete` command to delete the NSS map attributes.
- Use the `Map Show` command to view the NSS map attributes.

Show

View the LDAP configuration details.

Status

View the status of LDAP authentication on the appliance.

Unconfigure

Unconfigure LDAP user authentication for the appliance.

Note: Before you unconfigure the LDAP server, you must revoke the roles from all of the LDAP users that have been added to the appliance. Otherwise the operation fails.

Warning: Unconfiguring LDAP user authentication disables and deletes the current LDAP configuration. The LDAP users are deleted from the appliance, but not from the LDAP server.

Users

Add or remove one or more LDAP users. Only the users that already exist on the LDAP server can be added to the appliance.

- Use the `Users Add <username>` command to add a comma-separated list of LDAP users.
- Use the `Users Remove <username>` command to delete a comma-separated list of LDAP users.

Note: As a matter of best practice, you should delete a registered user or user group from the appliance before deleting it from the LDAP server, AD server, or NIS server. If a user is removed from the remote directory service first (and not removed from appliance), the user is listed as a registered user on the appliance but won't be able to log on.

EXAMPLES

Example 1 - Configure an association between the appliance and an LDAP directory server to enable the appliance to import users and user groups.

```
appliance123.LDAP > ConfigParam Set host ldap.example.com
appliance123.LDAP > ConfigParam Set base dc=sample,dc=com
appliance123.LDAP > ConfigParam Set ssl no
appliance123.LDAP > Configure
- [Info] Configure Successful. Continuing with Post-Configure Processing!
Configure Successful. Continuing with Post-Configure Processing!
```

Command was successful!

Example 2 - Register a user or user group from the LDAP directory server so that those users can be authorized and authenticated on the appliance.

```
appliance123.LDAP> Users Add ldapuser1,ldapuser2
Command was successful!
appliance123.LDAP> Groups Add ldapgrou01
Command was successful!
appliance123.Authorization> List
```

```
+-----+
|Principal Type|Name/login |Access | Role |Principal Source|
|-----+-----+-----+-----+-----+
|User          |ldapuser1  |Allowed|NoRole|Ldap            |
|-----+-----+-----+-----+-----+
|User          |ldapuser2  |Allowed|NoRole|Ldap            |
|-----+-----+-----+-----+-----+
|Group         |ldapgrou01 |Allowed|NoRole|Ldap            |
|-----+-----+-----+-----+-----+
| -Member      |ldapuser3  |Allowed|      |                |
+-----+-----+-----+-----+-----+
```

Command was successful!

Example 3 - Export the current LDAP configuration into an XML file that can be imported on other appliances.

```
appliance123.LDAP> Export ldapconfig1  
- [Info] Exporting LDAP configuration  
Exporting LDAP configuration
```

Command was successful!

Example 4 - Import an LDAP configuration from an XML file.

```
appliance123.LDAP> Export ldapconfig1  
- [Info] Exporting LDAP configuration  
Exporting LDAP configuration
```

Command was successful!

Settings > Security > Authentication > LocalUser

Settings > Security > Authentication > LocalUser – create and manage local users on the appliance.

SYNOPSIS

Clean

List

Password

Users

DESCRIPTION

You can use the `LocalUser` command to perform the following tasks:

- Delete all local users.
- List all local users.
- Change local user password.
- Add or remove one or more local users.

OPTIONS

The following commands and options are available under `Authentication > LocalUser`:

Clean

Delete all of the local users.

List

List all of the local users that have been added to the appliance.

Password

Change the password of a local user.

Users

Add or remove one or more local users.

- Use the `Users Add <username>` command to add a comma-separated list of local users.
- Use the `Users Remove <username>` command to delete a comma-separated list of local users.

Main > Support view commands

This appendix includes the following topics:

- [Support > Checkpoint](#)
- [Support > Cleanup > RemoveShelfEntries](#)
- [Support > DataCollect](#)
- [Support > Disk](#)
- [Support > Errors](#)
- [Support > FactoryReset](#)
- [Support > InfraServices](#)
- [Support > iostat](#)
- [Support > IPMI](#)
- [Support > KillRemoteCall](#)
- [Support > Logs](#)
- [Support > Maintenance](#)
- [Support > Messages](#)
- [Support > NBDNA](#)
- [Support > nbperfchk](#)
- [Support > NBSU](#)

- [Support > Processes](#)
- [Support > Reboot](#)
- [Support > RecoverStorage](#)
- [Support > Service](#)
- [Support > ServiceAllowed](#)
- [Support > Show](#)
- [Support > Shutdown](#)
- [Support > Storage Reset](#)
- [Support > Storage SanityCheck](#)
- [Support > Test](#)

Support > Checkpoint

Support > Checkpoint – Used to manage system checkpoints

SYNOPSIS

Checkpoint Create

Checkpoint Rollback

DESCRIPTION

This command exists under the `Main_Menu > Support` view. Use this command to create a new checkpoint or rollback the hosts to an existing appliance checkpoint.

OPTIONS

Checkpoint Create

Use this command to create a user-defined checkpoint.

Checkpoint Rollback

Use this command to rollback an appliance to a specific checkpoint that you select. You can chose from the following checkpoints:

- Pre-upgrade checkpoint
A checkpoint that is created before you perform a software upgrade.
- Post-upgrade checkpoint
A checkpoint that is created after you have upgraded your appliance to a newer version.
- User-directed checkpoint
A checkpoint that you created.

EXAMPLES

The following examples demonstrate how to create a new user-defined checkpoint and to rollback to specified checkpoint.

To create a new checkpoint from the NetBackup Appliance Shell Menu:

- 1 Log on to the appliance as an administrator and open the NetBackup Appliance Shell Menu.

- 2 Enter the following command to

```
Main_Menu > Support > Checkpoint Create
```

The following interactive process begins. The NetBackup Appliance Shell Menu informs you of any existing checkpoints before you can create a new checkpoint. In the following example, no existing checkpoints exist.

- 3 Enter **Yes** to proceed with the creation of the new checkpoint.
- 4 Enter a description for your checkpoint. That is an optional field.
- 5 Enter **Yes** to begin the Create checkpoint process.

To roll back to an existing checkpoint from the NetBackup Appliance Shell Menu

- 1 Log on to the appliance as an administrator and open the NetBackup Appliance Shell Menu.
- 2 Enter the following command to

```
Main_Menu > Support > Checkpoint Rollback
```

The following interactive process begins. The NetBackup Appliance Shell Menu informs you of the components that are reverted during this process. It also lists all of the existing checkpoints.

Rolling back to an Appliance Checkpoint will restore the system back to the checkpoint's point-in-time. This can help undo any misconfiguration or system failures that might have occurred.

Rolling back to an Appliance Checkpoint will revert the following components:

- 1) Appliance Operating System
- 2) Appliance Software
- 3) NetBackup Software
- 4) Clustering Software
- 5) Networking Configuration
- 6) Any previously applied patches
- 7) Backup data is not reverted

The existing Appliance Checkpoints in the system are:

```
-----  
(1) Checkpoint Name: User directed checkpoint  
Date Created: Fri Oct 5 09:27:32 2012  
Description: User checkpoint after configuring network  
-----
```

Please enter the checkpoint to rollback to (Available options: 1 only):

- 3 Enter the number of the checkpoint that you want to use for the Rollback operation.
- 4 Enter **Yes**, if you want to automatically restart all appliances after the rollback completes.

- 5 Enter **Yes** a second time to confirm that you want to restart appliances automatically after the rollback operation completes.
- 6 Enter **Yes** to begin the rollback to a checkpoint operation.

The following status is provided once the Rollback operation is started.

Support > Cleanup > RemoveShelfEntries

Support > Cleanup > RemoveShelfEntries – Used to remove hardware monitoring data that is associated with the decommissioned storage shelves. This command applies to 52xx platforms (5220 and later) and must be run under the guidance of Technical Support.

SYNOPSIS

```
RemoveShelfEntries
```

DESCRIPTION

This command exists under the `Main_Menu > Support > Cleanup` view. After the storage shelves have been decommissioned, this command must be run to clear the hardware monitoring data that is associated with the storage shelves. This command removes the storage shelf entries from the database.

Note: This command must be run under the guidance of Technical Support

OPTIONS

```
RemoveShelfEntries
```

After the storage shelves have been decommissioned, this command must be run to clear the hardware monitoring data that is associated with the storage shelves. This command removes the storage shelf entries from the database.

EXAMPLES

The following example demonstrates how to run the Support > Cleanup > RemoveShelfEntries command:

```
abcxxx.Cleanup> RemoveShelfEntries
>> Do you want to remove hardware monitoring data for
    the decommissioned storage shelves?[yes, no](no): yes
    12 records deleted
    Successfully deleted storage shelf entries.
```

Support > DataCollect

Support > DataCollect – Gather device logs.

SYNOPSIS

DataCollect

DESCRIPTION

This command exists under the `Main_Menu > Support` view. Use this command to gather NetBackup 52xx Device Logs.

OPTIONS

DataCollect

Use to gather NetBackup 52xx Device Logs.

EXAMPLES

The following procedure is executed after you run the `DataCollect` command.

```
abc123.Support> DataCollect
touch: cannot touch `/log/upload/APPLIANCE_SN_XYZ0000248.txt':
No such file or directory
Gathering release information
Gathering dmidecode logs
Gathering /dev/sg2 sg_ses logs
Gathering ipmitool sel list logs
Gathering fwtermlog logs
Gathering AdpEventLog logs
Gathering smartctl logs
Gathering disk performance logs
Gathering ipmiutil command output
Gathering sg_ses failure output
Gathering cpu information
Gathering memory information
Gathering sdr logs
Gathering adpallinfo logs
Gathering encinfo logs
Gathering cfgdsply logs
Gathering ldpdinfo logs
Gathering pdlist logs
```

Gathering fru logs
Gathering adpbucmd logs
Gathering os logs
Gathering adpalilog logs
Gathering dfinfo logs
Gathering vxprint logs
Gathering Test Hardware logs
Gathering patch logs

All logs have been collected in /tmp/DataCollect.zip
Log file can be collected from the appliance shared folder -
\\abc123.engba.symantec.com\logs\APPLIANCE
Share can be opened using Main->Support->Logs->Share Open

=====End of DataCollect=====

All logs have been collected in /tmp/DataCollect.zip

Support > Disk

Support > Disk – Gather disk information

SYNOPSIS

Disk info

DESCRIPTION

This command exists under the `Main_Menu > Support` view. Use this command to gather and display information about the local disk layout and usage.

OPTIONS

Disk info

Use to gather disk information and display the disk layout and usage information.

Support > Errors

`Support > Errors` – Display NetBackup error logs.

SYNOPSIS

`Errors HoursAgo`

DESCRIPTION

This command exists under the `Main > Support` view. The `Errors` command displays all the recorded problem entries in the NetBackup logs for the previous day. You can designate the number of hours that you want to go back and display.

OPTIONS

`Errors`

Displays the NetBackup error logs of the previous day. Here, *HoursAgo* specifies the number of hours in the past from the current time. *HoursAgo* is an integer. The default is 24 hours before the current time.

Support > FactoryReset

Support > FactoryReset – Reset the appliance to factory default settings.

SYNOPSIS

```
FactoryReset
```

```
FactoryReset NoPrompt
```

DESCRIPTION

This command exists under the `Main_Menu > Support` view. You can use this command to reset the appliance to the factory default settings. If you had changed the initial password to something else and you run this command, your password is reset to the initial default value.

OPTIONS

```
FactoryReset
```

Use this command to reset the appliance to the factory default settings.

```
FactoryReset NoPrompt
```

Use this command to reset the appliance factory installed image in non-interactive mode.

EXAMPLES

To begin a factory reset from the appliance shell menu

- 1 Open an SSH session and log on to the appliance as an administrator.
- 2 Enter `Main_Menu > Support > FactoryReset`. This command shows the following messages and requires you to answer the following questions before the factory reset begins.

Appliance factory reset will reset the entire system to the factory installed image. The appliance will have the following components reset to the factory restored settings/image:

- 1) Appliance Operating System
- 2) Appliance Software
- 3) NetBackup Software
- 4) Tape media configuration on the master server
- 5) Networking configuration
- 6) Storage configuration and backup data (optionally retain)

```
- [Info] Running factory reset validation...please wait (approx 2 mins)
- [Info] Factory reset validation successful.
```

RESET NETWORK CONFIGURATION [Optional]

- Resets the IP and routing configuration.
- Resets the DNS configuration.

```
>> Do you want to reset the network configuration? [yes/no] (yes) no
```

RESET STORAGE CONFIGURATION and BACKUP DATA [Optional]

- Removes all the images on the AdvancedDisk and MSDP storage pools.
- Resets the storage partitions.
- Resets storage expansion units, if any.

```
>> Do you want to delete images and reset backup data? [yes/no] (yes)
```

```
>> Resetting the storage configuration will remove all backup
data on the storage partitions and any connected expansion
units. This is not reversible. Are you sure you want to
reset storage configuration? [yes/no] (yes)
```

```
>> A reboot of the appliance is required to complete the factory reset.
Reboot automatically after reset? [yes/no] (no) yes
```

```
>> Automatically rebooting after the reset will not provide you with an
opportunity to review the progress/final status of the reset. Are you sure
you would like to automatically reboot? [yes/no] (no) yes
```

3 After you respond to these questions, the following summary information is shown:

FACTORY RESET SUMMARY

Reset Appliance OS, software configuration : [YES]
Reset Appliance network configuration : [NO]
Reset Appliance storage configuration (REMOVE DATA) : [YES]
Auto reboot after reset? : [YES]

Appliance will make the following version changes:

+-----+			
Appliance	Current Version	Reverted Version	
+-----+			
v49	NetBackup 7.6.0.1 Appliance	NetBackup 7.6.0.1 Appliance	
	2.6.0.1	2.6.0.1	
+-----+			

4 The following warning appears. If you want to begin the factory reset operation, enter **Yes**.

```
WARNING: an Appliance Factory reset cannot be reversed!  
Continue with factory reset? yes
```

The following summary messages appear as the factory reset continues:

```
- [Info] PERFORMING APPLIANCE RESET TO FACTORY STATE ON : app2.symantec.com  
- [Info] Delete checkpoints (type: NON_FACT) succeeded  
- [Info] Reset of the appliance to FACTORY STATE successful.  
- [Info] Stopping NetBackup processes... (6 mins approx)  
- [Info] Moving NetBackup Appliance Directory to ce-win21-urmil...  
- [Info] Acquired lock on the storage.  
- [Info] Resetting the storage configuration...  
- [Info] Checking whether the 'MSDP' storage partition exists...  
- [Info] Initiating deletion of 'MSDP' storage partition...  
- [Info] Unmounting the 'MSDP' partition '0'...  
- [Info] Deleting the 'MSDP' partition '0'...  
- [Info] Checking whether the 'Catalog' storage partition exists...  
- [Info] Initiating deletion of 'Catalog' storage partition...  
- [Info] Unmounting the 'Catalog' partition '0'...  
- [Info] Deleting the 'Catalog' partition '0'...  
- [Info] Checking whether the 'Configuration' storage partition exists...  
- [Info] Initiating deletion of 'Configuration' storage partition...  
- [Info] Unmounting the 'Configuration' partition '0'...  
- [Info] Deleting the 'Configuration' partition '0'...  
- [Info] Checking whether the 'AdvancedDisk' storage partition exists...  
- [Info] Initiating deletion of 'AdvancedDisk' storage partition...  
- [Info] Unmounting the 'AdvancedDisk' partition '0'...  
- [Info] Deleting the 'AdvancedDisk' partition '0'...  
- [Info] Removing the storage configuration...  
- [Warning] Failed to query SCSI device '/dev/system/root'.  
  
- [Warning] Failed to query SCSI device '/dev/system/root'.  
>> A reboot of the appliance is required to complete the factory reset.  
    Reboot now?[yes/no] (no)yes  
Rebooting the appliance now...  
- [Info] Rebooting app2.symantec.com...
```

```
Broadcast message from root (Mon Nov 25 11:56:39 2013):
```

```
The system is going down for reboot NOW!
```

- [Info] Rebooting appliance to complete the reset.
Please reconnect to the Appliance shell menu to continue using this appliance

Support > InfraServices

Support > InfraServices – Display and control the infrastructure services.

SYNOPSIS

```
Show All
Start All
Stop All
Show Database
Start Database
Stop Database
Show MessageQueue
Start MessageQueue
Stop MessageQueue
Show Webserver
Start Webserver
Stop Webserver
```

DESCRIPTION

These commands exist under the `Main > Support > InfraServices` view. You can use these commands to monitor, start, and stop the infrastructure services.

Note: The infrastructure service commands are mainly used for troubleshooting and support. These should be used under the guidance of Technical Support. Stopping the infrastructure services may lead to failure of running operations.

OPTIONS

```
Show All
```

Shows the status of all the infrastructure services. The infrastructure services include the database, message queue, and the Web server service.

Start All

Used to start all the infrastructure services. The infrastructure services include the database, message queue, and the Web server service.

Stop All

Used to stop all the infrastructure services. The infrastructure services include the database, message queue, and the Web server service.

Show Database

Shows the status of the database.

Start Database

Used to start the database.

Stop Database

Used to stop the database.

Show MessageQueue

Shows the status of the message queue service.

Start MessageQueue

Used to start the message queue service.

Stop MessageQueue

Used to stop the message queue service.

Show Webserver

Shows the status of the Web server service.

Start Webserver

Used to start the Web server service.

Stop Webserver

Used to stop the Web server service.

Support > iostat

Support > iostat – Used to monitor system input and output device loading

SYNOPSIS

```
iostat help
```

```
iostat run
```

```
iostat [options] [interval] [count]
```

DESCRIPTION

The `iostat` command is a Linux command that you can use to monitor system input and output devices. The command enables you to observe the time that the devices are active in relation to their average transfer rates. This command generates reports that you can use to change the system configuration to better balance the input and the output load between physical disks. The `iostat` command generates reports continuously.

Note: You must run the `iostat run` command before you can use the available options that are supported for the `iostat` command.

OPTIONS

```
iostat help
```

View the help information of the command.

```
iostat run
```

Prompts you to enter the available options that are supported.

```
[options]
```

The following list describes the available options that are supported:

- `-c`
Display the CPU utilization report.
- `-d`
Display the device utilization report.
- `-N`
Display the registered device mapper names for any device mapper devices.
- `-n`

Display the network file system (NFS) report. This option works only with kernel 2.6.17 and later.

- `-h`
Make the NFS report that is displayed by option `-n` easier to read.
- `-k`
Display statistics in kilobytes per second instead of blocks per second.
- `-m`
Display statistics in megabytes per second instead of blocks or kilobytes per second.
- `-t`
Print the time for each report displayed.
- `-V`
Print the version number then exit.
- `-x`
Display the extended statistics.
- `-p [{ device [,...] | ALL }]`
The `-p` option displays the statistics for block devices and all their partitions that the system uses. If a device name is entered on the command line, then the statistics for it and all of its partitions are displayed. The `ALL` keyword indicates that statistics have to be displayed for all the block devices and partitions defined by the system. That includes those that have never been used.
- `[device [,...] | ALL]`
If a device name is entered on the command line, then the statistics for it and all of its partitions are displayed. The `ALL` keyword indicates that statistics have to be displayed for all the block devices and partitions defined by the system. That includes those that have never been used.

[interval]

- The *interval* parameter specifies the amount of time in seconds between each report.
- The first report contains statistics for the time since system startup. Each subsequent report contains statistics that are collected during the interval since the previous report.

[count]

- The *count* parameter can be specified with the *interval* parameter.

- If the *count* parameter is specified, the value of *count* determines the number of reports that are generated at *interval* seconds apart.

Support > IPMI

Support > IPMI – Use these commands to manage the IPMI configuration.

SYNOPSIS

```
IPMI Network Configure<IPAddress> <Netmask> <GatewayIPAddress>
```

```
IPMI Network Show
```

```
IPMI Reset
```

```
IPMI User Add <User_name>
```

```
IPMI User Delete <User_name>
```

```
IPMI User List
```

DESCRIPTION

The IPMI commands let you configure the IPMI network and manage users accessing the appliance using the IPMI connection. Use the IPMI commands to:

- Configure IPMI sub-system
- View the current IPMI settings
- Reset the IPMI
- Add users
- Delete users
- List users

OPTIONS

IPMI Network Configure

This command is used to configure the IPMI sub-system using the IPMI port.

IPMI Network Show

This command is used to view the current IPMI port information.

IPMI Reset

This command is used to reset the IPMI. You must reset IPMI only if the IPMI interface stops responding or hangs.

IPMI User Add

This command is used to add new users to access the IPMI sub-system.

IPMI User Delete

This command is used to delete existing users to access the IPMI sub-system.

IPMI User List

This command is used to view the list of users who can access the IPMI sub-system.

The following procedure is executed after you run the `IPMI Network Configure` command.

```
Support> IPMI Network Configure 10.182.8.70 255.255.240.0 10.182.1.1
Network is configured successfully.
```

The following information is displayed when you run the `IPMI Network Show` command.

```
Support> IPMI Network Show
IP Address Source      : STATIC
IP Address             : 10.182.8.70
Subnet Mask            : 255.255.240.0
Gateway IP Address     : 10.182.1.1
```

The following information is displayed when you run the `IPMI Reset` command.

```
Resetting the IPMI disconnects all current IPMI users.
Are you sure you want to reset the IPMI? [yes, no]: yes
```

In case other users are not affected, type **yes** and press **Enter** to continue. The following message is displayed:

```
-[Info] The IPMI is being reset...
-[Info] Wait for two minutes before attempting to reconnect to the
IPMI console. If you cannot access the IPMI console, the appliance
must be shut down and then restarted. First schedule a convenient time
for the shutdown, alert all users and shut down the appliance.
Then disconnect all appliance power cables for 15 seconds, reconnect
them and turn on power to the appliance.
```

Type **no** in case other users are affected. Alert all users and schedule a convenient time for reset. Run the `IPMI Reset` command again at the scheduled time.

The following procedure is executed after you run the `IPMI User Add <User_name>` command.

```
Support> IPMI User Add abc
New password:
```

Confirm password:
Operation successful

The following procedure is executed after you run the IPMI User Delete
<User_name> command.

```
Support> IPMI User Delete abc
User abc has been deleted successfully.
```

The following information is displayed after you run the IPMI User List command.

```
Support > IPMI User List

User name      : Anonymous User
User privilege : ADMIN

User name      : sysadmin
User privilege : ADMIN

User name      : root
User privilege : ADMIN
```

See [“About the commands under the Support view”](#) on page 28.

See [“About the NetBackup Appliance Shell Menu”](#) on page 12.

See [“About NetBackup Appliance Shell Menu usage”](#) on page 11.

Support > KillRemoteCall

Support > KillRemoteCall – Use to terminate remote calls on peer appliances.

SYNOPSIS

KillRemoteCall

DESCRIPTION

You can use this command to terminate remote calls on peer appliances. The remote calls that are terminated can be in a running or hung state.

OPTIONS

KillRemoteCall

Use this command to terminate remote calls on peer appliances.

Support > Logs

`Support > Logs` – Share, unshare logs files for the NetBackup appliance. Show and set debug levels for the logs.

SYNOPSIS

```
Logs Browse
Logs Delete Date LogType
Logs GetLevel
Logs SetLevel Option Level
Logs Share
Logs VXLogView JobID job_id
Logs VXLogView Minutes minutes_ago
Logs VXLogView Module module_name
Logs Upload JobID jobid case_num
Logs Upload Time start end case_num
```

DESCRIPTION

This command exists under the `Main_Menu > Support` view. You can use this command to do the following functions:

- Browse the NetBackup appliance log directories and files.
You can use the `Browse` command to view the log directories and log files that are configured in your appliance. When you run the `Logs Browse` command the command prompt changes to `LOGROOT/>`. From the `LOGROOT/` command prompt you can run the following commands to list, view, and change directories:
 - `ls` - List the directories and files
 - `tree` - Provides a tree-view of the directories and files.
 - `cd DIR` - Use to change the directory, where *DIR* is the directory name. For example, you can use `cd .`, `cd ..`, and `cd -`.
 - `less FILE` - Provides a read-only view of a file. You must enter the letter `q` or `quit` to exit this view.
 - `exit|quit` - Enables you to exit the log shell.

- `help|?` - Use either of these two commands to display help.

From the `LOGROOT/>` command prompt, you can use the `ls` command to see the following log directories on your appliance:

- `APPLIANCE`
- `GUI`
- `NBU`
- `OS`
- `PD`
- `VxVM`
- `WEBSERVER`

To see the log files from within a log directory, you must change directories to the log directory that contains the log files that you want to view. After you change directories, the same commands that were available under the `LOGROOT/` view are available for each of the log directories.

For example, to see the operating system (OS) log files, you must first enter `cd OS` at the `LOGROOT/>` command prompt. The command prompt changes to `LOGROOT/OS>/. Then you can enter ls to see the file names. Finally, you can use the less filename command to view a read-only version of the log file.`

- Set the level of debug logs

You can use the `Logs SetLevel` command to set the NetBackup log level for an appliance component that you choose. The range begins with zero and can differ for each component. A value of zero means that logging is at its lowest level.

In addition, you can use the `Logs GetLevel` command to get the NetBackup log level.

- Export or remove CIFS and NFS shares for the logs.

The `Log Share` command is used to export the CIFS and the NFS shares for the logs. The `Log Unshare` command removes the CIFS and the NFS shares for the logs.

- Display debug information from the VXlog files.

You can use the `Logs VXLogView` command to display log files for specific job or by a set duration of time.

- Upload the NetBackup log files for your appliance to Support. The files that you send can be based on the job ID, the time that the log files were taken, or the default-based duration.

If an issue occurs and you decide you need additional support, you should call Veritas Technical Support and open a customer case. The customer support

contact assigns a unique customer case number that identifies you, your company information, and your issue. To further help you diagnose the issue, the customer support contact needs to obtain a copy of your NetBackup appliance log files. You can use the `Logs Upload` command to send all of the log files that are associated with your appliance to Support.

The following procedure describes the process that you use to send the log files from your appliance to NetBackup Technical support.

To configure your appliance to upload log files using the `Logs Upload` command

- 1 Make sure that you have a customer case number assigned to your issue. If you do not have a case number, contact NetBackup Technical Support and have a customer case opened and a unique customer case number assigned to your issue. The customer case number is used to create the name of the file that you send so the Support. That helps the technical support contact identify the file that you sent.
- 2 Log on to your NetBackup appliance as the administrator.
- 3 From the shell menu command prompt, enter **Support**. That takes you into the **Support** view.
- 4 Enter one of the following commands to create a log set for technical support. Depending on the nature of your issue, technical support may ask you to use one of the following command to create the log set. Each of these commands creates a `.tar` file that is based on the job ID, a specific start and end time, or a default duration of four hours.
 - `Type Logs Upload Jobid jobid case_num.`
This command creates a `.tar` file that contains log files that are based on the job ID.
 - `Type Logs Upload Time start End case_num.`
This command creates a `.tar` file that contains log files that are based on the default duration of four hours
Where *case_num* is the customer case number that was issued to you by your NetBackup Support contact. This number becomes a part of the `.tar` file name so your Technical Support contact can identify the files that came from your appliance.
Where *jobid* is the job ID number that is used to collect the logs.
Where *start* and *End* are the start date and the end date of the logs to collect.

OPTIONS

Logs Browse

Use the show the appliance logs.

Logs Delete *Date LogType*

Use this command to delete archived log files. Here, *Date* defines the date until which you want to delete archived log files. and *LogType* is the product name (NetBackup/PureDisk/WebGUI/ALL) for which you want to delete the archived log files.

Logs GetLevel

Use to view the NetBackup log levels

Logs SetLevel *Option Level*

Use to set the NetBackup log levels. Where *Option* is the appliance component. For example, an appliance component can be NetBackup or PureDisk. In addition, *Level* is the appliance logging level. For NetBackup, you can select a level from 0 to 5 and for PureDisk, you can select a level from 0 to 10. Zero provides the lowest level of logging that is available.

Logs Share

Use to extract the CIFS and the NFS shares for the logs.

Logs VXLogView JobID *job_id*

Display debug information from the log files by designating a specific job ID as the criteria by which the information is parsed.

Where *job_id* is the NetBackup job that you determine you want to view from the debug information.

Logs VXLogView Minutes *minutes_ago*

Display debug information from the log files using time (in minutes) as the criteria by which the information is parsed.

Where *minutes_ago* is the amount of time, in minutes, used to determine how much of the past debug information to display.

Logs VXLogView Module *module_name*

Display debug information from the log files by designating a specific logging module as the criteria by which the information is parsed.

Where *module_name* is the module from which you want to view log files. You can select from the following modules: All, CallHome, Checkpoint, Common, Config, Database, Hardware, HWMonitor, Network, RAID, Seeding, SelfTest, Storage, SWUpdate, Commands, CrossHost, Trace, FTMS, FTDedup, AuthService, and TaskService.

Logs Upload JobID *jobid case_num*

Upload log files for the NetBackup appliance to Support. This command creates a .tar file of the logs using the job ID. Use FTP to upload the file to Support.

Where *jobid* contains the job ID number that is used to collect the logs. The *case_num* variable is a unique number filed with Support that identifies the customer and their corresponding log files. The format of this number is

###-###-###

Logs Upload Time *start end case_num*

Upload the logs based on the default duration. The default duration is four hours. This command creates a .tar file of the logs using the time. Use FTP to upload the file to Support.

Where *start* is the start date of the log files to send to Support. *end* is the end date of the log files to send to Support. And *case_num* is a unique number filed with Support that identifies the customer and their corresponding log files.

The format of this number is ###-###-###

Support > Maintenance

Support > Maintenance – Enables the user to open an interactive shell menu.

SYNOPSIS

Maintenance

DESCRIPTION

Your appliance is pre-configured with a **Maintenance** user account. When you log into this account, you open an interactive shell menu that you can use to troubleshoot or manage underlying operating system tasks.

This command exists under the `Main_Menu > Support` view. The default password is, `P@ssw0rd`. Veritas recommends that you change this password at your earliest convenience. Use the following command to reset the password.

```
Main > Settings > Password user_name
```

In this case, the user name is `maintenance`.

If you require customer support to resolve an issue, you may be required to provide this password to your support representative. In addition, if you change this password and then run the `FactoryReset` command, this password is reset to the initial default value.

OPTIONS

Maintenance

Used to enter an interactive shell menu that you can use to troubleshoot or manage underlying operating system tasks.

EXAMPLES

To enter your Maintenance account, run the following command, and provide the password when you receive a prompt.

```
NBApl.Support> Maintenance
<!--Maintenance Mode--!>
maintenance's password:
```

Run the following command to change your Maintenance password, from the default password to a new password.

```
NBAppl.Settings> Password maintenance
Changing password for user "maintenance"
Old Password      : P@ssw0rd
Password          : newpassword
Confirm password  : newpassword

all authentication tokens updated successfully.
```

Support > Messages

Support > Messages – Display the message file.

SYNOPSIS

Messages *lines*

DESCRIPTION

This command exists under the `Main_Menu > Support` view. Use this command to display the messages file. With this command, you can designate the number of lines that you want to display from that file. If you do not define the number of lines the entire messages file is displayed.

OPTIONS

Messages *lines*

Display the message file. Here, *lines* is the number of lines that are to be displayed in the message.

Support > NBDNA

Support > NBDNA – Create and remove network traces with the NBDNA utility.

SYNOPSIS

NBDNA Create *phase*

NBDNA Remove

DESCRIPTION

This command exists under the `Main_Menu > Support` view. This command is used in conjunction NetBackup Domain Network Analyzer utility. The NetBackup Domain Network Analyzer (NBDNA) is a utility that analyzes the following information:

- The NetBackup domain and its configuration for network issues
- Performance
- Behavior in regards to hostname lookup and connectivity between NetBackup hosts and their role within the NetBackup domain

You can run NBDNA on a NetBackup a primary or a secondary appliance.

OPTIONS

NBDNA Create *phase*

Used to create and remove network traces with the NetBackup Domain Network Analyzer utility.

Where *phase* is used to specify which test phase to run, phase 0, phase 1, or phase 2.

Phase 0: Default mode. Name lookup test and socket connection test.

Phase 1: Includes Phase 0. Add basic NetBackup service test for the SERVER list.

Phase 2: Includes Phase 0. Add basic NetBackup service test for SERVER and CLIENT list.

NBDNA Remove

Use to remove all existing trace files that the NetBackup Domain Network Analyzer generates.

Support > nbperfchk

Support > nbperfchk – Measures a disk array's read and write speeds.

SYNOPSIS

```
nbperfchk -i inputpath -o outputpath [-s filesize] [-syncend] [-bs buffersize]
```

DESCRIPTION

The `nbperfchk` command measures the read speed and write speed of a disk array. You can use this command to test the read speed and the write speed of the disks that host deduplicated data. For example, you can measure the speeds of the disks that host deduplicated data as follows:

- In a PureDisk storage pool, use this command to measure the speed of disks attached to the content router.
- In a NetBackup media server deduplication pool (MSDP), use this command to measure the speed of the disks attached to the media server. The media server can be running any operating system that Veritas supports for media servers and MSDPs.

Note: Veritas recommends that you work with a Veritas Technical Support staff member when you run this command and interpret its results. Veritas recommends a minimum disk performance level of 130 MB/sec for deduplicated read and write operations.

The `nbperfchk` command is functionally equivalent to the obsolete `camel` command that was available from Veritas as a downloadable program but was not associated with any specific product release. The `camel` command is available internally from the Veritas Technical Support website as HOWTO47457.

The `nbperfchk` utility enables you to write a test file to a disk, read back that test file, and observe the read speeds attained during the read operation. You can use the results from `nbperfchk` to make sure that the `ReadBufferSize` parameter is set appropriately in your backup environment. The `ReadBufferSize` parameter resides in the `[CRDataStore]` section of the `contentrouter.cfg` file. You can use this command as follows:

- Use the following command to write data to the disks:

```
nbperfchk -i inputpath -o outputpath -s filesize -syncend
```

- Use the following command to read data from the disks:

```
nbperfchk -i inputpath -o outputpath -bs buffersize
```

OPTIONS

`-i inputpath`

For *inputpath*, specify the full path to an input file. The `nbperfchk` command reads this file and generates information about the read speed when this file is read to disk.

For example, you can specify the following to read in a file that contains all zero characters (0x00) from the `/dev/zero`:

`-o outputpath`

For *outputpath*, specify the full path to an output file. The `nbperfchk` command creates this file.

For example, on writes, specify the path to the output file that you want to create. On reads, specify `-o NUL` to discard all the output as it is generated.

`-s filesize`

For *filesize*, specify a file size that is equal to or larger than than combined memory size of your computer plus the amount in the disk array. A file of this size ensures that the data is written to disk and not to a buffer.

`-syncend`

The `syncend` parameter flushes the buffer and writes all data to disk.

`-bs buffersize`

For *buffersize*, specify the read buffer size to use when `nbperfchk` runs. For example, `64k` or `128k`.

PROCEDURES

To analyze nbperfchk results and adjust the ReadBufferSize parameter setting

- 1 Log in as the root user (UNIX) or the administrator (Windows) on the computer that hosts the content router.

In PureDisk environments, log into the storage pool authority node or storage pool authority appliance.

In NetBackup environments, log into the media server.
- 2 Change to a test directory.

- 3 Type the `nbperfchk` command in the following format to write a large test file to the content router:

```
nbperfchk -i inputpath -o outputpath -s filesize -syncend
```

For example, the following command writes a 64 GB data file that contains all zeros to the `e` drive:

```
nbperfchk -i zero: -o e:\datal -s 64g -syncend
```

- 4 Type the `nbperfchk` command in the following format to read the test file and observe the read speeds in the `nbperfchk` output:

```
nbperfchk -i inputpath -o NUL -bs buffersize
```

Example 1. To observe several read speeds, with several buffer sizes, type the following series of commands:

```
nbperfchk -i e:\datal -bs 64k -o NUL
nbperfchk -i e:\datal -bs 128k -o NUL
nbperfchk -i e:\datal -bs 256k -o NUL
```

Example 2. The following `nbperfchk` command reads back the data in file `datal` and uses a buffer size of 1024 K:

```
C:\Users\administrator.mymediaserver\Desktop>nbperfchk -i e:\datal -bs 1024k -o NUL
195 MB @ 65.3 MB/sec, 194 MB @ 64.9 MB/sec
295 MB @ 49.4 MB/sec, 100 MB @ 33.5 MB/sec
403 MB @ 44.8 MB/sec, 108 MB @ 35.8 MB/sec
505 MB @ 42.1 MB/sec, 102 MB @ 34.1 MB/sec
599 MB @ 40.0 MB/sec, 94 MB @ 31.3 MB/sec
705 MB @ 39.2 MB/sec, 106 MB @ 35.5 MB/sec
821 MB @ 39.2 MB/sec, 116 MB @ 38.8 MB/sec
943 MB @ 39.4 MB/sec, 122 MB @ 40.8 MB/sec
1024 MB @ 40.1 MB/sec
```

Observe the following when you analyze the data:

- The left two columns show the amount of data read and the average read speed.
- The final line shows the overall read speed. This is the most important line in this output because it shows you how fast the total read occurred with the buffer size you specified.

- The right two columns show the average read speed in the last 3 seconds of each read. Unless these numbers vary drastically from read to read, you can disregard the right two columns.
- 5 Analyze your read speeds and adjust the `ReadBufferSize` parameter if necessary.

Your operating system, your disk speeds, and the `ReadBufferSize` parameter setting all affect restore and rehydration performance.

Veritas recommends that you type several `nbperfchk` commands and increase the size of the argument to the `-bs` parameter each time. Example 1 in step 4 shows this method. If you can enter ever-increasing arguments to the `-bs` parameter, you can probably increase the size of the `ReadBufferSize` parameter in the `[CRDataStore]` section of the `contentrouter.cfg` file.

By default, `ReadBufferSize=65536`, which is 64K. Veritas testing shows that `ReadBufferSize=1048576`, which is 1024 X 1024, or 1M, offers good performance on most Windows systems. On most UNIX systems, Veritas testing shows that `ReadBufferSize=65536` (the default) offers good performance.

For information about how to edit NetBackup configuration files, see your NetBackup documentation.

For information about how to edit PureDisk configuration files, see the *PureDisk Administrator's Guide*.

Support > NBSU

Support > NBSU – Manage NetBackup support data files

SYNOPSIS

NBSU Create

NBSU Remove

DESCRIPTION

This command exists under the `Main_Menu > Support` view. The NetBackup Support Utility (NBSU) is a Veritas utility used to gather diagnostic information about the system on which the utility is run. By default, NBSU gathers appropriate diagnostic information based on the operating system and NetBackup environment.

You can use this command to create or remove the NetBackup configuration support files that the NBSU utility uses.

OPTIONS

NBSU Create

Use to create NetBackup configuration support files.

NBSU Remove

Use to remove any NetBackup configuration support files.

Support > Processes

Support > Processes – Display and control the NetBackup and Administration console processes.

SYNOPSIS

```
Processes AdminConsole Show
Processes AdminConsole Start
Processes AdminConsole Stop
Processes NetBackup Show
Processes NetBackup Start
Processes NetBackup Stop
```

DESCRIPTION

This command exists under the Main > Support view. You can use this command to monitor, start, and stop the NetBackup processes and the administration console processes.

OPTIONS

```
Processes AdminConsole Show
    Shows the administration console processes that are currently active.

Processes AdminConsole Start
    Used to start the administration console processes.

Processes AdminConsole Stop
    Used to stop the administration console processes.

Processes NetBackup Show
    Shows the NetBackup processes that are currently active.

Processes NetBackup Start
    Used to start the NetBackup processes.

Processes NetBackup Stop
    Used to stop the NetBackup processes.
```

Support > Reboot

`Support > Reboot` – Reboot the system

SYNOPSIS

`Reboot [Force]`

DESCRIPTION

Use this command to reboot the current system. You cannot use this command to restart another system remotely.

OPTIONS

`Reboot [Force]`

Use this command to restart the system.

The `Force` parameter forces the system to restart even if services are not able to be stopped. Use this parameter if a previous attempt failed.

Support > RecoverStorage

Support > RecoverStorage – View or purge any storage recovered during a reimage

SYNOPSIS

```
RecoverStorage PurgeBackups
```

```
RecoverStorage ViewBackups
```

DESCRIPTION

This command exists under the `Main_Menu > Support` view. Use this command to view or purge the data sets that were saved during the reimage.

OPTIONS

```
RecoverStorage PurgeBackups
```

Use this command to purge the storage that was recovered during the Appliance reimage operation.

```
RecoverStorage ViewBackups
```

Use this command to view the storage that was recovered during the Appliance reimage operation.

EXAMPLES

The following prompt is displayed after you run the `RecoverStorage PurgeBackups` command.

```
Are you sure you want to delete data found on disk during reimage? (yes/no)
```

Type **yes** to delete the data recovered during reimage.

Support > Service

`Support > Service` – You can use this command to restart a service on a host. When you use this command you designate the name of the service that you want to restart and the target host name.

SYNOPSIS

```
Service Restart
```

```
Service Stop
```

DESCRIPTION

You can use this command to stop or restart a service on a host. You must provide the name of the service that you want to stop or restart.

OPTIONS

```
Service Restart ServiceName
```

Use this command to restart a service on your appliance. Here, *ServiceName* is the name of the service that you want to restart. For example, network.

```
Service Stop ServiceName
```

Use this command to stop a service on your appliance. Here, *ServiceName* is the name of the service that you want to stop. For example, smb.

Support > ServiceAllowed

Support > ServiceAllowed – Use the `ServiceAllowed` commands to set specific components of a Primary or an Expansion Storage Shelf to the Service Allowed mode so that service can be performed on those units.

SYNOPSIS

```
ServiceAllowed Set PrimaryShelf
```

```
ServiceAllowed Set ExpansionShelf
```

DESCRIPTION

The `ServiceAllowed` command options let you set specific components of a Primary or an Expansion Storage Shelf to the Service Allowed mode so that service can be performed on those units.

Veritas requires that you perform this procedure only with assistance from Veritas Technical Support. Before you attempt to run these commands, refer to the following documents:

NetBackup Appliance Administrator's Guide

NetBackup Appliance Troubleshooting Guide

OPTIONS

The following command options are available for the `ServiceAllowed Set PrimaryShelf` command:

```
ServiceAllowed Set PrimaryShelf Controller location flag
```

Use this command to set the Service Allowed flag for a Primary Shelf controller.

Where *location* is A or B, and *flag* is on or off.

```
ServiceAllowed Set PrimaryShelf FanCanister location flag
```

Use this command to set the Service Allowed flag for a Primary Shelf fan canister.

Where *location* is Left or Right, and *flag* is on or off.

```
ServiceAllowed Set PrimaryShelf HDD DrawerID SlotNo Flag
```

Use this command to set the Service Allowed flag for a Primary Shelf hard disk drive.

Where *DrawerID* is 1-5, *SlotNo* is 1-12, and *flag* is on or off.

`ServiceAllowed Set PrimaryShelf PowerCanister location flag`

Use this command to set the Service Allowed flag for a Primary Shelf power canister.

Where *location* is Top or Bottom, and *flag* is on or off.

The following command options are available for the `ServiceAllowed Set ExpansionShelf` command:

`ServiceAllowed Set ExpansionShelf ExpansionCanister location flag`

Use this command to set the Service Allowed flag for an Expansion Shelf canister.

Where *location* is Top or Bottom, and *flag* is on or off.

`ServiceAllowed Set ExpansionShelf FanCanister location flag`

Use this command to set the Service Allowed flag for an Expansion Shelf fan canister.

Where *location* is Left or Right, and *flag* is on or off.

`ServiceAllowed Set ExpansionShelf HDD ExpansionShelfID DrawerID SlotNo Flag`

Use this command to set the Service Allowed flag for an Expansion Shelf hard disk drive.

Where *ExpansionShelfID* is 0 - 98, *DrawerID* is 1-5, *SlotNo* is 1-12, and *flag* is on or off.

`ServiceAllowed Set ExpansionShelf PowerCanister location flag`

Use this command to set the Service Allowed flag for an Expansion Shelf power canister.

Where *location* is Top or Bottom, and *flag* is on or off.

Support > Show

Support > Show – Displays reference table for hardware diagnosis.

SYNOPSIS

Show HW-DiagnosisHelp

DESCRIPTION

Use this command to view the reference table for hardware diagnosis. Using the reference table, you can identify the potential causes of various error states, such as critical warnings or failures, of a hardware.

Note: This command is available only for a 52xx appliance.

OPTIONS

Show HW-DiagnosisHelp

Use this command to display the reference table for hardware diagnosis.

EXAMPLES

The following is an example of the information that is displayed when you run the Main > Support > Show HW-DiagnosisHelp command.

Reference Chart

ID	Device	State	Diagnosis
1	Power Supply	Warning	Check if both the Power Supply Units are cabled and is receiving power * If PS is cabled and receiving power, call Symantec support to replace the Power Supply Unit
2	CPU	Failed	Check the status column. * If the status is "Disabled", run the test again. (ipmitool may sometimes report incorrect CPU status)

			* If the failure persists, call Symantec support to replace the CPU

			Check the status column
			* "Device Absent" indicates that the fan is either not inserted correctly or the power supply cable for the fan is loose.
3	Fan	Failed	
			* If the fan is inserted correctly or the power supply cable is inserted correctly on the motherboard, call Symantec support to replace the fan.

			Check the Speed column.
			* Speed will be above the high water mark levels. Check if any other fan is in failed state. If yes, call Symantec support to replace the failed fan. Once replaced, the speed will stay within water mark level.
4	Fan	Warning	
			* If none of the other fans have failed, check the temperature table. If the temperature of appliance rises, then fan speed increases unless proper cooling is provided to the machine.

			Check the "Slot number" column
5	Disk	Failed	
			* Call Symantec support to replace the drive in that slot

			Check the "Status" column
			* Drive in that slot was supposed to be in "Hotspare" state. It might have changed the state due to a drive failure in another slot.
6	Disk	Warning	
			* If none of the other drives are in failed state, copyback needs to be initiated so that the drive in this particular slot becomes a "hotspare"

7	Fiber Channel	Failed	* Call Symantec support to replace the FC card

8	Temperature	Warning	* Make sure enough cooling is provided so that the temperature does not cross the high threshold limit

9	RAID	Failed	Check the "status" column

			* Multiple drive failure can result in RAID volume going offline

			Check the "Write Policy" column

			* If it is in "WriteThrough" mode, check the "RAID adapter" table. If either the "BBU learn cycle active" field for that RAID adapter is "yes" OR if the "BBU charge" field is less than 60%, the write policy will temporarily remain in WriteThrough mode.

10	RAID	Warning	* If "BBU learn cycle active" is not "yes" AND "BBU charge" is more than 60%, change the write policy for RAID-6 to "WriteBack with BBU" using MegaCli

			* Status can be "Degraded" or "Partially degraded". One or more drives might have failed. Call Symantec support to replace the failed drive (s) and wait for the rebuild and copyback operation to complete.

			Check "Adapter status" and "BBU status" column

			* Either adapter NVRAM, Memory, or Flash of the adapter is absent or bad. Call Symantec support to replace the RAID card
11	Adapter	Failed	* Either BBU, BBU voltage or BBU temperature is not OK, call Symantec support to replace the BBU on that adapter.

			* This is a temporary state when either the BBU

12	Adapter	Warning	learn cycle is active or the BBU charge is less
			than 60%

			* Warning indicates that either the PCI card in
13	PCI	Warning	not inserted in the compatible slot or an
			unsupported card is inserted.

lines 51-109/109 (END)

Support > Shutdown

Support > Shutdown – Turn off the system

SYNOPSIS

Shutdown

DESCRIPTION

Use this command to turn off the current system.

OPTIONS

Shutdown

Use to turn off the current system.

Support > Storage Reset

`Support > Storage Reset` – Use the `Storage Reset` command to delete the backup data and partitions from the appliance, and configures the disk status for all the disks as New Available.

SYNOPSIS

`Storage Reset`

DESCRIPTION

This command is available when the appliance is in a factory install state. An appliance is in a factory install state when it has not been configured as a master or media server (or the role is not configured). This command stops the NetBackup processes, deletes the backup data and partitions from the appliance, and configures the disk status for all the disks as New Available.

EXAMPLES

The following procedure is executed after you run the `Reset` command from the `Support > Storage` menu.

```
Support> Storage Reset
```

```
=====StorageReset=====
```

```
Resetting storage will delete any existing data and configuration.  
>> Do you want to continue? (yes,no): yes
```

```
- [Info] Stopping NetBackup services ...please wait.  
- [Info] Resetting the storage configuration...  
- [Info] Stopping NetBackup processes... (6 mins approx)  
- [Info] Checking whether the 'MSDP' storage partition exists...  
- [Info] The 'MSDP' storage partition does not exist.  
- [Info] Checking whether the 'Catalog' storage partition exists...  
- [Info] Initiating deletion of 'Catalog' storage partition...  
- [Info] Unmounting the 'Catalog' storage '0' partition...  
- [Warning] Failed to unmount the 'Catalog' storage '0' partition.  
The 'Catalog' storage '0' partition may not be mounted.  
- [Info] Deleting the 'Catalog' storage '0' partition...  
- [Info] Checking whether the 'Configuration' storage partition exists...  
- [Info] Initiating deletion of 'Configuration' storage partition...
```

- [Info] Unmounting the 'Configuration' storage '0' partition...
- [Warning] Failed to unmount the 'Configuration' storage '0' partition.
The 'Configuration' storage '0' partition may not be mounted.
- [Info] Deleting the 'Configuration' storage '0' partition...
- [Info] Checking whether the 'AdvancedDisk' storage partition exists...
- [Info] Initiating deletion of 'AdvancedDisk' storage partition...
- [Info] Unmounting the 'AdvancedDisk' storage '0' partition...
- [Warning] Failed to unmount the 'AdvancedDisk' storage '0' partition.
The 'AdvancedDisk' storage '0' partition may not be mounted.
- [Info] Deleting the 'AdvancedDisk' storage '0' partition...
- [Info] Removing the storage configuration...
- [Info] Succeeded.
- [Info] Starting NetBackup services ...
- [Info] Successfully started NetBackup services.

Support > Storage SanityCheck

Support > Storage SanityCheck – Use the Storage SanityCheck command if you want to disable or enable storage sanity checks.

SYNOPSIS

```
Storage SanityCheck Disable
```

```
Storage SanityCheck Enable
```

DESCRIPTION

Storage sanity check runs everyday and also runs as a part of storage manipulation operations. The Storage sanity check helps to fix some of the storage issues or reports them. The storage sanity check is enabled by default. Use the `Support> Storage SanityCheck Disable` command to disable the storage sanity check. This command can be used for debugging mostly by Support engineers. Use the `Support> Storage SanityCheck Enable` command to enable the storage sanity check.

Support > Test

Support > Test – Test the current status of the various appliance components.

SYNOPSIS

Test Hardware

Test Software

DESCRIPTION

The appliance runs a test at regular intervals to check the status of its hardware and software components. This ability of the appliance is referred to as self test. Use the `Test` command to verify the current status of the various appliance software components.

OPTIONS

Test Hardware

Use this command to view the enhanced hardware monitoring page that displays the status of various hardware components.

EXAMPLES

The following is an example of information that is displayed when you run the `Main > Support > Test Hardware` command.

```
abc123.Support> Test Hardware
Gathering hardware information. It might take about a minute...
```

```
Compute Node abc123.engba.symantec.com
```

```
Time Monitoring Ran: Mon Mar 25 2013 23:15:06 PDT
```

```
+-----+
|                                     Power Supply Information                                     |
+-----+
||ID|           Status           | Wattage | HighWaterMark | State |Acknowledge |
+---+-----+-----+-----+-----+-----+-----+
||1 |Power Supply AC lost |0.00 Watts |920.00 Watts  |Warning|No          |
+-----+
|                                     PCI Information                                     |
```

ID	Slot	Details	State	Acknowledge
1	1	EMPTY	Warning	No
4	4	EMPTY	Warning	No

The following is an example of information that is displayed when you run the [Main > Support > Test Software]command for a Master appliance.

```
xyz123.Support> Test Software
```

```
Running Validation tests on Master Appliance xyz123.
```

```
Checking whether serial number is present ... [OK]
Checking whether installation is successful ... [OK]
Checking whether critical kernel drivers exist and can work ... [OK]
Checking whether SSH is enabled ... [OK]
Checking whether hostname is set ... [OK]
Checking whether IP address is set ... [OK]
Checking whether appliance user accounts exist ... [OK]
Checking whether required packages are installed ... [OK]
Checking whether BIOS firmware is compatible with the software ... [NA]
Checking whether registration information is properly set ... [OK]
Checking whether NetBackup is configured and running ... [OK]
Checking whether storage units and diskpools have been created ... [OK]
Checking whether Web Server is configured and running ... [OK]
Checking test backup and restore operations ... [OK]
Expiring test backup images and deleting test policy ... [OK]
```

```
Completed running tests on the appliance.
```

```
SELF TEST RESULT : [PASS]
```

See [“Logging into the NetBackup Appliance Shell Menu ”](#) on page 11.